





1




2






1x





3




4





5






6





7






8






9





10





11





12




13





14





15





16





17




18




19




20




如3D打印件裝上後不會鬆動，可以跳過這步驟




21



22




貼上灰色貼紙，確保黑色
部份與指針前部對齊。




23





1x





24





25




26





27




28




29




30




31





32




33




34





35





36






37



38



39



40

