

What you'll need:


- Apple Computer
- USB Thumb Drive
- ► Internet Connection ► USB Cable
- LightBurn License Key

Software and Driver Installation

1 Go to https://lightburnsoftware.com and click on Download / Trial.



2 Download LightBurn to your computer LightBurn will run on MacOS 10.11 or later.



3 Double-click the LightBurn.dmg file to mount the disk image.




4 Drag the LightBurn application into your applications folder, and then double-click on the LightBurn icon to begin.



NOTE

If Lightburn will not open because it cannot be verified, perform the following:



5 Copy and paste your LightBurn License Key, which can be found in your Getting Started email. Then click the Activate License button, and click OK.




Connecting via USB

1 Plug the USB thumb drive that came with your laser into an open USB port on your computer.




2 If the Devices Window does not popup, click on Devices in the Laser Window.



3 In the Devices Window, click the Import button.



4 Navigate to the DISK_IMG drive.




5 Click on the Settings folder.




6 Select the file ending in USB.lbdev, and click Open.




7 Select the new USB device from the Devices list and click OK.



8 In the Laser Window, select the new USB device from the dropdown menu.



9 Plug one end of the USB cable that came with your laser, directly into an open USB port on your computer.




NOTE

USB cables longer than 10 feet, and USB hubs, are not recommended.


10 Plug the other end of the supplied USB cable into the bottom USB port, on the right side of the machine.



In the Laser Window, right-click the Devices button to reset the connection. It should now say Ready.



Congratulations! LightBurn is now paired with your laser via USB.





Connect via WiFi

1 Plug the USB thumb drive that came with your laser into an open USB port on your computer



2 If the Devices Window does not popup, click on Devices in the Laser Window.







3 In the Devices window, click the Import button.




4 Navigate to the DISK IMG drive on your computer.




5 Select the Settings folder.




6 Select the file ending in WiFi.lbdev, and click Open.




7 Select WiFi from the Device List, and click on OK.




8 In the Laser Window, select the new WiFi device from the dropdown menu.




9 Click on the WiFi symbol at the top, right hand corner of your computer Taskbar.



10 Select your laser from the list of available WiFi connections, and click Connect.



11 In the Laser Window, right-click the Devices button to reset the connection. It should now say Ready.



Congratulations! LightBurn is now paired with your laser via WiFi. You are now ready to create wirelessly!

