

FIT CHECK SHEET — PRINT AT 100% SCALE

- 1. Check the 10 mm bar below with a ruler before anything else.
- 2. Put the real ESP32-S3 Super Mini on the two pad rows.
- 3. Compare the pin labels with the silkscreen on your module.

If anything differs, edit `MODUL_SPACINGS/BOARD-mgen/gen_pcb.py`

	J_MCU_A		J_MCU_B	
5V				GPIO8
GND				GPIO7
3V3				GPIO6
GPIO13				GPIO5
GPIO12				GPIO4
GPIO11				GPIO3
GPIO10				GPIO2
GPIO9				GPIO1

10 mm — measure this first

assumed: 8 pins per row, rows 15.24 mm apart, 2.54 mm pitch