### From analog to discrete-time systems

Kjartan Halvorsen

2022-06-30

## The world according to the discrete-time controller





Figure 1.1 Schematic diagram of a computer-controlled system.


Source: Åström and Wittenmark

"Computer-controlled systems".

### Discrete-time Linear Shift-Invariant systems




#### Discrete-time Linear Shift-Invariant systems



#### General case (non-causal)

$$y(k) = g * u = \sum_{n=-\infty}^{\infty} g(n)u(k-n)$$
  
= \cdots + g(-2)u(k+2) + g(-1)u(k+1) + g(0)u(k) + g(1)u(k-1) + \cdots

### Discrete-time Linear Shift-Invariant systems



General case (non-causal)

$$y(k) = g * u = \sum_{n=-\infty}^{\infty} g(n)u(k-n)$$
  
= \cdots + g(-2)u(k+2) + g(-1)u(k+1) + g(0)u(k) + g(1)u(k-1) + \cdots


Causal case

$$y(k) = g * u = \sum_{n=0}^{\infty} g(n)u(k-n)$$
  
=  $g(0)u(k) + g(1)u(k-1) + g(2)u(k-2) + g(3)u(k-3) + \cdots$ 

#### Discrete-time LSI systems

#### Impulse response

If the input signal is a unit discrete impulse



#### Discrete-time LSI systems

#### Impulse response

If the input signal is a unit discrete impulse




$$y(k) = \sum_{n=0}^{\infty} g(n)\delta(k-n) = g(k)$$

The weighting sequence is equal to the impulse response of the system.

The response of a discrete LSI system is a weighted sum of the current and previous values of the input

$$y(k) = g * u = \sum_{n=0}^{\infty} g(n)u(k-n) = g(0)u(k) + g(1)u(k-1) + g(2)u(k-2) + \cdots$$

Activity What is the response of a system to the input signal u(k) if its impulse response (weighting sequence) is the one below?



$$y(k) =$$

## The Laplace transform

#### **Definition**

$$F(s) = \mathcal{L}\left\{f(t)\right\} = \int_0^\infty f(t) \mathrm{e}^{-st} dt$$

Inverse transform

$$f(t) = \mathcal{L}^{-1}\{F(s)\} = rac{1}{2\pi i} \int_{\gamma-i\infty}^{\gamma+i\infty} F(s) \mathrm{e}^{st} \, ds$$

Note that in control engineering, the one-sided transform is used.

#### The z-transform

#### **Definition**

$$F(z) = \mathcal{Z}\left\{f(kh)\right\} = \sum_{k=0}^{\infty} f(kh)z^{-k}$$

#### Inverse transform

$$f(kh) = \frac{1}{2\pi i} \oint_r F(z) z^{k-1} dz$$

Note that in control engineering, the one-sided transform is used.

### The Laplace transform of a sampled signal

Assume right-sided signal f(t), meaning it is zero for negative times t < 0.

$$f_s(t) = f(t)m(t) = f(t)\sum_{k=0}^{\infty} \delta(t - kh) = \sum_{k=0}^{\infty} f(t)\delta(t - kh) = \sum_{k=0}^{\infty} f(kh)\delta(t - kh)$$

## The Laplace transform of a sampled signal

Assume right-sided signal f(t), meaning it is zero for negative times t < 0.

$$f_s(t) = f(t)m(t) = f(t)\sum_{k=0}^{\infty} \delta(t - kh) = \sum_{k=0}^{\infty} f(t)\delta(t - kh) = \sum_{k=0}^{\infty} f(kh)\delta(t - kh)$$

$$F_{s}(s) = \mathcal{L}\left\{f_{s}(t)\right\} = \int_{0}^{\infty} \left(\sum_{k=0}^{\infty} f(kh)\delta(t-kh)\right) e^{-st} dt$$
$$= \sum_{k=0}^{\infty} \int_{0}^{\infty} f(kh)\delta(t-kh)e^{-st} dt = \sum_{k=0}^{\infty} f(kh)e^{-skh}$$
$$= \sum_{k=0}^{\infty} f(kh)\left(e^{sh}\right)^{-k}$$

## The Laplace transform of a sampled signal

Note:

$$F_s(s) = \sum_{k=0}^{\infty} f(kh) \left(\mathrm{e}^{sh}
ight)^{-k}$$
 Laplace transform  $F(z) = \sum_{k=0}^{\infty} f(kh) z^{-k}$  z-transform

The z-transform of a sampled signal corresponds to its Laplace transform with the following relationship between the s-plane of the Laplace transform and the z-plane of the z-transform.

$$z = e^{sh}$$

#### Exercise on the z-transform




#### Exercise on the z-transform



$$G(z) = \sum_{k=0}^{\infty} g(k)z^{-k}$$
 z-transform

Activity What is the z-transform of the delayed impulse signal  $g(k) = \delta(k-4)$  below?



## One of the most important transform pairs

$$f(kh) = \alpha^{kh}, \quad \alpha \in \mathbb{C}$$

# One of the most important transform pairs

$$f(kh) = \alpha^{kh}, \quad \alpha \in \mathbb{C}$$

$$F(z) = \mathcal{Z}\left\{f(kh)\right\} = \sum_{k=0}^{\infty} f(kh)z^{-k} = \sum_{k=0}^{\infty} \alpha^{kh}z^{-k} = \sum_{k=0}^{\infty} \left(\alpha^{h}\right)^{k} z^{-k}$$
$$= \sum_{k=0}^{\infty} \left(\frac{\alpha^{h}}{z}\right)^{k} = \frac{1}{1 - \frac{\alpha^{h}}{z}} = \frac{z}{z - \alpha^{h}}, \quad \left|\frac{\alpha^{h}}{z}\right| < 1$$

## One of the most important transform pairs

$$f(kh) = \alpha^{kh}, \quad \alpha \in \mathbb{C}$$

$$F(z) = \mathcal{Z}\left\{f(kh)\right\} = \sum_{k=0}^{\infty} f(kh)z^{-k} = \sum_{k=0}^{\infty} \alpha^{kh}z^{-k} = \sum_{k=0}^{\infty} \left(\alpha^{h}\right)^{k} z^{-k}$$
$$= \sum_{k=0}^{\infty} \left(\frac{\alpha^{h}}{z}\right)^{k} = \frac{1}{1 - \frac{\alpha^{h}}{z}} = \frac{z}{z - \alpha^{h}}, \quad \left|\frac{\alpha^{h}}{z}\right| < 1$$

$$\alpha^{kh} \quad \stackrel{\mathcal{Z}}{\longleftrightarrow} \quad \frac{z}{z - \alpha^h}$$






Figure 1.1 Schematic diagram of a computer-controlled system.

Source: Åström and Wittenmark


"Computer-controlled systems".





Step-invariant sampling (zero order hold): 
$$u(kh) = \begin{cases} 1, & k \geq 0 \\ 0, & k < 0 \end{cases}$$


The idea is to sample the continuous-time system's response to a step input, in order to obtain a discrete approximation which is exact (at the sampling instants) for such an input signal.



Step-invariant sampling (zero order hold):  $u(kh) = \begin{cases} 1, & k \ge 0 \\ 0, & k < 0 \end{cases}$ 

## Why is step-invariant sampling a good idea?

A piecewise constant (stair-case shaped) function can be written as a sum of delayed step-responses!



## Step-invariant sampling, or zero-order-hold sampling

Let the input to the continuous-time system be a unit step  $u(t) = u_H(t)$ , which has Laplace transform  $U(s) = \frac{1}{s}$ . In the Laplace-domain we get

$$Y(s)=G(s)\frac{1}{s}$$

- 1. Obtain the time-response by inverse Laplace:  $y(t) = \mathcal{L}^{-1} \left\{ Y(s) \right\}$
- 2. Sample the time-response to obtain the sequence y(kh) and apply the z-transform to obtain  $Y(z) = \mathcal{Z}\{y(kh)\}$
- 3. Calculate the pulse-transfer function by dividing with the z-transform of the input signal  $U(z) = \frac{z}{z-1}$ .

$$H(z) = \frac{Y(z)}{U(z)} = \frac{z-1}{z}Y(z)$$