Creatista

Price

Creatista Plus

Price = 899.00

Creatista Pro

Price = 1299.00

Cup Sizes

Size and/or Milk Recipe	Ristretto	Espresso	Lungo	Cappuccino	Flat White	Latte Macchiato	Caffe Latte	Hot Milk	Mocha	Americano
Image	25 ml Ristretto	40 ml Espresso	110 ml Lungo	Cappuccino	Flat White	Latte macchiato	Caffè Latte	Hot milk	Mocha	230ml Americano
Machine	Creatista Plus, Creatista Pro	Creatista Plus, Creatista Pro	Creatista Plus, Creatista Pro	Creatista Plus, Creatista Pro	Creatista Pro	Creatista Plus, Creatista Pro	Creatista Plus, Creatista Pro	Creatista Pro	Creatista Plus	Creatista Pro

Specifications

<u>Creatista Plus</u>
- Dimensions (W x D x H) = 17 x 40.9 x 30.9 cm
- Weight = 5.2 kg
- Warranty = 2 years
- Removable Water Tank = 1.5 L
- Automatic Power Off = after 10 minutes of non-use
- Clean System = Descaling Alert
- Capsule Container Capacity = 14 capsules
- Removable Milk Jug = 500 ml

<u>Creatista Pro</u>
- Dimensions (W x D x H) = 19.7 x 42.9 x 32.8 cm
- Weight = 6.65 kg
- Warranty = 2 years
- Removable Water Tank = 2 L

- Heat-Up Time = 25 seconds
- Clean System = Descaling Alert
- Capsule Container Capacity = 12 capsules
- Milk Jug Capacity = Max line - 240 ML

Premise

All the Nespresso Original machines are equipped with a 19-bar pressure pump, which provides the power needed to pierce the film of the capsule and release the coffee's 900 or so different aromas. The shape of the Nespresso capsule has been specially designed to ensure that the pressurized water flows evenly through the ground coffee during extraction. The temperature and flow time are also set to ensure that each precious aroma is expressed.

Creatista Plus

Nespresso Creatista Plus enables you to easily create an authentic top-quality Latte Art coffee at home, thanks to Nespresso system's convenience and coffee expertise combined with Breville advanced milk texturing technology.

Creatista Plus proposes 8 beverages: 3 black coffees (Ristretto, Espresso and Lungo), 4 milk-based recipes (Cappuccino, Cafe Latte, Latte Macchiato, Flat White) and milk froth, with a versatile level of settings (coffee volume, milk temperature and milk texture).

Creatista Pro

Let your artistic inspiration take you through an array of different milk recipes. Creatista Pro simultaneously brews the coffee and heats the milk. All you need is a spark of creativity when assembling the coffee and the milk to add the final touch to your latte art. And for those who prefer black coffee, let your intuition take you from Ristretto all the way to Americano, thanks to the hot water function. The creative process is also exquisitely simple.

Creatista Pro offers an even greater variety of coffees & recipes with the addition of the Americano & Cafe Latte. You may also create your own recipes and add them to the drinks menu in order to enjoy it again and again. It's high resolution touch screen makes the interactions with the machine very intuitive and easy, and it will guide you through the everyday use and maintenance of your machine. Finally, thanks to its 2L water tank, you will have to refill it even less often (1.5L on Creatista Plus).

The Creatista Pro can brew Ristretto, Espresso, Lungo, Americano, Latte Macchiato, Cappuccino, Flat White, Cafe Latte & Hot Milk. Additionally you can create your own recipes and add them to the drink menu so you can enjoy it again and again. Hot water function is also available.

Descaling

Creatista Plus

Descale when prompted on-screen. It takes approximately 15 minutes. Please note that the machine will stop you from use if the descale cycle has not been performed after 10 uses. A "lockout" count-down will appear to alert you of the number of uses remaining until usage will stop. Check out "how to descale" on the machine assistance page.

Creatista Pro

Descale when prompted on-screen. It takes approximately 15 minutes. Please note that the machine will stop you from use if the descale cycle has not been performed after 30 uses. A “lockout” count-down will appear to alert you of the number of uses remaining until usage will stop. To descale your machine go to the settings menu and select “Descale”. Follow the on screen instructions.

The screen will notify the consumer when a descaling is necessary. Please descale when prompted on-screen, as the machine will stop you from use if the descale cycle has not been performed after 30 uses. A “lockout” count-down will appear to alert you of the number of uses remaining until usage will stop.

Factory Reset Instructions

Creatista Plus

For the Nespresso Creatista Plus machine you will need to:
1. Select SETTINGS
2. Select RESET
3. Select FACTORY RESET
4. Select the validation icon to confirm
5. Select the cancel/cross icon to cancel
6. Machine will power off
7. On next use, you will need to refer to first use instructions.

Note:
- Doing a reset to factory settings, this will reset the water hardness level. You will be guided to reset it after the next use of machine.
- Factory settings are: Lungo 110 ml, Espresso 40 ml, Ristretto 25 ml

Creatista Pro

Open the settings menu, scroll down to find “Factory Reset” and follow the on screen instructions.

First Time Use Procedure

Creatista Plus

1. Fill the water tank with fresh potable water.
2. Place the water tank, insert the drip tray and the capsule container in position. For your safety, operate the machine only with drip tray and capsule container in position.
3. Plug he machine into the power outlet.
4. Turn the machine ON by pressing the START|CANCEL button. Heating up takes approximately 10 seconds.
5. Rotate the SELECT dial to set your language. Press SELECT to confirm.
6. Setting your water hardness, dip the Water Hardness Test Strip in and out the water tank. Wait 1 minute. Set the water hardness by rotating the SELECT dial according to the results on the Test Strip. Press SELECT to confirm,. For further information refer to page 26 of the machine manual.

7. Follow the on-screen prompts to rinse & prepare your machine for use.
8. Follow the Quick Start Tutorial.
9. To turn OFF your machine, press and hold the START/CANCEL dial for 2 seconds until machine is off.

Creatista Pro

1. Plug the machine into the power outlet.
2. Turn the machine ON by pressing the power button.
3. Tap to select your language.
4. Follow on-screen instructions for machine set up. First use cycle is to rinse the machine and prime the heating system.
5. Follow the on-screen Quick Start Guide. Water Hardness can be manually set or the default can be used. The setting can be adjusted in the menu.
6. To turn OFF your machine, press the Power button. Any drink recipe can be interrupted by turning the machine off.

Helpful Links

Name of Link	URL
Creatista Plus Machine Manual	https://www.nespresso.com/shared_res/manuals/creatista/BNE800_J520_CREATISTA_UM_EUR%20MEAC_D.pdf
Creatista Pro Machine Manual	https://www.nespresso.com/shared_res/manuals/creatista-pro/BNE900_CREATISTA_PRO_USC_IB_C20_LR.pdf
Machine Assistance Creatista Plus	https://www.nespresso.com/ca/en/machine-assistance#!/Creatista/troubleshooting
Machine Assistance Creatista Pro	https://www.nespresso.com/ca/en/machine-assistance#!/Creatista-Pro/troubleshooting
Creatista Plus Descaling Guide	https://www.nespresso.com/static/us/documents/Creatista.Creatista%20Plus%20Descaling%20Guide.pdf
Creatista Pro Descaling Guide	https://www.nespresso.com/static/us/documents/CreatistaPro%20DescalingGuide%20FINAL.pdf
Creatista Plus YouTube Playlist	https://youtube.com/playlist?list=PLQ2elUsAVWUwLWyGoUXH2qH8TQoNSPcHq&feature=shared
Creatista Pro YouTube Playlist	https://youtube.com/playlist?list=PLQ2elUsAVWUxQTk_QzTr9JIw4EI0jYJxq&si=0hNG3gX6ctUOVIN_

FAQS

- For optimal milk froth, use pasteurized whole or semi-skimmed milk at refrigerated temperature. It is recommended to use the milk jug provided with the machine for an optimized performance.
- The drip tray & milk jug are dishwasher-safe.

- There is no specific functionality to adjust coffee temperature on this machine. If coffee is not hot enough, we recommend to preheat the cup. Descale if necessary.

Creatista Plus

- To ensure the best hygienic conditions, it is highly recommended emptying and cleaning the capsule container every day. Check ‘how to clean - daily cleaning’ video on the machine assistance page. Additionally, we highly recommend that you perform the Milk System Cleaning Procedure monthly or when the display shows “Clean Steam Wand”. It takes approximately 10 minutes. Check ‘how to clean - monthly maintenance’ video on the machine assistance page.
- Turn the machine ON by pressing the START|CANCEL button. To turn OFF your machine, press and hold the START|CANCEL dial for 2 seconds until machine is off. NB: The machine turns OFF automatically. It minimizes power use when not making a drink (heater is not powered). The display dims after 2 mins of no use, after 10 mins of no use display turns off. Restart by pressing the START|CANCEL button.

Creatista Pro

- To ensure the best hygienic conditions, it is highly recommended emptying and cleaning the capsule container every day. You may also use the “Rinse Steam Wand” option from the settings menu. Additionally, we highly recommend that you perform the Milk System Cleaning Procedure monthly when the display shows “Clean Steam Wand”. It takes approximately 10 minutes. Go to settings, select “Clean Steam Wand” and follow the on screen instructions.
- Every beverage is customizable in at least 1 parameter:
  - Black coffees can be reprogrammed in volume to fit your taste.
  - Milk based recipes can be reprogrammed in coffee volume, milk temperature and froth volume.
- The machine can be switched on/off using a button. The machine also has an automatic shut off feature that kicks in after 10 minutes.

Colour Variations

Creatista Plus

Creatista

Machine Name	Machine Photo
Creatista Plus - Black	

Creatista

Machine Name	Machine Photo
Creatista Plus - Blue	

Creatista

Machine Name	Machine Photo
Creatista Plus - White	

Creatista

Machine Name	Machine Photo
Creatista Plus - Stainless Steel	

Creatista Pro

Creatista

Machine Name	Machine Photo
Creatista Pro - Black Truffle	

Creatista

Machine Name	Machine Photo
Creatista Pro - Stainless Steel	