Essenza Mini

Price

Price = 209.00
Bundle Price with Milk Frother = 279.00
=> Milk Frother: Aeroccino 3

Cup Sizes

Espresso	Lungo
40 ml Espresso	**110 ml** Lungo

Premise

Two Cup Sizes
- Two coffee cup sizes with automatic flow stop. Simply pop in your capsule, choose between Espresso and Lungo size, and it's ready at a touch of a button.
- All Original capsules can be made as Espresso or Lungo coffees.

Small in Size, for Big Coffee Moments
- Enjoy your coffee moment in the most convenient way, the Essenza Mini Black coffee machine is small, easy to use, and doesn't compromise on taste. It fits into the most modest of spaces, but is still bold on style and personality. If you like clean-cut lines, go for the rectangular shape with Essenza C. For a curvier style, try out the triangular one with Essenza D.

Specifications

- Dimensions (W x D x H)
  - Essenza Mini C = 8.4 x 33 x 20.4 cm
  - Essenza Mini D = 11 x 32.5 x 20.5 cm
- Weight: 2.3 kg
- Warranty: 1 year
- Removable Water Tank: 0.6 L
- Automatic Power Off: after 9 minutes of use

- Heat-Up Time: 25 sec
- Capsule Container Capacity: 5 - 6 capsules

First Time Use Procedure

1. Rinse the water tank before with potable water. Place a container.
2. To turn the machine ON, press either the Espresso or Lungo button. Blinking Lights: heating up (25 seconds). Steady Lights: ready.
3. Press the Lungo button to rinse the machine. Repeat 3 times.
4. To turn the machine off before automatic Auto Off mode, press both the Espresso and Lungo buttons simultaneously.

Factory Reset Instructions

1. Factory settings: Espresso cup: 40ml, Lungo cup: 110ml; Auto Off mode: 9 mins. With machine turned off, press and hold down the Lungo button for 5 seconds.
2. LEDS will blink fast 3 times to confirm machine has been reset to factory settings.
3. LEDs will then continue to blink normally, as heating up, until ready. Steady Lights: ready.

Helpful Links

Name of Link	URL
Machine Manual	https://www.nespresso.com/ecom/medias/sys_master/public/15139841933342/UM-NEW-LAYOUT-SAFETY-Z1-WEB-2020-02-25.pdf
Machine Maintenance Essenza Mini	https://www.nespresso.com/ca/en/machine-assistance#!/Essenza-Mini/troubleshooting
Descaling Video	https://youtu.be/5pikKfELrM8?feature=shared
First Use Video	https://youtu.be/_musG9RnGg4?feature=shared
Descaling Guide	https://www.nespresso.com/static/us/documents/Essenza%20Mini%20Descaling%20Guide.pdf

Colour Variations

Essenza Mini

Machine Name	Machine Photo
Essenza Mini C - Black	

Essenza Mini

Machine Name	Machine Photo
Essenza Mini D - Piano Black	