Vertuo Creatista

Price

Price = ~~1099.00~~ 999.00

Cup Sizes

Espresso	Double Espresso	Gran Lungo	Long Coffee	Alto	Carafe	Cappuccino	Latte Macchiato	Cold Brew	Caffe Latte	Flat White
40 ml Espresso	80 ml Double Espresso	150 ml Gran Lungo	230 ml Long Coffee	355 ml Alto	535 ml (Carafe)	Cappuccino	Latte Macchiato	Cold Brew	Caffè Latte	Flat White

Besides the cup sizes/recipes shown above, any other milk based beverage can also be made.

Premise

Versatility: From Espresso to Carafe — Smooth, full bodied coffee topped with a velvety layer of cream, for a perfect cup every time.

Automatic Steam Pipe for Milk Recipes — Create top-quality latte art on you cappuccino, flat white, caffe latte or latte macchiato with the automatic and expert steam wand.

Adjustable Milk Froth Settings — Endless coffee and milk recipes can be made with 3 milk temperature and texture levels.

With a wide range of coffee options made for different cup sizes, you can indulge in black coffee or create your own milk recipes. The integrated steam pipe lets you froth your milk, personalize your recipes, or try your hand at latte art.

CENTRIFUSION is the brewing technology used to gently and fully brew the following coffee sizes: Espresso, Double Espresso, Gran Lungo, Long Coffee, Alto, Carafe & Cold Brew Style.

Specifications

- Dimensions (W x D x H): 24.5 x 41.7 x 32.2 cm
- Weight: 7 kg
- Warranty: 2 years
- Removable Water Tank: 2 L
- Milk Jug Capacity: Max Line - 240 ML / Jug - 480 ML
- Connected Machines; Ensures software updates

- Automatic Power Off: after 2 minutes of non-use
- Heat-Up Time: 30 seconds (coffee) and 3 seconds (milk)
- Capsule Container Capacity: 10 small capsules / 6 large capsules

Factory Reset Instructions

Press and hold the Milk temperature button for 10 seconds. All lights will flash 5 times to indicate your machine has been reset to factory settings.

First Time Use Procedure

1. Place the 1 L container on top of the drip tray.
2. Press the coffee button three times within 2 seconds.
3. This process will take up to 7 minutes but can be stopped at any time by pushing the coffee button.
4. Fill the milk jug with portable water to the MAX line.
5. Lift up the steam wand and insert in milk jug.
6. Press and hold the Steam Button for 3 seconds.
7. Once the cycle is complete, remove the milk jug.
8. Wipe the steam wand with a clean damp cloth.
9. Empty and rinse the milk jug, drip tray and container.
10. WARNING: HOT. Do not touch steam wand.

Descaling

See User Manual or Tutorial video for detailed procedure. You can also use the Nespresso app if your machine is paired. Thanks to the step-by-step procedure, descaling your machine is super easy.

The descaling frequency depends on the machine usage and the water hardness, which varies based on how often coffee is consumed in the household and the water of that particular location. The general riles is every 3000 cups of coffee. The most reliable way to ensure it is ready to descale is through the descaling alert or by checking the status through the App.

The Descale Alert will blink orange when a descale cycle is needed. When a descale cycle must be completed to use the machine, the alert will illuminate solid orange. For full instructions on how to descale your machine, please refer to the User Manual online.

FAQS

- Power Rating of coffee machine: 120 volts
- Cable length from coffee machine to plug: 80 cm
- The cup support is adjustable and has 3 different heights available. It can also be removed. The drip tray can also be fully removed to accommodate a carafe or travel mugs.
- The milk jug and the removed steam wand tip can be washed in the dishwasher. We recommend placing these parts on the top shelf.
- The machine can be turned “OFF” at any time (when not operating) by holding the button for 3 seconds.

- It is possible to preselect a beverage during heat up time. You can press on the button while the machine is still heating up. The coffee will then flow automatically when the machine is ready.
- The heat of Vertuo Creatista cannot be regulated. The temperature varies for each blend and cannot be altered. If you would like a warmer coffee, it is recommended to preheat your cup by rinsing it in hot water to help maintain the temperature and mix the coffee with the crema once brewed. The temperature of the milk can be adjusted by choosing amongst the 2 different milk temperatures.
- The Original Nespresso capsules cannot be used in the Vertuo machine system. They interact with the systems in different ways. These are two separate lines that will appeal to different types of coffee lovers.

Helpful Links

Name of Link	URL
Machine Manual	https://www.nespresso.com/ecom/medias/sys_master/public/26943966445598/Vertuo-Creatista-User-Manual.pdf
Machine Assistance Vertuo Creatista	https://www.nespresso.com/ca/en/machine-assistance#!/Vertuo-Creatista/troubleshooting
YouTube Playlist	https://youtube.com/playlist?list=PLQ2eIUsAVWUzRodvoGTcHWsZq5mjf2I_w&feature=shared

Notes

- Easy cleaning due to the steam wand system
- Highly customizable in terms of making milk recipes
- An all-in-one to making coffee shop style milk recipes at home

Colour Variations

Vertuo Creatista

Machine Name	Machine Photo
Vertuo Creatista - Stainless Steel	

Vertuo Creatista

Machine Name	Machine Photo
Vertuo Creatista - Sea Salt	

Vertuo Creatista

Machine Name	Machine Photo
Vertuo Creatista - Black Truffle	