Vertuo Round Head

Price

Price = 279.00
Bundle Price with Milk Frother = 349.00
=> Milk Frother: Aeroccino 3

Cup Sizes

Espresso	Double Espresso	Gran Lungo	Long Coffee
40 ml Espresso	80 ml Double Espresso	150 ml Gran Lungo	230 ml Long Coffee

Specifications

- Dimensions = 21.1 x 30.2 x 30.2 cm
- Weight = 4.9kg
- Warranty = 1 year
- Removable Water Tank = 1.2 L
- Automatic Power Off = after 9 minutes of non-use
- Heat-Up Time = 15 - 20 sec
- Capsule Container Capacity = 13 capsules

Premise

Vertuo prepares freshly brewed Coffee and authentic espresso with cream at the touch of a button thanks to the revolutionary Centrifusion and code reading parametric extraction technologies.

Helpful Links

Vertuo Round Head

Name of Link	URL
Machine Manual	https://www.nespresso.com/shared_res/manuals/vertuoline/www_VertuoLine_Nespresso(EN_FR).pdf
Machine Assistance Vertuo Round Head	https://www.nespresso.com/ca/ca/machine-assistance#!/Vertuoline/troubleshooting
YouTube Playlist	https://youtube.com/playlist?list=PLQ2eIUsAVWUyFnvlmuL-D0F60aAGaXl9Q&feature=shared
Descaling Guide	https://www.google.ca/url?sa=t&rct=j&q=&esrc=s&source=web&cd=&cad=rja&uact=8&ved=2ahUKEwj40f7wlbWCAxXJITQIHeJDDDoQFnoECBkQAQ&url=https://www.nespresso.com/static/us/documents/VertuoLine%20Descaling%20Guide.pdf&usg=AOvVaw3GVxAg4oPk8v09ZL0GpZ7-&opi=89978449
Factory Reset Instructions	https://www.mymorningespresso.com/how-to-reset-nespresso-machine/?expand_article=1#5-vertuo

Factory Reset Instructions

1. Open the machine head and let the used capsule be ejected.
2. Close the head. Leave the lever in “UNLOCKED’ position.
3. Push the button 5 times within 3 seconds. The button will blink slowly 5 times to confirm reset is done.

Descaling

Descaling Alert = The button’s light alternatively blinking 3 times and then steady on.

- Descaling needed: Machine can be operated when alert appears only a few times after this alert before descaling becomes necessary.
- Refer to Descaling Guide on how to perform the descaling process.

First Time Use Procedure

1. Rinse and clean the water tank before filling it only with fresh drinking water. Put the water tank in place.
2. Ensure the capsule container and the cup support (if necessary for the selected cup size) are in place. For your safety, operate the machine only with cup and capsule container in position.
3. Plug the machine into the outlet.
4. Turn the machine “ON” by pushing the button. The button will gradually illuminate as the machine heats up in approximately 15 seconds.
5. Steady light indicates the machine is ready.
6. Place a cup of at least 0.5 L under the coffee outlet.

7. Close the machine if open and lock the machine by turning the lever left to the lock symbol on the machine head.
8. Press the button 3 times within 2 seconds to start cleaning and let the cleaning procedure complete automatically. It will take less than 2 minutes before a flow comes out. The procedure consists of 3 cycles of pumping water in, internal cleaning and water flowing from the outlet to complete.
9. This operation may take up to 5 minutes. The procedure can be stopped at any time by pushing the button. The button will go to steady light. In case you want to resume the cleaning process, push the button again, To brew a coffee, insert a capsule, then close, lock the machine by turning the lever left and push the button.

Notes

- Given the introduction of Vertuo Pop+ and the existence of Vertuo Next, this machine model can be considered a mid-tier despite it being one of the first renditions of the Vertuoline machines.
- This is an excellent machine model that is given to employees upon joining the Nespresso organization.

Colour Variations

Machine Name	Machine Photo
Vertuo Round Head - Black	

Vertuo Round Head

Machine Name	Machine Photo
Vertuo Round Head - Chrome	

Vertuo Round Head

Machine Name	Machine Photo
Vertuo Round Head - Matte Black	