



Packing List


1. Acrylic Plates











The acrylic plates are fragile, so please be careful when assembling them in case of breaking.

The acrylic plate is covered with a layer of protective film. You need to remove it first.



Some holes in the acrylic may have residues, so you need to clean them before the use.

2. Machinery Parts

M2	M3	M3	M1.4*6	M2*14
Nut	Nut	Lock	Self-Tapping	Screw
2		Nut	Screw	
×11	×10	×3	×2	×7
M2*10	M2*5	M2.5*7	M3*8	M3*12
Screw	Screw	Screw	Screw	Screw
×4	×4	×5	×24	×5
×4	×4	×3	×24	× 5
M3*18	M3*10	M2*11	M3*8	M3*15
Screw	Countersunk	Copper	Copper	Nylon
	Head	Standoff	Standoff	Standoff
	Screw			
×1	×9	×2	×1	×4
		Constitute Dises Constitution		
M3*30	M3*40	Sucking Disc Component		
Nylon	Nylon			
Standoff	Standoff			
×5	×2			
		Cap Nut Sucking Disc ×4 ×4		



Square Bearing Turntable





×1






3. Electronic Parts





4. Tools



5. The following parts need to be purchased by yourself:



