

Notification and caring

- 1. It is normal battery and charger is heat(60℃) during charging.
- 2. No water in the connector when charging, or will short circuit.
- 3. Use charger and battery provided by factory only, or may damage charger and battery.

Playing notification

- 1. Make sure your car is connecting correctly before playing.
- 2. Donot play in the street, road, slope or drain.
- 3. Donot play on the smooth place, like marble or floor tile.
- 4. Donot change forward/backward swithc during playing. Donot allow children stand on the seat.
- 5. Donot change car line or add any other thing.
- 6. Donot play car in the rain or water, keep car away from water and fire, or damage the car line.
- 7. Stop car when meet obstacle, move it first.
- 8. Donot paly indoor, or damage furniture or children.
- 9. When power low, light and music will not work, please recharge quickly.
- 10. Only one rider playing, no overload, max capacity is 20kg.
- 11. Turn off the power if you are not playing. Please loosen battery line if you don't use your car for quite a long time.

Caring

- 1. For safe driving, please often check and maintain the car.
- 2. Before assembling, please make sure no missing parts. if missed, please connect factory.
- 3. Often check whether screw loose or parts damage.
- 4. Make sure parts are ok, if not, please connect factory.
- 5. Often clean the car carefully. Donot use wet cloth to wash.
- 6. When dismounting, please read guide book carefully, or will damage part.
- 7. Often check charger, car line, plug, appearane and other parts. if broken, please replace and repair.

In order to show how to operate the car and the struction of product we use picture to guide you. Maybe what you bought is different from the picture, please see the real one.

In orider to Improve our quality, we will change the appearance and struction without notification, please understand.

Please read the operating instructions carefully before using. Assembly it correctly or it will hurt your children. Please keep guide book properly.

Basic Information

Name	specification
battery	one motor(6V4.5AH)
motor	one motor(6V)
suitable age	24-72 months
load capacity	30kg
product size	770*410*450mm
Package Size	660*255*420mm
speed	3-4 km/h
playing time	charging 8-12hours, playing 1-2hours
charger	output: DC6V
fuse	restorable: 5A

Warning:

To reduce the risk of injury, adult supervision is required, never use in roadways, near cars, on or near steep inclines or steps, swimming pools or other bodies of water, always wear shoes, and never allow more than one rider.

Adult Assembly Required.

Take care during unpacking and assembly as product has small parts.

Sealed lead-acid battery must be recycled or disposed of properly.

Batteries are to be inserted with the correct polarity.

Toy must be assem bled by adult before use


Retain all noted instructions for future reference.

To reduce the risk of injury, adult supervision is required, never use in roadways, near cars, on or near steep inclines or steps, swimming pools or other bodies of water, always wear shoes, and never allow more than one rider.


Assembly by an adult.

Not to be used for traffic.

How to use and maintain




- 8. Battery charge: please charge tricycle when battery is low. Charging hole is on the left side of the right wheel. Connecting chargine hole, then charge. (Notice: cannot play when charging, charging only under adult supervision)



If the current is too large, the power will be cut off automatically and will be restored within 5-10 seconds.

problem	cause	solution
car cannot move	1. voltage to low 2. fuse fired 3. switch assembled uncorrect 4. battery line loose 5. battery broken 6. battery damage 7. motor broken	1. recharge 2. replace new fuse 3. reassemble according to guide book 4. reconnect 5. replace new battery 6. factory repair 7. factory repair
cannot charge	1. battery line loose 2. charger no electricity 3. charger broken	1. reconnect 2. plug-in 3. replace new charger
short time for playing	1. battery not full 2. battery old	1. recharge 2. replace new battery
small noise and heat when charging	chemical reaction	normal

How to assemble



Instructions for use and installation X300

Model#

M3

Product should be assembled by adults. Picture is for your reference only.

IS 15644:2006

Customer Care Contact: MDK Enterprises C-148 Hosiery Complex, Phase-2 Extn. NOIDA-201305, Uttar Pradesh, India Email: info@mekashi.toys ; mail@masoomtoys.in Phone: +91 9810344926 WWW.MEKASHI.TOYS

How to maintain, warning and charging notification

speed slow	1. battery old 2. no power 3. overload 4. rough road	1. replace new battery 2. recharge 3. normal weight 20kg 4. smooth road
loud motor noise	gear broken	factory repair
car shaking	1. motor line loose 2. motor has dead point	1. reconnect 2. factory repair
car not move	battery line loose	reconnect
car stops	spare parts broken	factory repair

Warning:

Safe driving for your children, please read this carefully.

- 1. Assembling should be done by adults, children stay away from small spare parts.
- 2. Adult supervision is needed, do not leave children alone. Away from fire.
- 3. No standing on the pedal switch or on the car.
- 4. Charging only for adult. Charge first before using.
- 5. Keep children away from plastic bag. Suffocation danger.
- 6. Only use spare parts provided by factory.
- 7. Charger is not a toy.
- 8. Max capacity is 20kg, do not overload.
- 9. One car one charger.
- 10. Donot play car when charging.
- 11. Suitable age: 24-72 months.
- 12. This toys contains battery that are non-replaceable
- 13. Charger was used with the toy should be regularly examined for damage to the cord, plug, enclosure and other parts, and that, in the event of such damage, the toys must not be used with this transformer until the damage has been repaired.

Charging notification

- 1. Charging 18 hours for the first time, or will damage the battery.
- 2. Connecting battery and charger first, then plug into power.
- 3. After laying one hour, please charge. Normally charge for 8-12 hours, not over 20 hours.

Part Name

1 Motorcycle body	2 Front axle / Rear axle / Foot mount	3 Handlebars
4 Front wheel	5 Seat	6 Fender
7 Rear wheel	8 The front	9 Charger
10 Motor	11 Instruction	12 Foot pedals
13 Front wheel fork	14 License plate	15 Accessory Package