## Exp8

```
int sensorValue = 0;
int outputValue = 0;
void setup() {
 pinMode(A0, INPUT);
 pinMode(9, OUTPUT);
 Serial.begin(9600);
}
void loop() {
 sensorValue = analogRead(A0);
 outputValue = map(sensorValue,0,1023, 0, 255);
 analogWrite(9,outputValue);
 Serial.print("sensor = ");
 Serial.print(sensorValue);
 Serial.println("output = ");
 Serial.print(outputValue);
 delay(2);
}
```