### Lesson EPSI-05-01 Download pdf file here

# Course EPSI: Essential Principles of Signal Integrity

With Eric Bogatin,
Signal Integrity Evangelist, Teledyne LeCroy Front Range Signal Integrity Lab
Dean, Teledyne LeCroy Signal Integrity Academy
Adjunct Professor, University of Colorado, Boulder, ECEE

■EPSI-05-01: recorded live, Dec 1, 2013

- Ground bounce and inductance
- Download the pdf copy of the slides here



**Teledyne LeCroy Signal Integrity Academy** 

7

### Lesson EPSI-05-10 Recap of Signal Integrity Principles

# Course EPSI: Essential Principles of Signal Integrity

With Eric Bogatin,
Signal Integrity Evangelist, Teledyne LeCroy Front Range Signal Integrity Lab
Dean, Teledyne LeCroy Signal Integrity Academy
Adjunct Professor, University of Colorado, Boulder, ECEE

- ■EPSI-05-10: recorded live, Dec 1, 2013
  - Recap of the six families of signal integrity
  - The design methodology to eliminate signal integrity problems
  - The essential principles
  - The real root cause of ground bounce in packages



Teledyne LeCroy Signal Integrity Academy

# Day 2

- Day 1
  - EPSI 1 Transmission Lines
  - EPSI 2 Differential Pairs and Lossy Lines
  - Lunch
  - EPSI 3 Reflections and Terminations
  - EPSI 4 Routing Topologies and Discontinuities
- Day 2
  - EPSI 5 Eliminating Ground Bounce
  - EPSI 6 Navigating Return Path Discontinuities
  - Lunch
  - EPSI 7 NEXT and FEXT Features
  - EPSI 8 PDN and EMI Design



**Teledyne LeCroy Signal Integrity Academy** 

3

# RPD: Ground bounce happens anywhere Switching noise happens near driver Root cause: return path discontinuities (RPD) TELEDYNE LECROY Everywhenyoutcox Teledyne LeCroy Signal Integrity Academy 4

### Lesson EPSI-05-20 Intro to ground bounce

# Course EPSI: Essential Principles of Signal Integrity

With Eric Bogatin,


Signal Integrity Evangelist, Teledyne LeCroy Front Range Signal Integrity Lab Dean, Teledyne LeCroy Signal Integrity Academy Adjunct Professor, University of Colorado, Boulder, ECEE

### ■EPSI-05-20: recorded live, Dec 1, 2013


- How not to think about return current
- When does return current come out the return path
- Two important properties of return current
- Where return current flows in a plane



**Teledyne LeCroy Signal Integrity Academy** 



Essential Principle # 4: Current Propagates as a signal-return path loop wave front with a direction of propagation and a direction of circulation



The current loop has two directions associated with it:

- 1. A direction of propagation
- 2. A direction of circulation

## They are independent!




**Teledyne LeCroy Signal Integrity Academy** 

7

# Where Does the Return Current Travel in the Return Plane?

DC




Current takes the path of lowest impedance

$$Z = R + i\omega L$$

Smaller the loop area, lower the inductance

@ > 1 MHz, ωL > R, path dominated by inductance

f > ~ 1 MHz



Teledyne LeCroy Signal Integrity Academy

### Lesson EPSI-05-30 Root cause of gnd bounce

# Course EPSI: Essential Principles of Signal Integrity

With Eric Bogatin,


Signal Integrity Evangelist, Teledyne LeCroy Front Range Signal Integrity Lab Dean, Teledyne LeCroy Signal Integrity Academy Adjunct Professor, University of Colorado, Boulder, ECEE


### ■EPSI-05-30: recorded live, Dec 1, 2013


- Estimating the width of the return current
- Inductance and a finite return path
- Near and far end cross talk and finite return path
- The two essential ingredients for ground bounce



**Teledyne LeCroy Signal Integrity Academy** 







# Lesson EPSI-05-40 inductance and reducing ground bounce

# Course EPSI: Essential Principles of Signal Integrity

With Eric Bogatin,

Signal Integrity Evangelist, Teledyne LeCroy Front Range Signal Integrity Lab Dean, Teledyne LeCroy Signal Integrity Academy Adjunct Professor, University of Colorado, Boulder, ECEE

### ■EPSI-05-40: recorded live, Dec 1, 2013

- How to reduce ground bounce based on its root cause
- Everything you think you know about inductance is probably wrong
- What really is inductance
- The three most important design features to reduce loop inductance



**Teledyne LeCroy Signal Integrity Academy** 

40

# What's Inductance? | Section Account of Theory | Court of the growth Eq. 4-50 as a country write Eq. 4-50 as a country of the magnetic field as a linear medium. This is the magnetic field as a formation of the growth of the magnetic field as a formation of the growth of the magnetic field as a formation of the growth of the magnetic field as a formation of the growth of the magnetic field as a formation of the growth of the magnetic field as a formation of the growth of the magnetic field as a formation of the growth of the magnetic field as a formation of the magnetic field as a formation of the magnetic field as a formation of the growth of the magnetic field as a formation of the magnetic field as a f

# Essential Principle #6: Inductance is fundamentally about how efficient a conductor is in generating rings of magnetic field lines.

Definition of Inductance: Inductance is the number of rings of magnetic field lines around a conductor, per amp of current through it

Units: Webers/amp = Henry

nH more common

Inductance is a measure of the efficiency of a conductor to create rings of magnetic field lines at the cost of current

- high inductance: lots of field lines per amp of current

3 ways of engineering lower inductance:

- 1. Wider conductors: more current spreads out, fewer field lines/amp
- Shorter conductors: shorter the length, fewer field lines/amp
- 3. Bring return current closer to signal current: mutual field lines cancel out self field lines

Important consequence: Planes have the LOWEST total inductance- <u>anything</u> else will have higher inductance



**Teledyne LeCroy Signal Integrity Academy** 

15

# Lesson EPSI-05-50 the total inductance of the return path


# Course EPSI: Essential Principles of Signal Integrity


With Eric Bogatin,
Signal Integrity Evangelist, Teledyne LeCroy Front Range Signal Integrity Lab
Dean, Teledyne LeCroy Signal Integrity Academy
Adjunct Professor, University of Colorado, Boulder, ECEE

- ■EPSI-05-50: recorded live, Dec 1, 2013
  - Why inductance is so important: induced voltage and changing current
  - Inductively coupled cross talk
  - The total inductance of the return path: self and mutual inductance
  - Ground bounce and the inductance of the return path



Teledyne LeCroy Signal Integrity Academy





# Lesson EPSI-05-60 estimating gnd bounce

# Course EPSI: Essential Principles of Signal Integrity

With Eric Bogatin,

Signal Integrity Evangelist, Teledyne LeCroy Front Range Signal Integrity Lab Dean, Teledyne LeCroy Signal Integrity Academy Adjunct Professor, University of Colorado, Boulder, ECEE

#### ■EPSI-05-60: recorded live, Dec 1, 2013

- Total inductance of the return path
- A simple rule of thumb for the total inductance of the return path
- Estimating ground bounce
- Ground bounce in packages and connectors



**Teledyne LeCroy Signal Integrity Academy** 

19

#### Calculating Total Inductance of the Return Path is Hard! "if all you have is a Signal path hammer, everything looks like a nail" Return path Total inductance of return path Total Inductance per length, nH/inch 20 18 16 14 12 10 s = 30 mils s = 20 mils s = 10 mils 8-6-For w = s15 25 30 45 50 L<sub>total</sub> ~ 10 nH/inch x Len Trace Width, mils TELEDYNE LECROY **Teledyne LeCroy Signal Integrity Academy**

### **Estimating Ground Bounce Noise**


$$V_{gnd} = L_{total} n \frac{dI}{dt}$$
 
$$\frac{dI}{dt} = \frac{V_{sig}}{Z_o RT}$$

$$\frac{V_{gnd}}{V_{sig}} = \frac{L_{total}n}{Z_0RT} = 2\% \times \frac{L_{total}[nH] \times n}{RT[nsec]}$$



 $L_{total}[nH]$  = total inductance of return path n = number of simultaneous signals switching RT[nsec] = 10-90 rise time of signal current

L<sub>total</sub> ~ 10 nH/inch x Len





 $L_{total} \sim 5 \text{ nH}$ 

Example: n = 3, RT = 0.5 nsec gb noise ~ 2% x 2 x 3 / 0.5 = 24% Example: n = 2, RT = 1 nsec gb noise ~ 2% x 5 x 2 / 1 = 20%

Do you wonder why ground bounce is so common in packages and connectors?



**Teledyne LeCroy Signal Integrity Academy** 

2

## Lesson EPSI-05-70 measuring ground bounce


# Course EPSI: Essential Principles of Signal Integrity


With Eric Bogatin,
Signal Integrity Evangelist, Teledyne LeCroy Front Range Signal Integrity Lab
Dean, Teledyne LeCroy Signal Integrity Academy
Adjunct Professor, University of Colorado, Boulder, ECEE


- ■EPSI-05-70: recorded live, Dec 1, 2013
  - Example of ground bounce in a package
  - Return path in the package
  - Ground bounce signature in a circuit
  - Reflections and the impact on ground bounce



Teledyne LeCroy Signal Integrity Academy







# Lesson EPSI-05-80 simulating gnd bounce


# Course EPSI: Essential Principles of Signal Integrity


With Eric Bogatin,
Signal Integrity Evangelist, Teledyne LeCroy Front Range Signal Integrity Lab
Dean, Teledyne LeCroy Signal Integrity Academy
Adjunct Professor, University of Colorado, Boulder, ECEE


- ■EPSI-05-80: recorded live, Dec 1, 2013
  - Translating real features into a simple simulation
  - Impact of source termination on transient current
  - Comparing the simulated ground bounce voltage and measured
  - Using the simulation to explore design features to reduce ground bounce



**Teledyne LeCroy Signal Integrity Academy** 







# Design Guidelines to Reduce Ground Bounce When Due to Constricted RPD

$$V_{gnd} = L_{total} n \frac{dI_{return current}}{dt}$$

- L<sub>total</sub>: Reduce total inductance of return conductors
  - Short return conductors
  - Wide return conductors
  - Signals close to returns
  - For power/gnd paths: use planes, with thin dielectric
- n: Reduce number of switching signals sharing same return path
  - Don't share return paths- each signal has its own return path
- dl, I: Reduce the return currents that overlap
  - Stagger I/O switching
  - Use source series termination series resistor (higher R, tradeoff noise/rise time)
  - Use differential signals
- dt: increase the rise time of the signal
  - Always use as long a rise time as possible consistent with timing budget
  - Slew rate control



**Teledyne LeCroy Signal Integrity Academy** 

