Lesson AGCD-03-01 Download the pdf slides here

Course AGCD: Advanced Gigabit Channel Design

With Eric Bogatin,

Signal Integrity Evangelist, Teledyne LeCroy Front Range Signal Integrity Lab Dean, Teledyne LeCroy Signal Integrity Academy Adjunct Professor, University of Colorado, Boulder, ECEE

AGCD-03-01: recorded live, Dec 1, 2013

Download a pdf copy of the slides by clicking on the link on this page



Teledyne LeCroy Signal Integrity Academy

ā

Lesson AGCD-03-10 How lossy lines collapse the eye vertically

Course AGCD: Advanced Gigabit Channel Design

With Eric Bogatin,
Signal Integrity Evangelist, Teledyne LeCroy Front Range Signal Integrity Lab
Dean, Teledyne LeCroy Signal Integrity Academy
Adjunct Professor, University of Colorado, Boulder, ECEE

- AGCD-03-10: recorded live, Dec 1, 2013
 - Why short rise time signals have no ISI
 - How to think of the origin of Inter Symbol Interference
 - Rise time degradation when passing through real interconnects
 - How increased rise time creates vertical collapse of the eye




Teledyne LeCroy Signal Integrity Academy


AGCD: A 2-Day Workshop

- Day 1
 - ✓ AGCD 1 Opening eyes
 - ✓ AGCD 2 Differential pairs and routing
 - ✓ Lunch
 - ✓ AGCD 3 Lossy Lines and ISI
 - ✓ AGCD 4 Channel to channel cross talk
- Day 2
 - ✓ AGCD 5 Mode conversion
 - ✓ AGCD 6 Discontinuities
 - ✓ Lunch
 - ✓ AGCD 7 Transparent Via Design
 - ✓ AGCD 8 Practical consideration

TELEDYNE LECROY

Teledyne LeCroy Signal Integrity Academy





Lesson AGCD-03-20 ISI and data dependent jitter


Course AGCD: Advanced Gigabit Channel Design


With Eric Bogatin,
Signal Integrity Evangelist, Teledyne LeCroy Front Range Signal Integrity Lab
Dean, Teledyne LeCroy Signal Integrity Academy
Adjunct Professor, University of Colorado, Boulder, ECEE


- AGCD-03-20: recorded live, Dec 1, 2013
 - How increased rise time signals create jitter
 - ISI and deterministic jitter
 - Describing the losses in a transmission line in terms of the attenuation per length
 - Quick review of the dB as related to insertion loss and attenuation




Teledyne LeCroy Signal Integrity Academy









Quick Review of the dB

$$0 dB = 1$$

-20 dB is:

$$\frac{V_{\text{output}}}{V_{\text{input}}} = 10^{\frac{A_{\text{dB}}}{20}}$$

$$A_{\text{dB}} = 20 \text{ x log} \left(\frac{V_{\text{output}}}{V_{\text{input}}} \right) \text{dB}$$

-40 dB

$$\frac{V_{\text{output}}}{V_{\text{input}}} = 10^{\frac{-20}{20}} = 0.1 = 10\%$$

<u>value in dE</u>
0 dB
-1 dB
-2 dB
-3 dB
-6 dB
-10 dB
-20 dB
-26 dB
-30 dB

-40 dB is:
$$\frac{V_{output}}{V_{input}} = 10^{\frac{-40}{20}} = 0.01 = 1\%$$

-10 dB is:

$$\frac{V_{\text{output}}}{V_{\text{input}}} = 10^{\frac{-10}{20}} = \frac{1}{\sqrt{10}} \sim 30\%$$



1%

Teledyne LeCroy Signal Integrity Academy

11

Lesson AGCD-03-30 How much attenuation is too much?

Course AGCD: Advanced Gigabit Channel Design

With Eric Bogatin,

Signal Integrity Evangelist, Teledyne LeCroy Front Range Signal Integrity Lab Dean, Teledyne LeCroy Signal Integrity Academy Adjunct Professor, University of Colorado, Boulder, ECEE

- AGCD-03-30: recorded live, Dec 1, 2013
 - The attenuation in real interconnects
 - The connection between frequency dependent attenuation and rise time
 - Data rate, attenuation and collapse of the eye
 - The maximum data rate and allowed attenuation for an acceptable eye



Teledyne LeCroy Signal Integrity Academy

13

Frequency Domain and Time Domain Responses of the Channel What is the connection between attenuation at Nyquist and the eye diagram? (36 inches, FR4, 4 mil wide line) FOM ~ 34 dB/36 inch/10 GHz = ~ 0.1 dB/inch/GHz Step response

What will the eye look like if the UI is 1 nsec, 0.5 nsec, 0.1 nsec?

Teledyne LeCroy Signal Integrity Academy

TELEDYNE LECROY

Attenuation at Nyquist and Eye Diagram What is the connection between Atten @Nyquist: attenuation at Nyquist and the eye diagram? 2 Gbps -4 dB (little impact from losses) Define xx dB-Bandwidth as the highest frequency at which the attenuation is less than xx dB What BW is required for eye opening? 4 Gbps -8 dB (highest data rate without equalization) 7 Gbps -12 dB (eye barely open) 9 Gbps -16 dB . (eye completely closedcan be opened with CTLE) Teledyne LeCroy Signal Integrity Academy

Lesson AGCD-03-40 Equalization and limits to attenuation

Course AGCD: Advanced Gigabit Channel Design


With Eric Bogatin,

Signal Integrity Evangelist, Teledyne LeCroy Front Range Signal Integrity Lab Dean, Teledyne LeCroy Signal Integrity Academy Adjunct Professor, University of Colorado, Boulder, ECEE

- AGCD-03-40: recorded live, Dec 1, 2013
 - When the attenuation closes the eye
 - Using CTLE equalization to open a closed eye
 - 10Gbase spec for maximum attenuation at the Nyquist
 - Estimating a channel's maximum data rate from the insertion loss curve



Teledyne LeCroy Signal Integrity Academy




What if Attenuation @ Nyquist is > |-8| dB?

- Bit error ratio (BER) maybe too high
- Must use equalization to recover data:
 - CTLE: continuous time linear equalizer
 - FFE: feed forward equalization
 - DFE: decision feedback equalization
- Just CTLE may give acceptable eye when |S21| < |-15| dB
- Very good equalization may give acceptable eye when |S21| < |-25| dB



Teledyne LeCroy Signal Integrity Academy



Lesson AGCD-03-50 Engineering a lower attenuation

Course AGCD: **Advanced Gigabit Channel Design**

With Eric Bogatin,

Signal Integrity Evangelist, Teledyne LeCroy Front Range Signal Integrity Lab Dean, Teledyne LeCroy Signal Integrity Academy Adjunct Professor, University of Colorado, Boulder, ECEE

- AGCD-03-50: recorded live, Dec 1, 2013
 - Four ways of reducing the attenuation in a channel
 - Estimating attenuation from conductor and dielectric losses
 - Important figure of merit for dielectric loss
 - Typical values of attenuation in dB/in/GHz for common laminates



Teledyne LeCroy Signal Integrity Academy

19

How do we Engineer Interconnects to Have Insertion loss below ~ -25 dB?

- Shortest interconnects practical
- Minimize conductor loss
 - Engineer widest line width balanced with required interconnect density
 - Loose coupling
 - Lowest impedance practical
 - Lowest Dk practical

 - Thickest dielectric layers practical Conductor thickness > ½ oz. copper not much impact
 - Use smoother copper
- Minimize dielectric loss (no design features affect dielectric loss)
 - Lowest dissipation factor laminate practical
 - Use lower loss laminate on selected layers for lowest cost
- Keep surface traces (microstrip) short
 - Humidity sensitivity
 - Higher loss from surface treatment, rougher copper
 - Possible high far end cross talk



Teledyne LeCroy Signal Integrity Academy

Estimating Attenuation (a first order approximation)

atten[dB/in] = 4.34 x
$$\left(\frac{R_{len}[Ohms/in]}{Z_0[Ohms]} + G_L[Siemens/in] \times Z_0[Ohms]\right)$$

Conductor loss

Dielectric loss

$$G_{L} = 2\pi f \times G_{0} \times Dk \times Df = 2\pi f \times G_{L} \times Df \qquad Z_{0} = \frac{\sqrt{Dk}}{c C_{Len}}$$
 atten[dB/in] = -4.34 x \left(2\pi f C_{Len} Df \times \frac{\sqrt{Dk}}{cC_{Len}} \right) = -\frac{4.34 \times 2\pi}{11.8 \text{inch/nsec}} \times f \times Df \times \sqrt{Dk} \]
$$= -2.3 \times f \times Df \times \sqrt{Dk}$$

Attenuation from dielectric loss:

- only depends on the materials, NOT design
- scales linearly with frequency
- is dominated by dissipation factor of material

For FR4:

- simple figure of merit (FOM): dB/in/GHz = 2.3 x Df x sqrt(Dk) = 0.1 dB/inch/GHz

TELEDYNE LECROY

Teledyne LeCroy Signal Integrity Academy

24

Attenuation from Dielectric: Figure of Merit

atten per length[dB / inch] = 2.3 x f x Df x \sqrt{Dk} dB / inch @ ~ 1 GHz

<u>Material</u>	<u>Dk</u>	<u>Df</u>	atten, dB/inch/GHz
Park Nelco N4000-6	4.3	0.02	0.1
Isola 370HR	4.4	0.016	0.077
GETEK	3.5-4.4	0.008- 0.01	0.046
N4000-13SI	3.4	0.01	0.042
Isola FR408HR	3.7	0.009	0.04
Park-Nelco N4000-13EP	3.6	0.008	0.035
Rogers RO4350	3.6	0.004	0.017
 GoreSpeedBoard 	2.6	0.004	0.015
 Panasonic Megtron 6 	3.7	0.002	0.009

Typical Vendors: Isola, Taconics, Rogers, Park-Nelco, Panasonic, Gore



Teledyne LeCroy Signal Integrity Academy

Lesson AGCD-03-60 What are your laminate's properties?

Course AGCD: Advanced Gigabit Channel Design

With Eric Bogatin,

Signal Integrity Evangelist, Teledyne LeCroy Front Range Signal Integrity Lab Dean, Teledyne LeCroy Signal Integrity Academy Adjunct Professor, University of Colorado, Boulder, ECEE

- •AGCD-03-60: recorded live, Dec 1, 2013
 - Typical variation in the Dk and Df of "FR4"
 - Why what you ask for may not be what you get
 - The attenuation in microstrip compared with stripline
 - Humidity sensitivity to Df and dielectric losses





Teledyne LeCroy Signal Integrity Academy

23

What is the Dk, Df of Your Laminate?

Measured Dk, Df of different "FR4" samples from 10 mil wide microstrips (different suppliers)







From: UMR Rolla MS&T, MS Thesis work of Abhilash Rajagopal, 2007

Depends also on temperature and humidity during measurement

TELEDYNE LECROY

Teledyne LeCroy Signal Integrity Academy





Lesson AGCD-03-70 Attenuation from conductor loss

Course AGCD: Advanced Gigabit Channel Design

With Eric Bogatin,

Signal Integrity Evangelist, Teledyne LeCroy Front Range Signal Integrity Lab Dean, Teledyne LeCroy Signal Integrity Academy Adjunct Professor, University of Colorado, Boulder, ECEE

- •AGCD-03-70: recorded live, Dec 1, 2013
 - The origin of frequency dependent resistance
 - Estimating the conductor resistance
 - Estimating the attenuation from conductor resistance
 - Impact from surface roughness increasing resistance




Teledyne LeCroy Signal Integrity Academy

Skin Depth Limited Current Distributions: Smooth Copper

$$\delta = \sqrt{\frac{1}{\sigma\pi\mu_0\mu f}} = 2.1\mu\sqrt{\frac{1}{f}} \quad \text{f in GHz}$$

@ 1 GHz, skin depth = 2 u



Ansoft SI 2D

- Properties of series resistance:
 - Above ~ 10 MHz, for 1 oz copper, current is skin depth limited
 - R will increase ~ sqrt(freq)
- All high end 2D field solvers will calculate the resistive and dielectric loss over frequency
 - Polar
 - Mentor Graphics HyperLynx
 - Agilent ADS
 - HFSS, CST, ...


Estimating conductor loss:

- 1. Smooth copper
- 2. Skin depth
- 3. Return current loss
- 4. Roughness

TELEDYNE LECROY Everywhereyoulook*

Teledyne LeCroy Signal Integrity Academy

Frequency Dependent Resistance



$$R = \rho \frac{\text{Len}}{t \times w} \rightarrow = \rho \frac{\text{Len}}{2 \times \delta \times w}$$

Assuming current is on both surfaces

At DC: For 1 oz copper @ R_{sq} = 0.5 mOhms/sq

5 mil wide line = 200 squares

 $R_{DC} = 0.5 \text{ mOhms x } 200 \text{ sq} = 0.1 \text{ ohms/in}$

$$R_{\text{Len}} = \frac{R}{\text{Len}} = \frac{\rho}{2 \text{ x } \delta \text{ x w}} = \frac{1.8 \text{x} 10^{-2} \Omega - \mu}{4.2 \mu \sqrt{\frac{1}{f}} \text{ x w}} = \frac{4.3 \Omega}{\text{w}} \sqrt{f}$$

 R_{Len} in Ohms/inch w in mils f in GHz

Return current contributes ~ 20% additional series resistance

$$R_{\text{Len}} \left[\text{Ohms / in} \right] \sim \frac{5 \Omega}{\text{w[mils]}} \sqrt{\text{f[GHz]}}$$

TELEDYNE LECROY

Everywherevoulook*


Teledyne LeCroy Signal Integrity Academy

29

Impact from Copper Surface Roughness: Can increase attenuation by > 2x HTE(Standard) Super-HTE Currently no good analytical predictions of measured copper surface texture and resulting attenuation- MUST rely on measurement characterization Measured Insertion Loss for Different Copper Foils Laminated to Rogers Ultralam 3850 (an LCP) Increasing surface Note: very rough surfaces Rolled foil 0.4u RM have atten ~ f, smooth ED 0.3u RMS 0.5u RMS ED not sqr(f) 0.8 u RMS ED 2.5u RMS ED Courtesy of John Andresakis Source: Rogers Corporation OAK-MITSUI TECHNOLOGIES 🤶 Teledyne LeCroy Signal Integrity Academy

A "Hidden Variable" to Real World Performance

- Identical boards from different suppliers
- Very different insertion loss: 2x difference- why?



Attenuation from Conductor

Includes:

- skin depth in smooth copper
- current on both surfaces
- return current in plane

$$atten \left[dB \, / \, in \right] = 4.34 \, x \, \frac{R_{len} \left[Ohms \, / \, in \right]}{Z_{_0} \left[Ohms \right]} = \frac{22 \left[Ohms \, / \, in \right]}{w \left[mils \right] \, x \, Z_{_0} \left[Ohms \right]} \sqrt{f \left[GHz \right]}$$

Z₀ is "single-ended impedance"

 $R_{Len}[Ohms/in] = \frac{5\Omega}{w[mils]} \sqrt{f[GHz]}$

For differential pairs, R is 2x larger, Z_0 is 2x larger, attenuation is the same

Surface roughness can more than double series resistance

- Very difficult to get accurate calculation of surface roughness impact

For 50 Ω :

atten[dB/in] =
$$\frac{44[\text{Ohms/in}]}{\text{w[mils]} \times Z_0[\text{Ohms}]} \sqrt{f[\text{GHz}]} \sim \frac{1}{\text{w[mils]}} \sqrt{f[\text{GHz}]}$$



Teledyne LeCroy Signal Integrity Academy

Lesson AGCD-03-80 Attenuation in typical channels

Course AGCD: Advanced Gigabit Channel Design

With Eric Bogatin,

Signal Integrity Evangelist, Teledyne LeCroy Front Range Signal Integrity Lab Dean, Teledyne LeCroy Signal Integrity Academy Adjunct Professor, University of Colorado, Boulder, ECEE

AGCD-03-80: recorded live, Dec 1, 2013

- Example of worst case channel: FR4 and narrow lines
- Important figures of merit in FR4, lossy channels
- Example of best case, low loss channel with Megtron 6
- Comparing simple figures of merit estimates with measured channels



Teledyne LeCroy Signal Integrity Academy

33

Typical Worst Case: FOM ~ 0.2 dB/inch/GHz Total Attenuation in FR4

- for 50 Ohm single-ended, 100 Ohm diff

$$atten[dB/in] = 4.34 \ x \left(\frac{\mathsf{R}_{len}[\mathsf{Ohms/in}]}{\mathsf{Z}_0[\mathsf{Ohms}]} + \mathsf{G}_{L}[\mathsf{Siemens/in}] \ x \ \mathsf{Z}_0[\mathsf{Ohms}] \right)$$

$$atten[dB/in] \sim \frac{1}{w[mils]} \sqrt{f[\mathsf{GHz}]} + 2.3 \ x \ f[\mathsf{GHz}] \ x \ \mathsf{Df} \ x \ \sqrt{\mathsf{Dk}}$$

$$- \mathsf{current on both surfaces}$$

$$- \mathsf{resistance of return path}$$

$$- \mathsf{2x surface roughness}$$

Example: @ 1 GHz, (2 Gbps) w = 5 mil, Dk = 4.3, Df = 0.02 $atten[dB/in] \sim \frac{1}{5} \sqrt{1} + 2.3 \times 1 \times 0.02 \times \sqrt{4.3} = 0.02$

Figure of Merit ~ 0.3 dB/in/GHz

0.2dB/in + 0.1dB/in = 0.3dB/in

Example: @ 4 GHz, (8 Gbps) w = 5 mil, Dk = 4.3, Df = 0.02

atten[dB/in] $\sim \frac{1}{5} \sqrt{4} + 2.3 \times 4 \times 0.02 \times \sqrt{4.3} =$


Figure of Merit ~ 0.22 dB/in/GHz

0.4dB/in + 0.5dB/in = 0.9dB/in



Teledyne LeCroy Signal Integrity Academy

Typical Best Case: FOM ~ 0.1 dB/inch/GHz Total Attenuation in Megtron6 atten[dB/in] = 4.34 x $\left(\frac{R_{len}[Ohms/in]}{Z_0[Ohms]} + G_L[Siemens/in] \times Z_0[Ohms]\right)$ atten[dB/in] $\sim \frac{1}{w[mils]} \sqrt{f[GHz]} + 2.3 \times f[GHz] \times Df \times \sqrt{Dk}$ - current on both surfaces resistance of return path - 2x surface roughness - for 50 Ohm single-ended, 100 Ohm diff Example: @ 1 GHz, (2 Gbps) w = 7 mil, Dk = 3.7, Df = 0.002 atten[dB/in] $\sim \frac{1}{7}\sqrt{1} + 2.3 \times 1 \times 0.002 \times \sqrt{3.7} =$ 0.14dB / in + 0.009dB / in = 0.15dB / inFigure of Merit ~ 0.15 dB/in/GHz Example: @ 4 GHz, (8 Gbps) w = 7 mil, Dk = 3.7, Df = 0.002 atten[dB/in] $\sim \frac{1}{7} \sqrt{4} + 2.3 \times 4 \times 0.002 \times \sqrt{3.7} =$ Figure of Merit ~ 0.08 dB/in/GHz 0.28dB/in + 0.035dB/in = 0.32dB/inVery expensive material wasted by conductor loss TELEDYNE LECRO **Teledyne LeCroy Signal Integrity Academy** 35



Summary of Bandwidth Terms

- If ISI is affected ONLY by losses (doing EVERYTHING else right) best cases:
- ~ 2 x (-4 dB BW) is the highest data rate at which the eye will not be strongly affected by loss
- ~ 2 x (-8 dB BW) is the highest data rate at which you may not need any equalization
- ~ 2 x (-15 dB BW) is the highest data rate at which CTLE equalization may recover acceptable eye
- ~ 2 x (-25 dB BW) is the highest data rate at which reasonable CTLE, FFE, DFE equalization might recover acceptable eye



Teledyne LeCroy Signal Integrity Academy

37

Examples

- In a low loss channel, how far can you go at 10 Gbps using best equalization?
 - -25 dB = -0.1 dB/inch/GHz x Len x 5 GHz= 0.5 dB/inch x Len
 - Len = 50 inches
- In a lossy channel, how far can you go with no equalization at 10 Gbps?
 - -10 dB = -0.2 dB/inch/GHz x Len x 5 GHz = 1 dB/inch x Len
 - Len = 10 inches



Teledyne LeCroy Signal Integrity Academy

How do we Engineer Interconnects to Have S21 loss below ~ -25 dB?

- Shortest interconnects practical
- Minimize conductor loss
 - Engineer widest line width balanced with required interconnect density

 - Loose coupling
 Lowest impedance practical
 Lowest Dk practical

 - Thickest dielectric layers practical
 - Conductor thickness > ½ oz. copper not much impact
 - Use smooth copper
- Minimize dielectric loss (no design features affect dielectric loss)
 - Lowest dissipation factor laminate practical
 - Use lower loss laminate on selected layers for lowest cost
- Keep surface traces (microstrip) short
 - Humidity sensitivity
 - Higher loss from surface treatment, rougher copper
 - Possible high far end cross talk



Teledyne LeCroy Signal Integrity Academy

