Key: FreqAnalyserISR Task Reads the frequency **ISR** on interrupt Queue Global variable newFreqQ Direction of arrow shows SwitchPollingTask StabilityMonitorTask direction of Polls for the status of manual Checks if stability condition has control switches been violated Higher priority Priority: 1 Priority: 5 number Executes periodically (100ms) Executes on newFreqQ message corresponds to switch ON load n Stable \rightarrow unstable condition higher task (enum: 0x0n) (enum: 0xFF) loadCtrlQ switch OFF load n priority (enum: 0x1n) systemStatusFlg LoadCtrlTask Reflects whether the Switches loads ON/OFF loads are being actively depending on loadCtrlQ regulated message Read Mutex guarded Priority: 4

Executes on loadCtrlQ message