Setting up the Raspberry Pi based field sensor monitor $$\operatorname{August}\ 2016$$

Contents

1	Intr	roduction	3
2		cription of hardware	3
		Base station (Raspberry Pi)	
	2.2	Logger (Moteino)	3
3 Usi		ng the software	3
	3.1	Base station (Raspberry Pi)	3
		Logger (Moteino)	3
		3.2.1 Radio parameters	3
		3.2.2 Logging parameters	3

1 Introduction

This document describes how to set up and use the field monitoring system based on a Raspberry Pi base station and Moteino/Arduino based loggers. It provides a description of the hardware used and how to set up specific parameters in software, such as logging frequency.

2 Description of hardware

- 2.1 Base station (Raspberry Pi)
- 2.2 Logger (Moteino)
- 3 Using the software
- 3.1 Base station (Raspberry Pi)
- 3.2 Logger (Moteino)
- 3.2.1 Radio parameters

NODEID

NETWORKID

GATEWAYID

FREQUENCY

ENCRYPTKEY

ENABLE_ATC

3.2.2 Logging parameters

NUM_PHOTODIODES