											PRO	OTECTI	VE DE	VICE A	AND T	HEIR (DESINA	TIONS							
		115 KV. LINE FROM SAMUT SAKON 2 SUBSTATION (EGAT)						115-22 kV.TRANSFORMER-TP1					115 KV. LINE TO THA SAI 2 SUBSTATION SUBSTATION					11	115 kV BUS COUPLER BREAKER		115 kV		115 kV		
			MAIN1 & MAIN2						MAIN1 & MAIN2					MAIN1 & MAIN2						COUPLER BREAKER		MAIN BUS 2		BUS 1	
		DISTANCE RELAY, PHASE&GROUND ZONE #1	DISTANCE RELAY, PHASE&GROUND ZONE #2	DISTANCE RELAY, PHASE&GROUND ZONE #3	DIRECTIONAL PHASE&GROUND OVERCURRENT RELAY	LINE BREAKER FAILURE RELAYING	UNDER/OVER VOLTAGE RELAYS		TP1 INTERNAL PROTECTIVE DEVICES	TP1 TRANSFORMER DIFFERENTIAL RELAY WITH RESTRICTED EARTH FAULT RELAY	TP1 115 kV. SIDE PHASE & GROUND OVERCURRENT RELAY	TP1 OVERCURRENT GROUND BACKUP RELAY	TP1 BREAKER FAILURE RELAYING	DISTANCE RELAY, PHASE&GROUND ZONE #1	DISTANCE RELAY, PHASE&GROUND ZONE #2	DISTANCE RELAY, PHASE&GROUND ZONE #3	DIRECTIONAL PHASE&GROUND OVERCURRENT RELAY	LINE BREAKER FAILURE RELAYING	UNDER/OVER VOLTAGE RELAYS	BUS COUPLING BREAKER FAILURE RELAYING		BUS DIFFERENTIAL RELAY	CT SUPERVISION RELAY	BUS DIFFERENTIAL RELAY	CT SUPERVISION RELAY
LOCA	LOCATION OF DEVICE (PNL.NO.)		LCP2&LRP2						TCP1&TPP1				LCP1&LRP1					BCP		BZP					
DEVICE NO.		21-1 21N-1	21-2 21N-2	21-3 21N-3	67 67N	50 BF	27 59		TP1 DEVICES	87T 87REF	50, 50N 51, 51N	51 GB	50 BF	<u>21-1</u> 21N-1	<u>21-2</u> 21N-2	21-3 21N-3	67 67N	50 BF	27 59	50 BF		87 B2	95 B2	87 B1	95 B1
AUXILIARY TIMING RELAY																									
AUXILIARY TRIPPING RELAY						86B, 86BF				86T18	% 86T2	•	86B, 86BF					86B, 86BF		86BF 86B1 86B2	;	86B2		86B1	
TRIPPING RELAY CHARACTERISTICS						HS ER			H E		HS Ef		HS ER					HS ER		HS ER		HS ER		HS ER	
OPERATION TARGET/AUDIBLE ALARM		Y	Y	Y	Υ	Υ	Y		Y	Y	Y	Y	Y	Υ	Y	Y	Y	Y	Y	Y		Y	Y	Y	Y
	0BYB-01					TL1 ⁷⁵	EE NOTE	2					T _L 7 ^{SE}	E NOTE 2				TL1 ^{ZS}	EE NOTE 2	T _{L1} ⁷	SEE NOTE 2	TL		TL	
FUNCTION OF DEVICE	01YB-01													T _R	Т	Т	Т	T _{L1}							
	02YB-01								Т	L	T	L	T _{L1}												
	03YB-01	T _R	Т	Т	Т	T _{L1}																			
	04YB-01																								
	05YB-01																								
	06YB-01																								
	TRIP ALL BUS NO.1 BREAKERS					TL1	see note	2					TL1] ,	EE NOTE	2			TL1	SEE NOTE 2	TL1	SEE NOTE 2			TL	
	TRIP ALL BUS NO.2 BREAKERS					TLJ							TLJ					TLJ		TL1		TL			
	1BVB-01									ГL	1	Ĺ	T _{L1}												
	2BVB-01																								
	3BVB-01																								

		THS-P
กองออกแบบสถานีไฟฟ้า ฝ่ายงานสถานีไฟฟ้า	การไฟฟ้าส่วนภูมิภาค	ใช้แทนแบบ ถูกแทนโดยแบบ
เขียน <u>ภราคร</u> สำรวจ <u>ภราคร</u> ศฎกร ภราคร	ผู้ว่าการ(แทน)	เขียนเสร็จวันที่ <u>30 ก.ย. 64</u>
ว์วหน้าแผนก <u>วรเวช</u> อำนวยการกอง	สถานีไฟฟ้าท่าทราย 1 จังหวัดสมุทรสาคร ฟังก์ชั่นการทำงานของอุปกรณ์ป้องกัน	มิติเป็น มาตราล่วน
ู้อำนวยการฝ่าย(แทน) องผู้ว่าการวิศวกรรม	THA SAI 1 SUBSTATION SAMUT SAKHON PROVINCE PROTECTIVE DEVICE FUNCTION	แบบเลขที่ <u>FA4-011/64058</u> แผ่นที่ <u>2 ข</u> องจำนวน <u>4</u> แผ่น