

Success with 2009 IECC in South Carolina: Tech Tips for Builders

FOUNDATION







TECH TIPS: FOUNDATION

Success with 2009 IECC in South Carolina for Builders

If installing poly sheeting, install at least 6-mil thickness and overlap at least 6 inches.






X NO DAMP PROOFING



Install a drainage system along entire foundation footing of belowgrade walls.









Damp proof the exterior of all below-grade walls.





Copyright ©2014 Advanced Energy. All Rights Reserved - Page 2