Ridgeline 2P and 3P Tent: Owner's manual

Thank you for choosing a Ridgeline tent. Keep this manual with your tent.

In the box

Inner tent, rainfly, DAC aluminium pole set, 10 stakes, 4 guylines, repair kit and stuff sack.
The footprint is sold separately (FP-R2 for the 2P, FP-R3 for the 3P).

Pitching

1. Lay out the footprint, shiny side up, and the inner tent on top, doors where you want them.
2. Stake the four corners of the inner tent through the footprint's corner webbing.
3. Assemble the poles and seat the ends in the corner grommets, colour to colour.
4. Clip the inner tent to the poles, starting from the bottom.
5. Drape the rainfly over the poles with its doors over the inner doors, and buckle it at the corners.
6. Stake out the vestibules and tension the guylines. In wind, face the narrow end into the wind.

Taking it down

Unclip in reverse order. Fold the poles from the middle so the shock cord wears evenly.

Care and storage

Never store the tent wet. Dry it within 24 hours, or mildew will stain and weaken the fabric.
Clean with lukewarm water and a sponge. Do not use detergent or a washing machine.
Store loosely in a dry place, out of the sun, not compressed in the stuff sack.
The seams are factory taped. Re-seal them with seam sealer after about three seasons of use.

Condensation

On cold, still nights, water can condense on the inside of the rainfly. This is not a leak.
Open both rainfly vents and keep the doors partly open to let moist air out.

Troubleshooting and repairs

Small tear in the rainfly or inner (under 3 cm): clean and dry the area, then apply a patch from the repair kit to both sides. Larger tears, and any tear along a seam, need a replacement rainfly: RF-R2 for the 2P, RF-R3 for the 3P.

Bent or cracked pole section: slide the splint sleeve from the repair kit over the damaged section and tape both ends. This is a temporary fix; replace the pole set (PK-R).

Stuck zipper: do not force it. Rinse grit out with water and pull the slider back gently. A zipper that splits behind the slider is covered by the warranty.

Warranty

Your tent has a two-year warranty against defects in materials and workmanship. Contact Acme support with your order number.