



Love our service?
Review Eagle at
Reviews.radonremover.com
or scan ↑

Radon Test Instructions

Follow these steps carefully to ensure accurate results.

RUNNING THE TEST

1 Wait at least 48 hours after the system has been running before you start testing.

2 Using the test kit provided, place the vial(s):

- At least **3 feet** from doors, walls, and windows
- At least **2 feet** off the floor
- At least **4 inches** from other objects
- In an area that stays at or above **55°F** for the entire test

If using two vials in the same location, place them four inches apart. Two vials can also be placed in two separate areas — for instance, the basement and first floor at the same time. Adjust according to your own needs.

3 Remove the cap from the vial(s). At the same time, begin filling in the laboratory information sheet found in the same box.

Important: The testing period must run **48–96 hours** — no more, no less.

4 After the testing period, replace the cap on the vial(s) and return them to the pre-posted box with the completed information sheet.

The back page of the information sheet has a spot for vial numbers. Write down your vial number(s) and tear that sheet off for your records.

5 Mail the kit back promptly once testing has ended.

Prompt shipping ensures the kit reaches the laboratory within the required time frame. If you're concerned about timing, feel free to ship by FedEx or UPS — but since the laboratory is in Massachusetts, delivery should not be a problem.

FILLING OUT THE LABORATORY INFORMATION SHEET

- 1** Under “**Report To,**” fill in **your own** name and address — **not** Eagle Environmental, Inc.
- 2** Disregard the technician name and certification number.
- 3** Start and finish **dates and times** must be filled in to receive results, along with the number(s) on the side of the vial(s) — the **device number**.

Temperature requirement: Do **not** report a temperature below **55°F**. A test area recorded below 55°F will be considered **invalid** by the laboratory.

Don't forget to place the information sheet in the box!