

CP Floor Standing Ceramic Heater

USER INFORMATION

This model is fitted with safety tilt switches. If the unit was to be knocked over the Ceramic elements turn off. If you only require heat from one Element we recommend that you use the top one.

Assembly Instructions

The CP unit has been packed with a separate base to the stand.

Remove the two screws in the base tube, join the two parts together and refit the screws.

IF THE FITTED MOULDED PLUG IS UNSUITABLE FOR YOUR SOCKET OUTLET THEN THE FUSE SHOULD BE REMOVED AND THE PLUG CUT OFF AND DISPOSED OF SAFELY. THERE IS A DANGER OF SEVERE ELECTRICAL SHOCK IF THE CUT OFF PLUG IS INSERTED INTO ANY 13 AMP SOCKET.

If a new plug is to be fitted please observe the wiring code as shown below. If in any doubt please consult a qualified electrician.

WARNING: THIS APPLIANCE MUST BE EARTHED.

The wires in this mains lead are coloured in accordance with the following code-

Green and Yellow - Earth Blue - Neutral Brown - Live

As the colours of the wire in the mains lead of this appliance may not correspond with the coloured markings identifying the terminals in your plug, proceed as follows.

The wire which is coloured GREEN AND YELLOW must be connected to the terminal in the plug which is marked with the letter E or by the Earth symbol or coloured GREEN or GREEN-AND-YELLOW.

The wire which is coloured BLUE must be connected to the terminal in the plug which is marked with the letter N or coloured BLACK.

The wire which is coloured BROWN must be connected to the terminal in the plug which is marked with the letter L or coloured RED.

SAFETY PRECAUTIONS

- 1. Please check rating label to ensure correct VOLTAGE before connection to any mains supply.
- 2. Do not cover the heater. A fire risk exists if the heater is covered or incorrectly positioned.
- 3. Do not use within 1.5 meters of combustible materials.
- 4. Ensure mains cable is behind heater during use.
- 5. Do not use in areas where water is present.
- 6. We recommend the use of a fire guard when children or animals are present.
- 7. Always unplug before removing any cover or guard, also before cleaning or maintenance is carried out.

PLEASE CHECK VOLTAGE LABEL PRIOR TO USE