## レッスン17迷路チャレンジ!(2)

# \*\*ロボットの超音波センサを工夫して決められた迷路をクリアしよう! このレッスンで身につける力

- □ 超音波センサを正しく取り付けることができる
- □ ジャンパーワイヤーを正しく接続できる
- □トラッキングセンサの感度を調整できる
- サンプルコードを実行できる
- □ 条件式の書き方を理解してコードを修正できる
- □ コースを走破するためにサンプルコードを修正できる

## ミッションの準備

## ハードウェアを用意しよう

- ■ Osoyoo ロボット(Arduino UNO rev.3と完全互換) x 1
- □ USBケーブル x 1
- □パソコン x 1
- 超音波センサ x 1
- サーボモータx1
- 取り付け用ねじなど

#### 0.ArduinoIDEを起動しよう

デスクトップにあるAruduinoのアイコンをダブルクリックしてArduinoIDEを起動しましょう.



#### 1.スケッチを保存しよう

(Arduinoでは、プログラムのことを「スケッチ」といいます.)

ファイル→保存をクリック(Ctrl+SでもOK)して,デスクトップに「lesson 08 1」という名前で保存しましょう.



## 2.Arduinoとパソコンを接続しよう

Arduino UNOボードとパソコンをUSBケーブルでつなぎましょう.




【注意】USBを抜き差しするときは向きを確認して、ていねいにあつかうこと.

USBを差したら、ArduinoIDEでボードとシリアルポートを指定しましょう.

ツール→ボードをクリックして、Arduino/Genuino UNOをクリックしましょう。


次にツール $\rightarrow$ シリアルポートをクリックして、「COM $\sim$ (Arduino UNO)」となっているものをクリックしましょう。(COM $\sim$ の数字は毎回変わります。)




## ミッションチャレンジ

## 配線をしよう

今回新たに取り付けるのはサーボモータと超音波センサだよ。これらをジャンパー線を用いて配線を行なおう! 写真と同じようにして配線をしてみよう。





サンプルスケッチを実行して、実験してみよう

#### スケッチに以下のコードをコピー&ペーストして、スケッチを実行してみよう。

### ▶ サンプルコードはここからコピー&ペーストしよう

```
* / _ \ / _ ) / _ \ | | | | / _ \ / _ \ / _ _ ) _ \ |
 *| |_| | ( (__| |_| | | |
 * \__/(__/\__/\__|\__/\__(_)___)__/|_|_|
 * Arduino Smart Car Tutorial Lesson 5
 * Tutorial URL http://osoyoo.com/2018/12/19/osoyoo-robot-car-kit-lesson-4-
obstacle-avoidance-robot-car/
* CopyRight www.osoyoo.com
* This project will show you how to make Osoyoo robot car in auto drive
mode and avoid obstacles
* /
 #include <Servo.h>
/*Declare L298N Dual H-Bridge Motor Controller directly since there is not
a library to load.*/
//Define L298N Dual H-Bridge Motor Controller Pins
#define speedPinR 3 // RIGHT PWM pin connect MODEL-X ENA
#define RightDirectPin1 12  // Right Motor direction pin 1 to MODEL-X
#define RightDirectPin2 11 // Right Motor direction pin 2 to MODEL-X
#define speedPinL 6 // Left PWM pin connect MODEL-X ENB
#define LeftDirectPin1 7 // Left Motor direction pin 1 to MODEL-X IN3
#define LeftDirectPin2 8 ///Left Motor direction pin 1 to MODEL-X IN4
#define LPT 2 // scan loop coumter
#define SERVO PIN 9 //servo connect to D9
#define Echo PIN 2 // Ultrasonic Echo pin connect to D11
#define Trig_PIN 10 // Ultrasonic Trig pin connect to D12
#define BUZZ PIN
                   13
#define FAST SPEED 250 //both sides of the motor speed
#define SPEED 120  //both sides of the motor speed
#define TURN_SPEED 200 //both sides of the motor speed
                          //back speed
#define BACK SPEED1 255
#define BACK SPEED2 90  //back speed
int leftscanval, centerscanval, rightscanval, ldiagonalscanval,
rdiagonalscanval;
const int distancelimit = 30; //distance limit for obstacles in front
const int sidedistancelimit = 30; //minimum distance in cm to obstacles at
both sides (the car will allow a shorter distance sideways)
int distance;
int numcycles = 0;
const int turntime = 250; //Time the robot spends turning (miliseconds)
```

```
const int backtime = 300; //Time the robot spends turning (miliseconds)
int thereis;
Servo head;
/*motor control*/
void go Advance(void) //Forward
 digitalWrite(RightDirectPin1, HIGH);
 digitalWrite(RightDirectPin2, LOW);
 digitalWrite(LeftDirectPin1, HIGH);
 digitalWrite(LeftDirectPin2,LOW);
void go Left() //Turn left
 digitalWrite(RightDirectPin1, HIGH);
  digitalWrite(RightDirectPin2, LOW);
 digitalWrite(LeftDirectPin1,LOW);
  digitalWrite(LeftDirectPin2, HIGH);
void go Right() //Turn right
  digitalWrite(RightDirectPin1, LOW);
 digitalWrite(RightDirectPin2, HIGH);
 digitalWrite(LeftDirectPin1, HIGH);
 digitalWrite(LeftDirectPin2,LOW);
void go Back() //Reverse
  digitalWrite(RightDirectPin1, LOW);
  digitalWrite(RightDirectPin2, HIGH);
  digitalWrite(LeftDirectPin1,LOW);
  digitalWrite(LeftDirectPin2, HIGH);
void stop_Stop() //Stop
  digitalWrite(RightDirectPin1, LOW);
  digitalWrite(RightDirectPin2, LOW);
  digitalWrite(LeftDirectPin1,LOW);
 digitalWrite(LeftDirectPin2,LOW);
  set Motorspeed(0,0);
/*set motor speed */
void set Motorspeed(int speed L, int speed R)
  analogWrite(speedPinL, speed L);
  analogWrite(speedPinR, speed R);
void buzz ON() //open buzzer
{
  for (int i=0; i<100; i++)
```

```
digitalWrite(BUZZ PIN,LOW);
   delay(2);//wait for 1ms
  digitalWrite(BUZZ PIN, HIGH);
  delay(2);//wait for 1ms
void buzz OFF() //close buzzer
  digitalWrite(BUZZ PIN, HIGH);
void alarm() {
  buzz ON();
  buzz OFF();
/*detection of ultrasonic distance*/
int watch(){
 long echo distance;
 digitalWrite(Trig PIN, LOW);
 delayMicroseconds(5);
 digitalWrite(Trig PIN, HIGH);
 delayMicroseconds (15);
 digitalWrite(Trig PIN, LOW);
 echo distance=pulseIn(Echo PIN, HIGH);
 echo distance=echo distance*0.01657; //how far away is the object in cm
 //Serial.println((int)echo distance);
 return round (echo distance);
//Meassures distances to the right, left, front, left diagonal, right
diagonal and asign them in cm to the variables rightscanval,
//leftscanval, centerscanval, ldiagonalscanval and rdiagonalscanval (there
are 5 points for distance testing)
String watchsurrounding(){
/* obstacle status is a binary integer, its last 5 digits stands for if
there is any obstacles in 5 directions,
* for example B101000 last 5 digits is 01000, which stands for Left
front has obstacle, B100111 means front, right front and right ha
* /
int obstacle status =B100000;
 centerscanval = watch();
  if(centerscanval<distancelimit){</pre>
   stop Stop();
    alarm();
    obstacle_status =obstacle_status | B100;
 head.write(120);
 delay(100);
 ldiagonalscanval = watch();
 if(ldiagonalscanval<distancelimit){</pre>
   stop Stop();
    alarm();
```

```
obstacle status =obstacle status | B1000;
  head.write(170); //Didn't use 180 degrees because my servo is not able to
take this angle
 delay(300);
  leftscanval = watch();
  if(leftscanval<sidedistancelimit){</pre>
    stop Stop();
    alarm();
     obstacle status =obstacle status | B10000;
  head.write(90); //use 90 degrees if you are moving your servo through the
whole 180 degrees
 delay(100);
  centerscanval = watch();
  if(centerscanval<distancelimit){</pre>
    stop Stop();
    alarm();
    obstacle status = obstacle status | B100;
  head.write(40);
  delay(100);
  rdiagonalscanval = watch();
  if(rdiagonalscanval<distancelimit){</pre>
    stop Stop();
    alarm();
    obstacle status =obstacle status | B10;
  head.write(0);
  delay(100);
  rightscanval = watch();
  if(rightscanval<sidedistancelimit){</pre>
    stop Stop();
    alarm();
    obstacle status =obstacle status | 1;
 head.write(90); //Finish looking around (look forward again)
 delay(300);
  String obstacle str = String(obstacle status, BIN);
  obstacle str= obstacle str.substring(1,6);
  return obstacle str; //return 5-character string standing for 5 direction
obstacle status
}
void auto avoidance(){
  ++numcycles;
  if(numcycles>=LPT) { //Watch if something is around every LPT loops while
moving forward
     stop Stop();
    String obstacle sign=watchsurrounding(); // 5 digits of obstacle sign
binary value means the 5 direction obstacle status
```

```
Serial.print("begin str=");
        Serial.println(obstacle sign);
                    if( obstacle sign=="10000") {
     Serial.println("SLIT right");
          set Motorspeed(FAST SPEED, SPEED);
     go Advance();
     delay(turntime);
     stop Stop();
       else if( obstacle sign=="00001" ){
     Serial.println("SLIT LEFT");
       set Motorspeed (SPEED, FAST SPEED);
      go Advance();
     delay(turntime);
     stop Stop();
    else if ( obstacle sign=="11100" || obstacle sign=="01000" ||
obstacle sign=="11000" || obstacle sign=="10100" ||
obstacle sign=="01100" ||obstacle sign=="00100" ||obstacle sign=="01000" )
     Serial.println("hand right");
        go Right();
     set Motorspeed (TURN SPEED, TURN SPEED);
     delay(turntime);
      stop Stop();
    else if( obstacle sign=="00010" || obstacle sign=="00111" ||
obstacle sign=="00011" || obstacle sign=="00101" || obstacle sign=="00110"
|| obstacle sign=="01010" ) {
   Serial.println("hand left");
    go Left();//Turn left
    set_Motorspeed(TURN_SPEED,TURN_SPEED);
     delay(turntime);
     stop_Stop();
    }
    else if( obstacle sign=="01111" || obstacle sign=="10111" ||
obstacle sign=="11111" ){
   Serial.println("hand back right");
      go Left();
       set Motorspeed( FAST SPEED, SPEED);
      delay(backtime);
         stop Stop();
        else if( obstacle_sign=="11011" || obstacle sign=="11101" ||
obstacle_sign=="11110" || obstacle_sign=="01110" ){
    Serial.println("hand back left");
    go Right();
   set Motorspeed( SPEED, FAST SPEED);
       delay(backtime);
          stop_Stop();
```

```
else Serial.println("no handle");
    numcycles=0; //Restart count of cycles
  } else {
     set Motorspeed(SPEED, SPEED);
     go Advance(); // if nothing is wrong go forward using go() function
above.
        delay(backtime);
          stop Stop();
  //else Serial.println(numcycles);
  distance = watch(); // use the watch() function to see if anything is
ahead (when the robot is just moving forward and not looking around it will
test the distance in front)
  if (distance<distancelimit) { // The robot will just stop if it is
completely sure there's an obstacle ahead (must test 25 times) (needed to
ignore ultrasonic sensor's false signals)
 Serial.println("final go back");
    go Right();
    set Motorspeed( SPEED, FAST SPEED);
  delay(backtime*3/2);
      ++thereis; }
  if (distance>distancelimit) {
      thereis=0;} //Count is restarted
  if (thereis > 25) {
  Serial.println("final stop");
    stop Stop(); // Since something is ahead, stop moving.
    thereis=0;
}
void setup() {
  /*setup L298N pin mode*/
  pinMode (RightDirectPin1, OUTPUT);
  pinMode (RightDirectPin2, OUTPUT);
  pinMode(speedPinL, OUTPUT);
  pinMode(LeftDirectPin1, OUTPUT);
  pinMode(LeftDirectPin2, OUTPUT);
  pinMode(speedPinR, OUTPUT);
  stop Stop();//stop move
  /*init HC-SR04*/
  pinMode(Trig PIN, OUTPUT);
  pinMode(Echo PIN, INPUT);
  /*init buzzer*/
  pinMode(BUZZ PIN, OUTPUT);
  digitalWrite(BUZZ PIN, HIGH);
  buzz OFF();
  digitalWrite(Trig PIN, LOW);
  /*init servo*/
  head.attach(SERVO PIN);
  head.write(90);
```


```
delay(2000);

Serial.begin(9600);

void loop() {
  auto_avoidance();
}
```

## 迷路を解いてみよう!

Lesson7ではセンサに頼ることなく、モータの動く時間で制御して迷路をクリアしたね。今回は超音波センサーを使って 迷路をクリアしてみよう



## 出来たことをチェックしよう

- □ 超音波センサを正しく取り付けることができる
- □ ジャンパーワイヤーを正しく接続できる
- ■トラッキングセンサの感度を調整できる
- ■サンプルコードを実行できる
- □ 条件式の書き方を理解してコードを修正できる
- □ コースを走破するためにサンプルコードを修正できる