Condo Tag Triage — One■Page Cheat Sheet

Scan → Identify → Action. Exact commands and example outputs for common tags.

Tag Type	What you should see (examples)	Action / Notes (commands)
EM410x (read-only)	lf search -> [+] Valid EM410x ID 57003E2DB3 Raw: 57003E2DB3 Note: ‘RF/64’ or EM410x	Action: Emulate or copy to writable blank Commands: lf search lf em 4x05 sim 57003E2DB3 Can't rewrite original (factory)
Indala (proprietary)	lf search -> [+] Indala (len 64) Raw: a0000000e3f00d51 Possible: Fmt26, Heden, Paxton	Action: Prefer T5577 or EM4305 target Commands: lf indala clone -r a0000000e3f00d51 lf t55xx detect lf readback odd -> try --pg1 or set offset
HID Prox / 26-bit	lf search -> Fmt 26 FC: 134 Card: 47173 Parity: 11 Shown as FMT26 / H10301	Action: Write to T5577 with FC/CN mapping Commands: lf indala clone --fc 134 --cn 47173 lf search
T5577 (writable blank)	lf t55xx detect -> Chip type: T55x7 lf t55xx read --blk 1 --r1 -> shows hex Blank read often: 00000000 or 'odd size'	Action: Configure then write Commands: lf t55xx config --PSK3 --rate 16 --r1 lf t55xx write --blk 0 --data 00088040 lf t55xx write --blk 1 --data A0000000
EM4305 (rewritable EM)	lf em 4x05 info -> shows chip details lf search may show EM4x05/EM4x69	Action: Use lf em 4x05 clone or info Commands: lf em 4x05 info lf em 4x05 clone --raw <raw>
Blank card (generic)	lf search -> 'Odd size, false positive' or nothing lf t55xx read -> 00000000 or randomized garbage	Action: Try page/offset then write test pattern Commands: lf t55xx detect lf t55xx read --blk 1 --r1 --pg1 lf t55xx config --offset <N>

Quick Workflow:

1) hw tune → 2) lf search / hf search → 3) backup raw → 4) lf indala clone or lf em 4x05 clone → 5) verify with lf search and the real reader

One-page Condo Tag Triage • Keep on phone for fast checks