Condo Tag Triage — Field Card (Clear & Spaced)

Big, spaced commands and clear examples. One page for field use.

Quick Decision Flow

1) Run: hw tune
2) Run: lf search (checks 125 kHz / LF tags)
   -> If found: follow LF path (see LF box)
3) If nothing or unclear: run: hf search (checks 13.56 MHz / HF tags)
   -> If HF found: follow HF path (see HF box)

LF (125 kHz) — Common outputs & next commands

Valid EM410x:

pm3> lf search
[+] Valid EM410x ID 57003E2DB3

Action: Clone to writable blank (EM4305/T5577)
Command: pm3> lf em 4x05 clone --raw 57003E2DB3

Indala (len 64) Raw:

pm3> lf search
[+] Indala (len 64) Raw: a0000000e3f00d51

1) Backup raw: pm3> lf indala read -f /home/pm3/dumps/condo_raw.bin
2) Clone: pm3> lf indala clone -r a0000000e3f00d51
3) Verify: pm3> lf t55xx detect ; pm3> lf t55xx read --blk 1 --r1

Fmt26 / Wiegand 26:

pm3> lf search
Fmt 26 FC: 134 Card: 47173

Map FC/CN -> pm3> lf indala clone --fc 134 --cn 47173 or write mapping to T55x7

HF (13.56 MHz) — Common outputs & next comma

MIFARE UID (NTAG/Classic):

pm3> hf search
UID: 04 A2 1B 3C 52 71 80
Type: MIFARE Classic 1K

Action: pm3> hf 14a info # inspect
Note: many HF systems (DESFire/iCLASS) protected — cloning ofte

DESFire / iCLASS:

pm3> hf search
Type: MIFARE DESFire or iCLASS

Action: STOP — request OEM provisioning or keys from property ma

T55x7 / T5577 Write Examples (spaced commands)

Detect blank chip and configuration (one command per line):

pm3> lf t55xx detect

If detect shows Chip type: T55x7 and Offset N, set config:

pm3> lf t55xx config --PSK3 --rate 16 --r1

pm3> lf t55xx config --offset 53 # example offset from detect

Write blocks (page 0):

pm3> lf t55xx write --blk 0 --data 00088040
pm3> lf t55xx write --blk 1 --data A0000000
pm3> lf t55xx write --blk 2 --data E3F00D51

If data seems missing on page0, read page1:

pm3> lf t55xx read --blk 1 --r1 --pg1

Verify readback:

pm3> lf t55xx read --blk 1 --r1

Field Tips & Stock

- Keep T5577 and EM4305 blanks (5 each) and a few MIFARE ultralight/NTAG for HF simple systems.
- Always backup raw before writing: lf indala read -f /path/you/want.bin
- Use absolute paths if you might forget your working directory.
- Verify at the real reader — reader acceptance is the final test.
- Log raw file name, blank type, offset, page used, and reader model.

Only clone tags you own or have permission to clone. Keep client consent on file.