



# 5V boost / USB OTG supply




## 3.3V supply / battery charger





# 5V power distribution


## Plugs




#### Power domain switches


























Note: R34 only needed for first revision of NRF51822. DNP for Rev. 2 and up.