







ARM CAN TOOL

(I2C)

(BOOT)

(RESET)

SCL3
SDA3
SCL1
SDA1
3.3V
GND

(ARM)

VIO
TXD0
RXD0
SWDIO
SWCLK
GND

(CAN)

ISO GND
HIGH
LOW
HIGH
LOW
ISO GND

ISO
5V
GND

JLCA1C1L01LC

GND

3.3V
SDCARD

3.3V

V1.0

32K
RTC



1

12



5V
USB

12V
OLED

(SWD)

3.3V
TXD
RXD
SWDIO
SWCLK
GND

(AUX)

VIO
TXD1
RXD1
RXD2
NRST
GND

VIO