VABB/BOM

AIP

AIRCRAFT PUSHBACK PROCEDURE Runway 32

MUMBAI INDIA

Stands - C21 to C25

CHHATRAPATI SHIVAJI MAHARAJ INTL

C21	 Aircraft on stands C21 to push back deep facing north east on Taxilane W6 till abeam stand C30. Taxi via stand C29 → TWY U
C22-C23	 Aircraft on stands C22 and C23 to push back facing north east on Taxilane W6. Taxi via stand C29 → TWY U
C24-C25	 Aircraft on stand C24 to push back facing north east on Taxilane W6 to TUG Release point T6. Aircraft on stand C25 to push back facing north east on Taxilane W6 and pull forward to TUG Release point T6. Taxi via stand C29 → TWY U

CAUTION:

- Pushback from stands C21, C22, C23, C27, C28, C30 and C31 are interdependent.
- Pushback from stands C24, C25, C32 and C33 are interdependent.
- Pushback from stand C25 will restrict aircraft taxiing on TWY N

