Hexgears Venture

Quickstart Guide



Packaging Contents:

Venture Mechanical Keyboard USB Type-C Cable Quick Start Guide Card

Quickstart & Pairing:

The Venture is a hybrid Bluetooth and wired Bluetooth Color Indicators mechanical keyboard. To turn on your keyboard in Bluetooth mode, press the power button for 5 seconds on the top multi-function row that has this icon

. The Venture can then connect to up to four (4) separate devices easily, by pressing and holding for 3 seconds the following key combination - Fn + (1, 2, 3, or 4).

Bluetooth and Wireless Mode ON - Blue Bluetooth and Wired Mode ON - Purple Wired Mode only ON - Green Fully Charged - Green

 $\textbf{Example:} \ \mathsf{Press} \ \mathsf{and} \ \mathsf{hold} \ \mathsf{Fn+1} \ \mathsf{to} \ \mathsf{designate} \ \mathsf{the} \ \mathsf{Venture} \ \mathsf{as} \ \mathsf{Hexgears} \ \mathsf{BK-1} \ \mathsf{and} \ \mathsf{pair}$ with your computer. Then, press and hold Fn + 2 to designate the Venture as Hexgears BK-2 and pair with your phone.

After this is completed, Press Fn + 1 quickly to use the keyboard with your computer and Fn + 2 to switch to typing on your phone.

To use your keyboard in wired mode, simply plug it in using the included USB Type-C Cable. No drivers are required to use the Hexgears Venture - it should function as intended simply by plugging it in.

To reset your keyboard to default settings and clear memory, press and hold Fn + Esc for 5 seconds.

If the keyboard cannot be connected to a Bluetooth device within 3 minutes, it will enter sleep mode to conserve battery life. When connected to your Bluetooth device, the Venture will enter light power saving mode and turn off LEDs if not used within 90 seconds. If the device is not used in 15 minutes, the keyboard will enter deep sleep mode, you can press any key to wake the Venture from this state.

System Compatibility:

Windows, Mac OS, Linux, Android, iOS Bluetooth 4.0 Low Energy Mode

Connection:

8	Toggles between USB and Bluetooth modes
Fn + 1	Connect to Bluetooth device 1
Fn + 2	Connect to Bluetooth device 2
Fn + 3	Connect to Bluetooth device 3
Fn + 4	Connect to Bluetooth device 4

RGB Backlighting:

-☆-	Backlight switch: Press it to turn off the key backlight. Press it again to turn off the side LED backlight and turn on the key backlight. Press it the 3rd time to turn off all the backlight.
:®:	Key backlight effect mode switch
.0	Side backlight effect mode switch
Fn + - :© :	Key backlight color switch
Fn + ∙ ⊚ ∙	Side backlight color switch
Fn + , <	Decrease side backlight speed
Fn + · >	Increase side backlight speed
Fn +- —	Decrease side backlight brightness
Fn +=+	Increase side backlight brightness
Fn + ▲	Increase backlight brightness
Fn + ▼	Decrease backlight brightness
Fn+◀	Decrease backlight changing speed
Fn+►	Increase backlight changing speed
Fn + NUM	Toggles of Indicator light color

Media:

Fn + F3	Volume -
Fn + F4	Volume +
Fn + F5	Mute
Fn + F6	Skip back
Fn + F7	Play/Pause
Fn + F8	Skip forwards

Device:

•	Under bluetooth mode,hold 5S to turn on/turn off the keyboard
â	WIN key locked , press again, unlock
<u>₽</u>	Lock full key
ტ	Shut down (hold for 5s)
C	Sleep (hold for 5s)
8	Lock
Q	Search
Fn + ESC	Hold for 5s for factory reset
Fn + F1	Decrease screen brightness
Fn + F2	Increase Screen brightness
Fn + \ ~	Full key / 6 key anti-ghosting

Light recording:

Fn + F9	Press and Hold Fn + F9 for 3 seconds to enter Light Macro Recording Mode. To cycle through the available colors, press each key until it is the appropriate color. To save your lighting setup, quickly press Fn + F9 to exit Light Macro Recording Mode. If you go into a different light mode and want to return to your custom light macro, simply press Fn + F9 to return to your defined setup.
---------	--

Macro Recording:

Fn + F11	The Venture supports Macro recording on the Y, U, I, O, and P keys. To enter macro recording mode press Fn + F11 and watch the Y, U, I, O, and P keys light up. Press one of these 5 (Y, U, I, O, or P) keys to designate it as the macro key. Then press the key or string of keys you want to be the macro and finish by pressing Fn + F11 to save.
Fn + Y	To enter Macro Mode and use your macros during gaming, simply press Fn + Y and the Y, U, I, O, and P keys will light up white. The normal function of these keys will be replaced with the macro you defined. To exit Macro mode press Fn + Y again.

Product features:

Kailh Choc Switches - rated for up to 70 million keypresses. 108 keys + 6 multi-function keys Sculpted ABS shine-through keycaps Macro Recording Options Available N-Key Rollover RGB Full Color key backlighting and ring underlighting Support for USB Type-C Wired Mode and Bluetooth Mode switching

System Compatibility:

Keyboard: Low Profile Mechanical Switch: Kailh Choc Switches Polling Rate: 1000 Hz Switch Life: 70 Million Cycles Connector: USB Type-C

Voltage / Current: DC 5V / 500 mA Cable Material: Black, Braided USB Cable Cable Length: 1.8m Size: 435 x 141 x 29 mm Weight: 722 g



https://hexgears.org

© 2019 Hexgears. All Rights Reserved.