L	N						
10001	111011						
10010	11100x						
10011	1xx110						
10101	1100xx						
11001	0xx11x						
11010	10x0xx						
11011	1xx1x1						
11101							
100100							
101100							
110100							

CO*CO	10001	10010	10011	10101	11001	11010	11011	11101	100100	101100	110100	111011	11100x	1xx110	1100xx	0xx11x	10x0xx	1xx1x1
10001	-																	
10010		-																
10011	0100y1	01001y	-															
10101	010y01			-														
11001	01y001				-													
11010		01y010				-												
11011			01y011		0110y1	01101y	-											
11101				01y101	011y01			-										
100100									-									
101100									10y100	-								
110100									1y0100		-							
111011							y11011					-						
11100x					y11001							1110y1	-					
1xx110									1001y0	1011y0	1101y0			-				
1100xx	y10001	y10010	y10011								110y00	11y011	11y00x	110y10	-			
0xx11x		010y10	010y11	0101y1		011y10	011y11	0111y1						yxx110		-		
10x0xx									100y00	101y00		1y1011	1y100x	10xy10	1y00xx		-	
1xx1x1				y10101				y11101	10010y	10110y	11010y	111y11	111y01	1xx11y	110yx1	yxx111	10xyx1	-
	0100x1	01001x	01x011	01x101	0110x1	01101x	x11011	0111x1	10x100	1011x0	1101x0	1110x1	11x00x	110x10	1x00xx			
A1	010x01	01x010	x10011	0101x1	011x01	011x10	011x11	x11101	1x0100	101x00	110x00	11x011	1x100x	xxx110	110xx1	]		
	01x001	x10010	010x11	x10101	x11001			_	1001x0	10110x	11010x	1x1011	111x01	10xx10	_	xxx111	10xxx1	Ø
	x10001	010x10							100x00			111x11		1xx11x		]		
		_					_		10010x									