

Dev With Ali Cloud Link TEE Air Edition

V0.1

more than ust connected






Arch





CA/TA Dev




Architecture




















API overview

Ali自定义API

Secure world:

- TEE internal API.

Non-secure world:

- TEE client API.
- TEE lpm API.



Software Development Kit (SDK)



This SDK is used to develop CA and TA of Alibaba TEE Air.

SDK layout:

- Non secure world
 - header files \$(code)/src/ntw/inc
 - library \$(code)/src/ntw/drv \$(code)src/ntw/lpm
- Secure world
 - header files \$(code)/src/tw/inc 暴露给TA的api是tee_tos.h tee_crypto.h tee_tst.h 其中tee_crypto.h实现了部份接口, tee_tst.h是安全存储的接口
 - service link script
- Tools
 - build_tw
- Documentations
- Samples
- Test

TA/CA sample

```
int tee_xor_test()
    unsigned int a = 12345, b = 67890, c = 0;
   TEEC_Context cntx;
   TEEC Session ss;
   TEEC Operation op;
   TEEC_Result ret = TEEC_SUCCESS;
   ret = TEEC_OpenSession(&ss, &_g_uuid, NULL);
   if (ret != TEEC_SUCCESS) {
       tee_dbg_print(ERR, "failed to call TEEC_OpenSession, 0x%08x\n", ret);
       goto cleanup2;
   op.paramTypes = TEEC_PARAM_TYPES(
           TEEC_VALUE_INPUT, TEEC_VALUE_INPUT,
           TEEC_VALUE_OUTPUT, TEEC_NONE);
   op.params[0].value.a = a;
   op.params[1].value.a = b;
   op.params[2].value.a = c;
   ret = TEEC_InvokeCommand(&ss, CMD_XOR, &op);
   if (ret != TEEC_SUCCESS) {
       tee_dbg_print(ERR, "failed to call TEEC_InvokeCommand, 0x%08x\n", ret);
       goto cleanup3;
   c = op.params[2].value.a;
   tee_dbg_print(INF, "a = %d; b = %d; c = a ^b: %d\n", a, b, c);
   if (c != (a ^ b)) {
       ret = TEEC ERROR GENERIC;
       tee_dbg_print(ERR, "XOR failed!\n");
       goto cleanup3;
cleanup3:
   TEEC_CloseSession(&ss);
cleanup2:
   return ret;
```



TA/CA sample(cont)

```
— Alibaba Cloud Link
```

```
2 * Copyright (C) 2015 The YunOS Project. All rights reserved.
5 #include "tee_tos.h"
6 #include "tee_srv.h"
7 #include "xor.h"
9 static TEE_Result _xor_CreateEntryPoint(void)
       return TEE_SUCCESS;
12 }
14 static void _xor_DestroyEntryPoint(void)
16
       return;
17 }
19 static TEE_Result _xor_OpenSessionEntryPoint(
          uint32_t paramTypes,
21
          TEE_Param params[4],
22
          void **sessionContext)
23 {
24
       return TEE_SUCCESS;
25 }
27 static void xor CloseSessionEntryPoint(void *sessionContext) (5)
29
       return;
30 }
32 static TEE_Result _xor_InvokeCommandEntryPoint(
          void *sessionContext,
34
          uint32 t commandID,
35
          uint32_t paramTypes,
36
          TEE_Param params[4])
37 {
38
       if (paramTypes != TEE_PARAM_TYPES(
39
                  TEE_PARAM_TYPE_VALUE_INPUT,
40
                  TEE_PARAM_TYPE_VALUE_INPUT,
41
                  TEE_PARAM_TYPE_VALUE_OUTPUT,
42
                  TEE_PARAM_TYPE_NONE)) {
43
           return TEE_ERROR_BAD_PARAMETERS;
44
45
46
       if (CMD_XOR != commandID) {
47
          return TEE_ERROR_BAD_PARAMETERS;
48
49
50
       params[2].value.a =
51
          params[0].value.a ^ params[1].value.a;
       return TEE_SUCCESS;
54
56 TEE_SRV_DATA_START(_xor_CreateEntryPoint,
           _xor_DestroyEntryPoint,
           xor OpenSessionEntryPoint,
58
59
           _xor_CloseSessionEntryPoint,
60
           xor InvokeCommandEntryPoint)
61 TEE SRV UUID PROPERTY ("gpd.ta.appID", XOR SRV UUID)
62 TEE SRV BOOL PROPERTY ("gpd.ta.singleInstance", true)
63 TEE SRV BOOL PROPERTY ("gpd.ta.multiSession", true)
64 TEE_SRV_BOOL_PROPERTY("gpd.ta.instanceKeepAlive", true)
65 TEE SRV INT PROPERTY ("gpd.ta.dataSize", 0x10000)
66 TEE_SRV_INT_PROPERTY("gpd.ta.stackSize", 0x1000)
67 TEE SRV DATA END
```

TA/CA build



CA

。参考FreeRTOS_M2351/Demo/M2351_NS (通过Keil可以直接打开工程文件)

TA

在\$(code)/build/srv_path_list.log文件中,指定新的TA的路径如下:

../samples/xor/tw

编译

在\$(code)/build/ 运行 ./b 就可以。会在\$(code)/out 目录下生成TEE 镜像文件 tee_tw.bin.

所知不此于感知

MORE THAN JUST CONNECTED

(-) Alibaba Cloud Link