Key	Scancode	Key	Scancode	Key	Scancode
ESC	76	I	43	Alt (right)	E011
F1	05	0	44	Windows (rig	jht) E027
F2	06	Р	4D	Menus	E02F
F3	04	[54	Ctrl (right)	E014
F4	0C]	5B	Insert	E070
F5	03	\	5D	Home	E06C
F6	0B	Caps Lock	58	Page Up	E07D
F7	83	Α	1C	Delete	E071
F8	0A	S	1B	End	E069
F9	01	D	23	Page Dow	n E07A
F10	09	F	2B	Up Arrow	E075
F11	78	G	34	Left Arrow	E06B
F12	07	Н	33	Down Arro	w E072
•	0E	J	3B	Right Arrov	w E074
1	16	K	42	Num Lock	77
2	1E	L	4B	1	E04A
3	26	;	4C	*	7C
4	25	•	52	-	7B
5	2E	Enter	5A	7	6C
6	36	Shift (Left)	12	8	75
7	3D	Z	1A	9	7D
8	3E	X	22	+	79
9	46	С	21	4	6B
0	45	V	2A	5	73
-	4E	В	32	6	74
=	55	N	31	1	69
Backspace	66	M	3A	2	72
Tab	0D	,	41	3	7A
Q	15		49	0	70
W	1D	1	4A		71
E	24	Shift (Right)	59	Enter	E05A
R	2D	Ctrl (left)	14	Scroll Lock	k 7E
T	2C	Windows (left)	E01F		
Υ	35	Alt (left)	11		
U	3C	Spacebar	29		

Pause/Break Make: E11477E1F014E077 — No break code
Prt Scr Make: E012E07C — Break: E0F07CE0F012