

Faderpunk WIP Apps — UX Cheatsheet

Synced to test/playground (CV Jack In/Out) · 26 Jul 2026 · A4 print

Main — Fader alone	Alt — Shift + Fader	Third — Channel button held + Fader
Short — Tap button	Long — Hold button (long-press)	Shift+... — Global Shift + gesture

Jack CV Out / CV In (Heat Pump, Grooves, Golden Gate, Arp de Lévy, Chord Vamp; Super LFO is 2-ch with CV on Ch0): **CV Out** = app drives the jack · **CV In** = jack modulates a **CV Dest** (attenuated by **CV Att** 0–100%). Device-cycle Dest: Heat Pump & Super LFO via **Shift+Short** (Grooves: Configurator only). Golden Gate + Jack=CV In → MIDI-first (no CV/gate outs).

ID 29Heat Pumpready

Clock-synced sidechain ducking envelope

FADERS	BUTTONS	LEDS / OTHER PARAMS
Main — Release (up = faster recovery) Alt — Duck depth (red LED) Third — Clock division (1/1 ... 1/32) JACK PARAMS - Jack: CV Out / CV In - CV Dest: Depth · Release · Duck - Dest colors: Red · Yellow · Cyan - CV Att 0–100%	Short — Manual duck trigger Long — Mute (freeze level; no snap to idle) Shift+Short (CV Out) — Cycle clock division Shift+Short (CV In) — Cycle CV Dest (flash) Shift+Long — Invert duck direction	- Button metronome Mid→Low per division 1/1 uses Color param - Invert: white ↔ off fade - Color, Range, MIDI CH/CC, NRPN, MIDI Out

Manual. Clock-synced ducking envelope: each division pulse ducks, then recovers by Release. Depth sets how far. Mute freezes the envelope at its current level (clock triggers discarded). Invert flips duck direction. Third sets division directly; Shift+Short cycles division (CV Out) or CV Dest (CV In). CV Att scales modulation.

ID 30Groovesready

Multi-genre MIDI drum grooves with feel

FADERS	BUTTONS	PARAMS
Main — Density (extra hits) Alt — Genre morph (LED = red→blue spectrum) Third — Feel (0 = flat/grid → max = accents + timing + swing) GENRES - Dub → Disco → House → Techno → Trip-Hop → Hip-Hop → Jungle → UK Garage → Dubstep - Alt LED: continuous spectrum (red→blue); Enum chrome still uses discrete genre colors - Morph: soft-lerp accents/timing/swing between neighbors; core masks from nearer genre - DNA: accent masks + microtiming; swing bias from shared groove module	Short — Reset to downbeat Long — Mute (notes off) Shift+Short — Reverse swing Shift+Long — Toggle jack Any ↔ Stacked (yellow/violet flash) JACK PARAMS - Jack: CV Out / CV In - CV Dest: Density · Feel · Reset (Configurator only) - Range, CV Att	- Kick / Snare / Hats: note + channel - Groove, Swing max % (Feel swing ceiling), GATE %, Color, MIDI Out

Manual. Genre MIDI drums on the global clock. Density reveals fills; Shift+Fader is a continuous genre morph (park between neighbors blends feel DNA; core pattern snaps at midpoint; LED = red→blue spectrum). Button+Fader = **Feel** — attenuates accents, microtiming, and genre swing (capped by Swing max %). Feel bottom ≈ flat equal velocity / straight grid; top = full groove. Shift+Long toggles CV Out Any↔Stacked. Jack=CV In modulates Density/Feel or triggers Reset — set CV Dest in the Configurator only. CV Att scales input.

ID 31Golden Gateready

Fibonacci-spaced gates — ratios → φ

FADERS	BUTTONS	MODE PARAM
Main — Fibonacci depth Alt — Cycle length N Third — Local speed grid (16th → quarter; center = follow Speed param) JACK PARAMS - Jack: CV Out / CV In (In = MIDI-first, no outs) - CV Dest: Depth · Cycle · Reset - Range, CV Att	Short — Reset to downbeat Long — Mute Shift+Short — Reverse gap direction Shift+Long — Cycle Mode (Note/CC/Pitch/Phi)	- Note · CC · Pitch (12-TET) · Phi (φ pitch) - Button color: default / orange / red / pink PARAMS - MIDI CH/Note/CC, GATE %, Speed, Color, MIDI Out

Manual. Fills cycle length N with Fibonacci gaps; deeper sets approach φ. Mode param selects Note/CC/Pitch/Phi; Shift+Long cycles the same on-device. Third overrides Speed locally. Short resets; Shift+Short reverses travel. Jack=CV In drops CV/gate outs and uses Dest for Depth/Cycle/Reset.

FADERS

- **Ch0 Main** — Morph (LED = red→blue spectrum) · **Alt** — Attenuation (Amp)
- **Ch0 Third** — Skew
- **Ch1 Main** — Symmetry · **Alt** — Speed
- **Ch1 Third** — Phase-Warp

CV DESTINATIONS (CH0 SHIFT+SHORT)

- Blue Rate Mod · Pink Phase · Red Reset · Cyan Amp
- Yellow Speed · Orange Morph · Violet Skew
- Green Warp · Rose Symmetry

BUTTONS

- **Ch0 Short** — Freeze toggle (white)
- **Ch0 Long** — In mute
- **Ch0 Shift+Short** — Cycle CV Dest
- **Ch0 Shift+Long** — Cycle Mix Mode
- **Ch1 Short** — Phase reset
- **Ch1 Long** — Out mute
- **Ch1 Shift+Short** — Phase reverse
- **Ch1 Shift+Long** — Clock sync toggle

PARAMS

- Speed, Range, MIDI, Grid Lock
- Mix Mode: Xfade / Min / Max / Sum
- Osc B: Quad / Octave · Mix balance 0–100%
- Rate-mod depth 0–100% (Configurator) · CV Dest can modulate it
- Ch0 jack = CV In · Ch1 jack = CV Out

Manual. Dual-osc morphing LFO. Ch0 Morph/Amp/Skew on CV In; Ch1 Symmetry/Speed/Warp on CV Out. Shift+Short on Ch0 cycles CV Dest. Freeze holds the wave; In-mute silences CV-in; Out-mute silences output. Ch1 Shift+Long toggles clock sync (Grid Lock). Mix balance 0–100% (Xfade only).

FADERS

- **Main** — Delay (up = shorter / faster)
- **Alt** — Feedback
- **Third** — Pitch interval (±24 st)

BUTTONS

- **Short** — Mute / ring-out
- **Long** — Panic (clear queue); skipped if Third used this hold

LEDS

- White flash on MIDI/gate in (~20% when muted)
- Ping-Pong: Top = Out A · Bottom = Out B

PARAMS

- I/O: MIDI→MIDI · MIDI→CV · CV→MIDI
- Delay: ms / Clock · Max delay
- Interval mode: Fixed / Stack / Bounce
- Routing: Single / Ping-Pong
- Signal: Pitch / Gate / CV→CC / Gate→Note
- MIDI In/Out A, Out Pong, CC, Note, Range, Color

Manual. Delay with feedback and optional pitch intervals. I/O picks MIDI/CV routing; Ping-Pong alternates MIDI Out A/B (MIDI→MIDI and CV→MIDI). Mute = ring-out (block new input; queue plays out). Long Panic clears the trail — Third interval edits never panic that hold. MIDI In always flashes white for diagnosis when muted.

FADERS

- **Main** — Evolve / mutation (0 = frozen)
- **Alt** — Texture (density / phrase / swing feel)
- **Third** — Lévy α / flight character

JACK PARAMS

- Jack: CV Out / CV In
- CV Out source (Jack=Out): Pitch · Gate · Velocity
- CV Dest (Jack=In): Evolve · Texture · Reroll
- Range, CV Att · V/Oct · Bypass quantizer

BUTTONS

- **Short** — Reroll note pool (+ reset)
- **Long** — Mute
- **Shift+Short (CV Out)** — Cycle CV Out source
- **Shift+Short (CV In)** — Reverse playback
- **Shift+Long** — Cycle octave span 1→2→3→4

OCTAVE LED

- Blue · Cyan · Yellow · Red

PARAMS

- MIDI CH, Base Note, Color, MIDI Out
- CV pitch + MIDI (dual path)

Manual. Generative arp whose pool evolves with Lévy-flight mutations. Main bottom freezes; raise to wander. Texture shapes phrase density/length; Third sets flight character (α). Shift+Long walks octave span (button color). Jack=CV Out: Shift+Short cycles Pitch/Gate/Velocity. Jack=CV In: Shift+Short reverses; CV modulates Evolve/Texture or fires Reroll.

FADERS

- **Main (Perform)** — Scrub genre degrees × 3 octaves (pitch map)
- **Main (Auto)** — Tension (Meander only)
- **Alt** — Genre morph (+ Capture clip slot if clip exists; Capture LED = rose)
- **Third (Auto)** — Feel (laid ↔ advanced stab length)
- **Third (Perform)** — Feel still stored; LEDs = blue / chord pitch

JACK PARAMS

- Jack: CV Out / CV In
- CV Dest: Macro · Panic
- Range, V/Oct, CV Att

BUTTONS

- **Perform hold** — Chord on; release = off (blue LEDs track pitch)
- **Auto short** — Play / pause
- **Shift+Short (Perform)** — Capture last N bars → Auto+Play
- **Shift+Short (Auto)** — Return to Perform
- **Auto Long** — Clear clip, reseed genre phrase
- **Shift+Long (Auto)** — Panic

PARAMS

- Root, Scale, Genre, Voicing, Velocity
- Auto style: Repeat / Meander
- Start mode: Perform / Auto
- Capture: 16 / 8 / 4 / 2 / 1 bars
- LED: Perform = app color; Auto = orange; Hold Auto = rose (phrase pos)

SCENE STORAGE

- 8-slot vamp + Capture clip
- **Swing** 0–100 — morphs between neighbor genre biases while parked; reseeds structure only on nearest-genre change
- Feel, scrub, tension, mode, play/pause

Manual. MIDI chord vamp with optional CV jack. **Perform:** fader = genre-unique degrees ascending across ~3 octaves; hold plays the chord (blue = pitch). **Shift+Short** captures recent harmony (starts quantized to 16ths, lead-in cropped to first hit; hold lengths free) into a timed clip and arms Auto. **Auto:** genre rhythm phrase loops — multi-chord statement (~1–2 bars) then multi-bar rest; harmony Repeat or Meander; Feel sets short stab gate (rests fixed); Swing delays odd 16ths — Shift+Fader morphs swing bias between neighbors without reseeding; crossing the midpoint reseeds phrase/slots once. Alt LED = red→blue spectrum (Capture slot stays rose). Short = play/pause; Long clears clip / reseeds; Shift+Short → Perform. CV Macro = scrub/tension; Panic from CV optional.