

Faderpunk WIP Apps — UX Cheatsheet

Synced to test/playground (CV Jack In/Out) · 31 Jul 2026 · A4 print · Hold Sam 36 · Harmonica 37

Main — Fader alone	Alt — Shift + Fader	Third — Channel button held + Fader
Short — Tap button	Long — Hold button (long-press)	Shift+... — Global Shift + gesture

Jack CV Out / CV In (Heat Pump, Grooves, Golden Gate, Arp de Lévy, Chord Vamp, Harmonica; Super LFO is 2-ch with CV on Ch0): **CV Out** = app drives the jack · **CV In** = jack modulates a **CV Dest** (attenuated by **CV Att** 0–100%). Device-cycle Dest: Heat Pump & Super LFO via **Shift+Short** (Grooves: Configurator only). Golden Gate + Jack=CV In → MIDI-first (no CV/gate outs).

ID 29Heat Pumpready

Clock-synced sidechain ducking envelope

FADERS	BUTTONS	LEDS / OTHER PARAMS
Main — Release (up = faster recovery) Alt — Duck depth (red LED) Third — Clock division (1/1 ... 1/32) JACK PARAMS - Jack: CV Out / CV In - CV Dest: Depth · Release · Duck - Dest colors: Red · Yellow · Cyan - CV Att 0–100%	Short — Manual duck trigger Long — Mute (freeze level; no snap to idle) Shift+Short (CV In) — Cycle CV Dest (flash) Shift+Long — Invert duck direction	- Button metronome Mid→Low per division 1/1 uses Color param - Invert: white ↔ off fade - Color, Range, MIDI CH/CC, NRPN, MIDI Out

Manual. Clock-synced sidechain duck: each division pulse drops to Depth, holds ~⅓ of the division, then log-shaped Release back to idle. Mute freezes the envelope (clock triggers discarded). Invert flips duck direction. Third (button+fader) sets division; Shift+Short cycles CV Dest when Jack=CV In. CV Att scales modulation.

ID 30Groovesready

Multi-genre MIDI drum grooves with feel

FADERS	BUTTONS	PARAMS
Main — Density (extra hits) Alt — Genre morph (LED = red→blue spectrum) Third — Feel (0 = flat/grid → max = accents + timing + swing) GENRES - Dub → Disco → House → Techno → Trip-Hop → Hip-Hop → Jungle → UK Garage → Dubstep - LEDs always follow genre spectrum (no Color param); Enum chrome still discrete - Morph: soft-lerp accents/timing/swing between neighbors; core masks from nearer genre - DNA: accent masks + microtiming; swing bias from shared groove module	Short — Reset to downbeat Long — Mute (notes off) Shift+Short — Reverse swing Shift+Long — Toggle jack Any ↔ Stacked (yellow/violet flash) LEDS - Button / Top / Bottom = genre hue (red→blue spectrum) - Button Mid→Low blink on each hit JACK PARAMS - Jack: CV Out / CV In - CV Dest: Density · Feel · Reset (Configurator only) - Range, CV Att	- Kick / Snare / Hats: note + channel - Groove, Swing max % (Feel swing ceiling), GATE %, MIDI Out

Manual. Genre MIDI drums on the global clock. Density reveals fills; Shift+Fader is a continuous genre morph (park between neighbors blends feel DNA; core pattern snaps at midpoint). Button / bar LEDs always use the genre spectrum hue (like LFO has no Color param). Button Mid→Low blinks on hits. Button+Fader = **Feel** — attenuates accents, microtiming, and genre swing (capped by Swing max %). Feel bottom ≈ flat equal velocity / straight grid; top = full groove. Shift+Long toggles CV Out Any↔Stacked. Jack=CV In modulates Density/Feel or triggers Reset — set CV Dest in the Configurator only. CV Att scales input.

ID 31Golden Gateready

Fibonacci-spaced gates — ratios → φ

FADERS	BUTTONS	MODE PARAM
Main — Fibonacci depth Alt — Cycle length N Third — Local speed grid (16th → quarter; center = follow Speed param) JACK PARAMS - Jack: CV Out / CV In (In = MIDI-first, no outs) - CV Dest: Depth · Cycle · Reset - Range, CV Att	Short — Reset to downbeat Long — Mute Shift+Short — Reverse gap direction Shift+Long — Cycle Mode (Note/CC/Pitch/Phi)	- Note · CC · Pitch (12-TET) · Phi (φ pitch) - Button color: default / orange / red / pink PARAMS - MIDI CH/Note/CC, GATE %, Speed, Color, MIDI Out

Manual. Fills cycle length N with Fibonacci gaps; deeper sets approach φ. Mode param selects Note/CC/Pitch/Phi; Shift+Long cycles the same on-device. Third overrides Speed locally. Short resets; Shift+Short reverses travel. Jack=CV In drops CV/gate outs and uses Dest for Depth/Cycle/Reset.

FADERS

- **Ch0 Main** — Morph (LED = red→blue spectrum) · **Alt** — Attenuation (Amp)
- **Ch0 Third** — Skew
- **Ch1 Main** — Symmetry · **Alt** — Speed
- **Ch1 Third** — Phase-Warp

CV DESTINATIONS (CH0 SHIFT+SHORT)

- Blue Rate Mod · Pink Phase · Red Reset · Cyan Amp
- Yellow Speed · Orange Morph · Violet Skew
- Green Warp · Rose Symmetry

BUTTONS

- **Ch0 Short** — Freeze toggle (white)
- **Ch0 Long** — In mute
- **Ch0 Shift+Short** — Cycle CV Dest
- **Ch0 Shift+Long** — Cycle Mix Mode
- **Ch1 Short** — Phase reset
- **Ch1 Long** — Out mute
- **Ch1 Shift+Short** — Phase reverse
- **Ch1 Shift+Long** — Clock sync toggle

PARAMS

- Speed, Range, MIDI, Grid Lock
- Mix Mode: Xfade / Min / Max / Sum
- Osc B: Quad / Octave · Mix balance 0–100%
- Rate-mod depth 0–100% (Configurator) · CV Dest can modulate it
- Ch0 jack = CV In · Ch1 jack = CV Out

Manual. Dual-osc morphing LFO. Ch0 Morph/Amp/Skew on CV In; Ch1 Symmetry/Speed/Warp on CV Out. Shift+Short on Ch0 cycles CV Dest. Freeze holds the wave; In-mute silences CV-in; Out-mute silences output. Ch1 Shift+Long toggles clock sync (Grid Lock). Mix balance 0–100% (Xfade only).

FADERS

- **Main** — Delay (up = shorter / faster)
- **Alt** — Feedback
- **Third** — Pitch interval (±24 st)

BUTTONS

- **Short** — Mute / ring-out
- **Long** — Panic (clear queue); skipped if Third used this hold

LEDS

- White flash on MIDI/gate in (~20% when muted)
- Ping-Pong: Top = Out A · Bottom = Out B

PARAMS

- I/O: MIDI→MIDI · MIDI→CV · CV→MIDI
- Delay: ms / Clock · Max delay
- Interval mode: Fixed / Stack / Bounce
- Routing: Single / Ping-Pong
- Signal: Pitch / Gate / CV→CC / Gate→Note
- MIDI In/Out A, Out Pong, CC, Note, Range, Color

Manual. Delay with feedback and optional pitch intervals. I/O picks MIDI/CV routing; Ping-Pong alternates MIDI Out A/B (MIDI→MIDI and CV→MIDI). Mute = ring-out (block new input; queue plays out). Long Panic clears the trail — Third interval edits never panic that hold. MIDI In always flashes white for diagnosis when muted.

FADERS

- **Main** — Evolve / mutation (0 = frozen)
- **Alt** — Texture (density / phrase / swing feel)
- **Third** — Lévy α / flight character

JACK PARAMS

- Jack: CV Out / CV In
- CV Out source (Jack=Out): Pitch · Gate · Velocity
- CV Dest (Jack=In): Evolve · Texture · Reroll
- Range, CV Att · V/Oct · Bypass quantizer

BUTTONS

- **Short** — Reroll note pool (+ reset)
- **Long** — Mute
- **Shift+Short (CV Out)** — Cycle CV Out source
- **Shift+Short (CV In)** — Reverse playback
- **Shift+Long** — Cycle octave span 1→2→3→4

OCTAVE LED

- Blue · Cyan · Yellow · Red

PARAMS

- MIDI CH, Base Note, Color, MIDI Out
- CV pitch + MIDI (dual path)

Manual. Generative arp whose pool evolves with Lévy-flight mutations. Main bottom freezes; raise to wander. Texture shapes phrase density/length; Third sets flight character (α). Shift+Long walks octave span (button color). Jack=CV Out: Shift+Short cycles Pitch/Gate/Velocity. Jack=CV In: Shift+Short reverses; CV modulates Evolve/Texture or fires Reroll.

FADERS

- **Main (Perform)** — Scrub genre degrees × 3 octaves (pitch map)
- **Main (Auto)** — Tension (Meander only)
- **Alt** — Genre morph (+ Capture clip slot if clip exists; Capture LED = rose)
- **Third (Auto)** — Feel (laid ↔ advanced stab length)
- **Third (Perform)** — Feel still stored; LEDs = blue / chord pitch

JACK PARAMS

- Jack: CV Out / CV In
- CV Dest: Macro · Panic
- Range, V/Oct, CV Att

BUTTONS

- **Perform hold** — Chord on; release = off (blue LEDs track pitch)
- **Auto short** — Play / pause
- **Shift+Short (Perform)** — Auto (capture if ring has chords)
- **Shift+Short (Auto)** — Return to Perform
- **Auto Long** — Clear clip, reseed genre phrase
- **Shift+Long (Auto)** — Panic

PARAMS

- Root, Scale, Genre, Voicing, Velocity
- Auto style: Repeat / Meander
- Start mode: Perform / Auto
- Capture: 16 / 8 / 4 / 2 / 1 bars
- LED: Perform = app color; Auto = orange; Hold Auto = rose (phrase pos)

SCENE STORAGE

- 8-slot vamp + Capture clip
- **Swing** 0–100 — morphs between neighbor genre biases while parked; reseeds structure only on nearest-genre change
- Feel, scrub, tension, mode, play/pause

Manual. MIDI chord vamp with optional CV jack. **Perform:** fader = genre-unique degrees ascending across ~3 octaves; hold plays the chord (blue = pitch). **Shift+Short** enters Auto (and captures recent harmony into a timed clip when the ring has chords; empty ring = genre phrase Auto). **Auto:** genre rhythm phrase loops — multi-chord statement (~1–2 bars) then multi-bar rest; harmony Repeat or Meander; Feel sets short stab gate (rests fixed); Swing delays odd 16ths — Shift+Fader morphs swing bias between neighbors without reseeding; crossing the midpoint reseeds phrase/slots once. Alt LED = red→blue spectrum (Capture slot stays rose). Short = play/pause; Long clears clip / reseeds; Shift+Short → Perform. CV Macro = scrub/tension; Panic from CV optional.

FADERS

- **Main (Note)** — Gate length (% of current division)
- **Main (CC)** — Output amount (sample → CC)
- **Alt** — Clock division
- **Third (Note)** — Velocity sensitivity from CV delta
- **Third (CC)** — unused

JACK

- CV In — signal to sample (pitch / CC source)
- Config Attenuverter applied before sample

BUTTONS

- **Short** — Soft mute (ausklingen; no new events)
- **Shift+Short** — Manual sample (+ Note/CC)
- **Long (no fader move)** — Hard Note Off + mute on
- **Long + Fader** — Third layer only (no panic)

TRANSPORT

- **Stop** — like soft mute; gate finishes via timer
- **Reset** — phase only; sample/note kept
- Always retrigger on tick (even same pitch); monophonic cut

PARAMS

- MidiMode Note/CC, Channel, CC #, Color
- Range, MidiOut, V/Oct, Bypass quantizer
- Attenuverter (0–4095, 4095 = unity)
- Base Velocity 1–127

LEDS

- Button = app color (off when muted)
- Top = note/CC activity (velocity brightness)
- Bottom = active latch value (Main/Alt/Third)

Manual. Clocked S&H bridge: each division tick samples CV In (after Config Att) and sends MIDI. Note mode: cut+retrigger with $vel = base + sens \times | \Delta CV |$; Main = gate % of the division. CC mode: Main = amount. Soft mute and Stop let the sounding note finish; Long without fader move is panic. Shift+Short samples off the clock. Global clock source (Internal / MIDI / one Aux); Aux divisions are just patchable outs into the jack if you want.

FADERS

- **Main** — Chord type (Unison → Power → min → maj → Sus4 → min7 → Dom7)
- **Alt** — Voicing spread (lift harmony in octave steps)
- **Third** — Harmony velocity (root keeps input vel)

JACK

- MIDI→CV: highest sounding pitch out
- CV→MIDI: root pitch in (stable before arm/play)
- MIDI→MIDI: unused

BUTTONS

- **Short** — Mute harmony only (root keeps sounding)
- **Shift+Short** — Cycle harmony octave –1 → 0 → +1
- **Long** — Panic (all notes this app owns)
- **Long + Fader** — Third layer only (no panic)

I/O

- MIDI→MIDI / MIDI→CV / CV→MIDI
- Templates chromatic; non-root tones snap to global scale (bypass = chromatic)
- Live revoice as fader moves

PARAMS

- I/O, Range, Color
- MIDI In / In CH / Out / Out CH
- 1V/Oct, Bypass quantizer

LEDS

- Top = chord type / pitch (red on Alt or Third)
- Bottom = octave (–1 dim, 0 mid, +1 bright); velocity on Third

Manual. Builds a chord from a single root. Fader picks chord type; Alt opens the voicing; Third sets harmony velocity. Mute affects harmony only. Shift+Short cycles harmony octave. CV→MIDI waits for a stable quantized pitch (anti-float) before arming, then plays on change. Long panics every note this app owns.