

Faderpunk WIP Apps — UX Cheatsheet

Synced to test/p/layground (IDs 29–42) · 9 Aug 2026 · A4 print

Main — Fader alone	Alt — Shift + Fader	Third — Channel button held + Fader
Short — Tap button	Long — Hold button (long-press)	Shift+... — Global Shift + gesture

Jack CV Out / CV In (Heat Pump, Grooves, Golden Gate, Arp de Lévy, Chord Vamp, Echolot, Loop de Cay; Super LFO is 2-ch with CV on Ch0):
CV Out = app drives the jack · **CV In** = jack modulates a **CV Dest** (attenuated by **CV Att** 0–100% where present). Device-cycle Dest: Heat Pump & Super LFO via **Shift+Short** (Grooves: Configurator only). Golden Gate + Jack=CV In → MIDI-first (no CV/gate outs).

ID 29Heat Pumpready

Clock-synced sidechain ducking envelope

FADERS	BUTTONS	LEDS / OTHER PARAMS
Main — Release (up = faster recovery) Alt — Duck depth (red LED) Third — Clock division (1/1 ... 1/32) JACK PARAMS - Jack: CV Out / CV In - CV Dest: Depth · Release · Duck - Dest colors: Red · Yellow · Cyan - CV Att 0–100%	Short — Manual duck trigger Long — Mute (freeze level; no snap to idle; dim red button) Shift+Short (CV Out) — Cycle clock division Shift+Short (CV In) — Cycle CV Dest (flash) Shift+Long — Invert duck direction	- Button metronome Mid→Low per division · Mute = dim red (not off) 1/1 uses Color param - Invert: white ↔ off fade - Color, Range, MIDI CH/CC, NRPN, MIDI Out

Manual. Clock-synced ducking envelope: each division pulse ducks, then recovers by Release. Depth sets how far. Mute freezes the envelope at its current level (clock triggers discarded). Invert flips duck direction. Third sets division directly; Shift+Short cycles division (CV Out) or CV Dest (CV In). CV Att scales modulation.

ID 30Groovesready

Multi-genre MIDI drum grooves with swing

FADERS	BUTTONS	PARAMS / LEDS
Main — Density (extra hits) Alt — Genre scrub (same colors as Chord Vamp) Third — Swing (capped by Swing max %) GENRES - Dub → Disco → House → Techno → Trip-Hop → Hip-Hop → Jungle → UK Garage → Dubstep - Colors (shared w/ Vamp): Orange · Yellow · Pink · Cyan · Violet · Red · Lime · Green · Blue - Alt scrub LEDS: continuous IR→UV spectrum (not discrete genre chrome)	Short — Reset to downbeat Long — Mute (notes off) Shift+Short — Reverse swing Shift+Long — Toggle jack Any ↔ Stacked (yellow/violet flash) JACK PARAMS - Jack: CV Out / CV In - CV Dest: Density · Swing · Reset (Configurator only) - Range, CV Att	- Kick / Snare / Hats: note + channel - Groove, Swing max %, GATE %, Color, MIDI Out Button Main: genre hue sat half→full (density) + bar lightness; hit dips kick –50% / snare –30% / hats –10% Button Third: White→Color→Red (swing); same voice-weighted hit dips Button Alt: committed genre hue (Top/Bottom = live fader meters; color changes only after latch pickup)

Manual. Genre MIDI drums on the global clock (9 shared genres with Chord Vamp, including Jungle). Density reveals hits; Shift+Fader scrubs genre on the shared axis — button hue follows the latched genre (meters show live fader until pickup); Button+Fader = Swing (capped by Swing max %). Watch the button: Main density ramps genre hue from half→full saturation with bar lightness; hits dim by voice (kick –50%, snare –30%, hats –10%) — not a clock blink. MIDI fires outside the clock subscriber (pending_* isolate). Third swing blends White→app→Red. Shift+Long toggles CV Out Any↔Stacked. Jack=CV In modulates Density/Swing or triggers Reset — set CV Dest in the Configurator only. CV Att scales input.

ID 31Golden Gateready

Fibonacci-spaced gates — ratios → φ

FADERS	BUTTONS	MODE PARAM
Main — Fibonacci depth Alt — Cycle length N Third — Local speed grid (16th → quarter; center = follow Speed param) JACK PARAMS - Jack: CV Out / CV In (In = MIDI-first, no outs) - CV Dest: Depth · Cycle · Reset - Range, CV Att	Short — Reset to downbeat Long — Mute Shift+Short — Reverse gap direction Shift+Long — Cycle Mode (Note/CC/Pitch/Phi)	- Note · CC · Pitch (12-TET) · Phi (φ pitch) - Button color: default / orange / red / pink PARAMS - MIDI CH/Note/CC, GATE %, Speed, Color, MIDI Out

Manual. Fills cycle length N with Fibonacci gaps; deeper sets approach φ. Mode param selects Note/CC/Pitch/Phi; Shift+Long cycles the same on-device. Third overrides Speed locally. Short resets; Shift+Short reverses travel. Jack=CV In drops CV/gate outs and uses Dest for Depth/Cycle/Reset.

FADERS

- **Ch0 Main** — Morph · **Alt** — Attenuation (Amp)
- **Ch0 Third** — Skew
- **Ch1 Main** — Symmetry · **Alt** — Speed
- **Ch1 Third** — Phase-Warp

CV DESTINATIONS (CH0 SHIFT+SHORT)

- Blue Rate Mod · Pink Phase · Red Reset · Cyan Amp
- Yellow Speed · Orange Morph · Violet Skew
- Green Warp · Rose Symmetry

BUTTONS

- **Ch0 Short** — Freeze toggle (white)
- **Ch0 Long** — In mute
- **Ch0 Shift+Short** — Cycle CV Dest
- **Ch0 Shift+Long** — Cycle Mix Mode
- **Ch1 Short** — Phase reset
- **Ch1 Long** — Out mute
- **Ch1 Shift+Short** — Phase reverse
- **Ch1 Shift+Long** — Clock sync toggle

PARAMS

- Speed, Range, MIDI, Grid Lock
- Mix Mode: Xfade / Min / Max / Sum
- Osc B: Quad / Octave · Mix balance 0–100%
- Rate-mod depth 0–100% (Configurator) · CV Dest can modulate it
- Ch0 jack = CV In · Ch1 jack = CV Out

Manual. Dual-osc morphing LFO. Ch0 Morph/Amp/Skew on CV In; Ch1 Symmetry/Speed/Warp on CV Out. Shift+Short on Ch0 cycles CV Dest. Freeze holds the wave; In-mute silences CV-in; Out-mute silences output. Ch1 Shift+Long toggles clock sync (Grid Lock). Mix balance 0–100% (Xfade only).

FADERS

- **Main** — Delay (up = shorter / faster)
- **Alt** — Feedback
- **Third** — Pitch interval (±24 st)

BUTTONS

- **Short** — Mute / ring-out
- **Long** — Panic (clear queue); skipped if Third used this hold

LEDS

- White flash on MIDI/gate in (~20% when muted)
- Ping-Pong: Top = Out A · Bottom = Out B

PARAMS

- I/O: MIDI→MIDI · MIDI→CV · CV→MIDI
- Delay: ms / Clock · Max delay
- Interval mode: Fixed / Stack / Bounce
- Routing: Single / Ping-Pong
- Signal: Pitch / Gate / CV→CC / Gate→Note
- MIDI In/Out A, Out Pong, CC, Note, Range, Color

Manual. Delay with feedback and optional pitch intervals. I/O picks MIDI/CV routing; Ping-Pong alternates MIDI Out A/B (MIDI→MIDI and CV→MIDI). Mute = ring-out (block new input; queue plays out). Long Panic clears the trail — Third interval edits never panic that hold. MIDI In always flashes white for diagnosis when muted.

FADERS

- **Main** — Evolve / mutation (0 = frozen)
- **Alt** — Texture (density / phrase / swing feel)
- **Third** — Lévy α / flight character

JACK PARAMS

- Jack: CV Out / CV In
- CV Out source (Jack=Out): Pitch · Gate · Velocity
- CV Dest (Jack=In): Evolve · Texture · Reroll
- Range, CV Att · V/Oct · Bypass quantizer

BUTTONS

- **Short** — Reroll note pool (+ reset)
- **Long** — Mute
- **Shift+Short (CV Out)** — Cycle CV Out source
- **Shift+Short (CV In)** — Reverse playback
- **Shift+Long** — Cycle octave span 1→2→3→4

OCTAVE LED

- Blue · Cyan · Yellow · Red

LEDS

- **Button / Top** — latch hue + level: Main = Color/Evolve · Alt = Orange/Texture · Third = Violet/ α ; mute = off
- **Bottom** — Pitch height in Color while gated (note activity)

PARAMS

- MIDI CH, Base Note, Color, MIDI Out
- CV pitch + MIDI (dual path)

Manual. Generative arp whose pool evolves with Lévy-flight mutations. Main bottom freezes; raise to wander. Texture shapes phrase density/length; Third sets flight character (α). Shift+Long walks octave span (button color). Jack=CV Out: Shift+Short cycles Pitch/Gate/Velocity. Jack=CV In: Shift+Short reverses; CV modulates Evolve/Texture or fires Reroll.

FADERS

- **Main (Perform)** — Scrub genre degrees × 3 octaves (pitch map)
- **Main (Auto)** — Tension (Meander only)
- **Alt** — Genre (+ Capture clip slot if clip exists)
- Shared axis: Dub → Disco → House → Techno → Trip-Hop → Hip-Hop → Jungle → UK Garage → Dubstep
- **Third (Auto)** — Feel (laid ↔ advanced stab length)
- **Third (Perform)** — Feel still stored; LEDs = blue / chord pitch

JACK PARAMS

- Jack: CV Out / CV In
- CV Dest: Macro · Panic
- Range, V/Oct, CV Att

BUTTONS

- **Perform hold** — Chord on; release = off (blue LEDs track pitch)
- **Auto short** — Play / pause
- **Shift+Short (Perform)** — Capture last N bars → Auto+Play
- **Shift+Short (Auto)** — Return to Perform
- **Auto Long** — Clear clip, reseed genre phrase
- **Shift+Long (Auto)** — Panic

PARAMS

- Root, Scale, Genre, Voicing, Velocity
- Auto style: Repeat / Meander
- Start mode: Perform / Auto
- Capture: 16 / 8 / 4 / 2 / 1 bars
- LED: Perform = app color; Auto = orange; Hold Auto = rose (phrase pos)

SCENE STORAGE

- 8-slot vamp + Capture clip
- **Swing** 0–100 — genre-seeded; odd-16th delay (no Configurator param)
- Feel, scrub, tension, mode, play/pause

Manual. MIDI chord vamp with optional CV jack. Shared 9-genre axis with Grooves (Dub→...→Jungle→...→Dubstep). **Perform:** fader = genre-unique degrees ascending across ~3 octaves; hold plays the chord (blue = pitch). **Shift+Short** captures recent harmony (starts quantized to 16ths, lead-in cropped to first hit; hold lengths free) into a timed clip and arms Auto. **Auto:** genre rhythm phrase loops — multi-chord statement (~1–2 bars) then multi-bar rest; harmony Repeat or Meander; Feel sets short stab gate (rests fixed); Swing (scene, genre-seeded) delays odd 16ths on Auto + Capture. Short = play/pause; Long clears clip / reseeds; Shift+Short → Perform. Alt = genre (+ Capture slot). CV Macro = scrub/tension; Panic from CV optional.

FADERS

- **Main** — Gate % (Note) or CC amount (CC mode)
- **Alt** — Clock division
- **Third** — Velocity / sensitivity

BUTTONS

- **Short** — Play / trigger held sample
- **Shift+Short** — Manual sample (capture now)
- **Long** (no fader move) — Soft mute (fade; no hard note-off)

PARAMS / LEDS

- Mode Note / CC, MIDI CH/CC, Color, Range, V/Oct
- Layer meters: IR→UV spectrum on Main/Alt/Third fader
- White flash on each sample; mute = red button

Manual. Clocked sample-and-hold. Capture on division or Shift+Short; Main shapes gate length or CC depth. Long soft-mutes so notes can ring out. Third sets how strongly velocity follows the sample.

FADERS

- **Main** — Chord type
- **Alt** — Spread / voicing width
- **Third** — Velocity

BUTTONS

- **Short** (no fader move) — Mute / unmute all voices
- **Alt+Short** — Cycle harmony octave (–1 / 0 / +1)
- **Alt+Long** — Step voicing preset

PARAMS

- I/O: MIDI / CV root; MIDI In/Out CH
- CV Gate: Sustain · ms · clock divisions
- Strum (ms), Color, Range, V/Oct
- Near-0V CV = rest; unpatched stays silent until stable pitch
- LEDs: IR→UV spectrum per layer; mute = red; preset flash on Alt+Long

Manual. One root (last MIDI note or pitch CV) picks the chord root; fader picks chord type; up to four MIDI voices (MIDI→CV follows highest). Not a polyphonic keyboard. Mute is a short tap; use Third (button+fader) for velocity so mute and vel don't collide. Alt+Long walks voicing presets.

FADERS

- **Main** — Pitch (span from Base Note); spectrum LED meter
- **Alt** (Shift+Fader) — Decay strength: bottom = immortal, top ≈ 4 wraps (violet→red)
- **Third** (Btn+Fader; gate modes while muted) — Decay mode zones (IR→UV): Random Rose · Pitch Up Orange · Pitch Down Yellow · Vel+Root Lime · Pitch Root Cyan · Velocity Blue · Gate Violet

BUTTONS

- **Hold** (gate modes) — Note on; release = off (long notes OK)
- **Shift+Short** — Cycle loop length 1→2→...→8 bars (amber→cyan flash)
- **Shift+Long** — Mute (red LED; decay pauses)
- **Short while muted** — Unmute (re-arms)
- **Shift+Long while muted** — Erase buffer (white flash)

PARAMS / LEDS

- Mode: Pitch→MIDI · Gate→MIDI · MIDI→MIDI · MIDI→CV · Fader→Both
- Decay Mode: Random · Pitch Up · Pitch Down · Vel+Root (default) · Pitch Root · Velocity · Gate
- MIDI CH / In / Out, Base Note, Span (semitones across fader)
- Color, Range, V/Oct
- Capture/playback hit: sharp button 80% dim (~2 PPQN) + Top white; layer meters on Top/Bottom/Button

Manual. Clocked overdub loop: play while armed to capture; each wrap applies Alt strength through the selected Decay Mode (0 = freeze forever). Pitch modes stay on the global scale. Random jitters scale pitch and only lowers velocity. Gate shortens duration toward a 16th floor. Hold the button for long notes — mute is Shift+Long. Length is Shift+Short (1–8 bars), not Alt/Third. Third picks Decay Mode (Configurator sync). Quantized to 16ths.

FADERS

- **Main** — Attenuverter −100...+100 % (center deadband = 0)
- **Alt** (Shift+Fader) — Offset −100...+100 %
- **Third** (hold button + fader) — Slew 0...10 s

BUTTONS

- **Short click** (no fader move) — Mute toggle on release (sends Output Min)
- **Hold + fader** — edit Slew (suppresses mute)
- **Shift+Hold** — momentary Bypass (keeps Range / Min-Max / Rate)

PARAMS / LEDS

- Pipeline: Gate/CV → Att → Offset → Transfer → Slew → Steps → Min/Max → Rate
- Button LED only: Main = app color × out; Alt = red × [offset]; Third = cyan × slew (floor so hue stays visible at 0)
- Mute = off · Bypass = full · black blink on downbeat while out > Min

Manual. 1-channel CV→MIDI sculptor. Defaults are transparent (+100 % att, 0 offset, 0 slew, Linear, full CC window, 100 Hz). Gate mode runs a Schmitt threshold (0.1 V hysteresis) then the same pipeline. Mute sends Output Min once and goes silent; unmute resends the live value. Watch the button LED for level — fader LEDs stay dark. Uses clock ticker only (no CLOCK_PUBSUB). No clock → no downbeat blink.

FADERS

- **Main** — F0 pulses A · F1 pulses B (density; absolute pulse count, Bjorklund redistributes)
- **Alt** (Shift) — F0 Extent (melodic span 0–24 st from Note A) · F1 Interval (0–12 st above the line for Ch2)
- **Third** (Btn1 or Btn2 hold) — F0 length A · F1 length B (2–32; independent)
- Rotation fixed at 0 (slots freed for Extent / Interval)
- **Division** (config) — note values 1/1 ... 1/192 (default 1/16)

BUTTONS

- **Btn1 or Btn2 hold** — Third (length A/B on F0/F1)
- **Btn2 tap** (no fader move) — Mute both outs
- **Shift+Btn1** — Cycle Logic OR → AND → XOR → Accnt
- **Shift+Btn2** — Toggle post-logic invert (shadow); white↔none fade like Heat Pump

MELODY / LEDS

- Note A (config) = root; each Length-A step maps into 0...Extent semitones; Ch2 = same line + Interval
- Extent 0 = monotone Note A; higher = wider ascending line through the A cycle
- Division (note values), GATE %, Prob %, Humanize (Vel jitter; 0 = fixed max), MIDI CH / Note A / Interval B / Out, Color
- Color = App Color on Btn1; Btn0 = Logic hue; Top A/B = App Color / complement (layer hits)
- Main Btn: logic / app color · density bright · soft hit dip
- Alt: Top+Btn dim→sat ∝ Extent / Interval (fixed hues) · Third: shortest hue btn→complement ∝ length
- Top flashes = layer hits (Main) · Bottom flashes = logic outs (Main)
- Jack0 = logic result + melodic line · Jack1 coupled (OR→∩, AND→△, XOR→∩, Accnt→accent) + Interval

Manual. Two independent Euclidean masks combined with boolean logic — the OXI GEN dual-layer idea without pitch. Color sets Layer A; Layer B LEDs use a fixed complement (always the same pairs). Btn1 shows logic mode, not Color. Different lengths per layer enable polyrhythmic XOR/AND patterns Euclid cannot make alone. Needs clock. Prob % < 100 adds optional flakiness; 100 is fully deterministic. No pitch CV (use GenSeq for that).

FADERS

- **Main** — Density (extra onsets + freer degrees)
- **Alt** — Genre scrub (shared axis with Grooves / Chord Vamp)
- **Third** — Feel / Groove (swing · microtiming · velocity · ghosts · gate; capped by Groove max %)

GENRES

- Dub → Disco → House → Techno → Trip-Hop → Hip-Hop → Jungle → UK Garage → Dubstep
- Alt scrub LEDs: continuous IR→UV spectrum (shared palette)

BUTTONS

- **Short** — Reset to downbeat
- **Long** — Mute (notes off)
- **Shift+Short** — Reverse swing
- **Shift+Long** — Cycle Voice (historical era order; flash = voice color)

JACK PARAMS

- Jack: CV Out (pitch V/Oct) / CV In
- CV Dest: Density · Feel · Reset (Configurator)
- Range, V/Oct, CV Att

VOICES / LEDS

- Order = historical era: bebop → Motown → P-Funk → fusion → dub duo → alt-funk → quirk
- **Mingus** Violet — chromatic neighbors
- **Jamerson** Orange — pocket root/fifth
- **Bootsy** Pink — funk ghosts + octave drops
- **Jaco** Cyan — melodic approaches + leaps
- **Robbie** Green — dub pocket, sustained / sparse
- **Flabba** Lime — roots walk, roomy gates
- **Flea** Red — staccato + aggressive jumps
- **Claypool** Yellow — quirky leaps + chromatic nudges
- Button: genre hue in play; Shift+Long flash = voice color; hits duck Mid→Low

Manual. Genre MIDI bass on the global clock (9 shared genres with Grooves / Chord Vamp). Density reveals fill hits and freer scale degrees; Alt scrubs genre on the shared spectrum axis; Third is Feel / Groove (swing, microtiming, velocity contrast, ghost drag, gate character — depth capped by Groove max %). Notes sustain across empty 16ths until the next hit (legato when the pitch repeats). Phrases are 8 bars in AA B A' form: the rhythmic motif repeats, harmony walks the tropes, bars 5–6 answer (shifted), bar 7 ornaments, bar 8 breathes. Shift+Long cycles bassist Voice personas in historical era order (Mingus → Jamerson → Bootsy → Jaco → Robbie → Flabba → Flea → Claypool; button flash = voice color). Short resets to the downbeat; Long mutes. CV Out is pitch (V/Oct); CV In modulates Density / Feel or triggers Reset. MIDI note-ons fire outside the clock subscriber (pending_↖ isolate), same pattern as Grooves.

FADERS	BUTTONS	SCALE SETS / LEDS
• Main — interval width (stepwise ↔ wide leaps; aggressive curve) • Alt (Shift) — phrase length only (3–28 steps) • Third (Btn hold) — note density (sparse rests ↔ continuous)	• Short — mute / unmute • Shift+short — previous scale set • Long — next scale set • Shift+long — octave span 1→2→3→4	• Flat list of named 12-TET sets (Ionian...Folk) — conventional interval-pattern labels, not cultural claims • Follow device tonic (default on); Follow device scale uses the global Key mask instead of the selected set • Per-set melodic feel (contour / leap / sustain) — expressivity is not a fader • Button hue cycles by scale index · Top = gate · Bottom = pitch height · Division via config (default 1/16)

Manual. # Contura Generates melodic contour phrases over selectable 12-TET pitch-class sets, anchored to the device quantizer tonic. Scale-set names are conventional labels for interval patterns (Western modes and other named collections on equal footing). They are not claims about living musical practice or authentic intonation. Needs a running clock. Pitch CV on the channel jack; gates via MIDI note on/off. Phrases mix short, medium, and longer note lengths.

Source: test/playground app sources · pool_size often 4 on heavy WIP apps (playground).