GND HOST

VDD HOST

RX (OUT)

DIRECTION

TX (IN)

B

A

VDD BUS

GND BUS