## Goals for Week 1

- 1. Watch the Electrical Safety Videos
- 2. Identify a laboratory partner and add your names to the Laboratory Teams sign-up sheet
- 3. install Matlab® on your laptop
- 4. Install Waveforms from Digilent on your laptop
- 5. Install NGspice on your laptop
- 6. Configure NGspice on your laptop
- 7. Purchase
  - (a) Laboratory Notebook
  - (b) Digilent "Analog Discovery 2 or 3" 100 MS/sec oscilloscope, function generator, and logic analyzer
  - (c) BNC Adaptor Board for the Analog Discovery
  - (d) Dual-output 12 V (±100 mA) USB power supply (PowerBrick)
- 8. Obtain (during ECE 214 Lab)
  - (a) BNC to alligator clip cable
  - (b) (2) 60 MHz X1-X10 Oscilloscope Probes
  - (c) Electrical Breadboard
  - (d) Digital Multimeter (DVM)