Installing the NGspice Simulation Environment for ECE 444

March 6, 2021

- **Step 1.** Download and install Matlab[®] version 2020a or 2020b from https://umaine.edu/it/software/matlab. Click the Matlab icon and make sure Matlab[®] opens without any errors. If you experience errors, you may need to update your operating system or install additional libraries.
- **Step 2.** Download and install CppSim from http://www.cppsim.com/download.html. This will install the Spice simulation engine, NGspice; the schematic capture program, Sue2; and the results browser, CppSimVie, on your computer. Click the Sue2 icon. A schematic capture window should appear. Again, if you experience any errors, check the documentation at: http://www.cppsim.com/Manuals/cppsim_vppsim_primer5.pdf for possible sources of errors and try and correct any installation errors.
- **Step 3.** Locate the CppSim directory on your computer. The CppSim directory should contain sub-directories including: SpiceModels, Import_Export, Sue2, SueLib, SimRuns, CppSimShared, and Netlist.
 - 1. If using MS Windows 10, in the CppSim/CppSimShared/HspcToolbox directory, locate the file named ngsim.m. Open the file using Matlab® or a text editor. On line 133, replace win32 with win64.
 - 2. If using OSX or Linux, download the spiceinit file from http://davidkotecki.com/ ECE214/docs/ngspice/spiceinit. Edit the file so that the lines beginning with codemodel all have a valid directory structure and point to valid .cm files. Rename this file .spiceinit and place in your home directory.

Step 4. Configure Sue2.

- 1. In the Sue2 schematic capture window, click: Tools → Library Manager. The Library Manager window should open.
- 2. A Library is the name of a folder where you store schematics. Each schematic is referred to as a module. Sue2 comes with a lot of libraries that are not used in ECE 444. From the Library text box, select each library except for "devices" and "spice," and click "Remove Library." This will not delete the library from your computer, but will remove it from your current design environment.
- 3. Create a new library to store your ECE 444 simulations. Click "Create" next to Library Operations. A "Create New Library" window will appear. Enter ECE444 as the library name, then click OK.
- 4. Close Sue2.

- **Step 5.** Download the file ece214_2021_devices.tar.gz from http://davidkotecki.com/ECE444/docs/ece214_2021_devices.tar.gz, and the file ece444_2021_devices.tar.gz from http://davidkotecki.com/ECE444/docs/ece444_2021_devices.tar.gz. Move these files to the "Import_Export" directory within the CppSim directory. Do not unzip these files.
- **Step 6.** Download the file ECE214_models.zip from http://davidkotecki.com/ECE444/docs/ECE214_models.zip, and the file ECE444_models.zip from http://davidkotecki.com/ECE444/docs/ECE444_models.zip. Move these files to the "SpiceModels" directory within the "Cpp-Sim" directory. Unzip these files in the "SpiceModels" directory. You should now have a number of files in the "SpiceModels" directory including a file called "ECE214_models.mod" and a file called "ECE444_models.mod". If these files do not exist in the "SpiceModels" directory, verify that you unzipped the files in the correct directory.
- **Step 7.** Start Sue2. Click: Tools → Library Manager. Click "Import Library Tool," select the ece214_2021_devices.tar.gz file and click Import. Click "Import Library Tool," select the ece214_2021_devices.tar.gz file and click Import. Close and restart Sue2.
- **Step 8.** Select the "ECE444 Library" in the Library Selection Box in the upper right hand corner of the schematic window. Click on the module called: "first_module_for_ECE444." Click: File → New Schematic. Enter a new schematic name and make sure the destination library is ECE444.

You are now ready to design and simulate!!!