

1. List 5 common issues users face with USB keyboards or mice on laptops, and write one possible solution for each.

Ans.

1. Keyboard or mouse is not working

Sometimes the keyboard or mouse may not work after connecting it to the laptop.

Solution: Remove the USB connector and connect it again properly. Also check that the device is switched on if it has a power switch.

2. USB device is not detected

The laptop may not recognize the connected keyboard or mouse.

Solution: Try connecting the device to another USB port. Restart the laptop if it is still not detected.

3. Mouse cursor is not moving properly

The mouse cursor may move slowly or may not move smoothly on the screen.

Solution: Clean the bottom sensor of the mouse and use the mouse on a clean and flat surface.

4. Some keyboard keys are not working

Some keys may stop working because of dust or dirt under the keys.

Solution: Clean the keyboard carefully and check whether any key is stuck.

5. Keyboard or mouse stops working sometimes

The device may work for some time and then suddenly stop.

Solution: Disconnect and reconnect the USB device. If the problem continues, restart the laptop and try another USB port.

2.Simulate a troubleshooting flow: Your Bluetooth headphones are not connecting to your phone. Write the exact step-by-step actions you would take to diagnose and fix the issue, mentioning any settings or indicators you would check.

Ans.

Problem: Bluetooth headphones are not connecting to the phone.

1. **Check the headphones:** First, make sure the headphones are switched ON and have enough battery.
2. **Check Bluetooth:** Open the phone Settings → Bluetooth and make sure Bluetooth is turned ON.
3. **Check pairing mode:** Put the headphones into pairing mode. Usually, the Bluetooth light starts blinking when they are ready to connect.
4. **Check the device list:** Look at the available Bluetooth devices on the phone and find the name of the headphones.
5. **Connect the headphones:** Tap the headphone name and wait for the phone to show Connected.
6. **Check the distance:** Keep the headphones close to the phone. Move away from other Bluetooth devices if there is interference.
7. **Disconnect old connection:** If the headphones are already connected to another phone or laptop, disconnect them from that device first.
8. **Forget and pair again:** If they still do not connect, select the headphones in Bluetooth settings, choose Forget/Unpair, and then pair them again.
9. **Restart both devices:** Turn the headphones and phone OFF and ON again, then try connecting.
10. **Final check:** Check the Bluetooth icon and headphone indicator to confirm that the headphones are connected and audio is coming through them.

3. A user reports that their external webcam is not detected during a Zoom call on Windows 10. Write a checklist of 6 things to check or try to resolve the problem.

Ans.

1. Check the USB connection

Make sure the webcam USB cable is properly connected to the laptop or PC. Try another USB port if needed.

2. Check Device Manager

Open **Device Manager** and look under **Cameras** or **Imaging Devices**. Check whether the webcam is listed and working properly.

3. Check Windows Privacy Settings

Go to **Settings → Privacy → Camera** and make sure camera access is turned ON.

4. Check Zoom camera settings

Open Zoom and go to **Settings → Video**. Select the external webcam from the camera list.

5. Close other apps using the camera

Close apps such as Teams, Skype, or the Camera app because another application may already be using the webcam.

6. Restart and reconnect the webcam

Disconnect the webcam, restart the computer, and connect the webcam again. Then open Zoom and check if the camera is detected.

4. You are helping a friend whose printer is showing 'offline' status on their PC. Describe how you would use the Windows Troubleshooter tool to try to fix the issue, and explain what information the tool provides during the process.

Ans.

If the printer shows “**Offline**” on the PC, I would follow these steps:

1. **Check the printer:** First, make sure the printer is switched ON and properly connected to the PC or Wi-Fi.
2. **Open Settings:** Go to **Start → Settings → Devices → Printers & scanners**.
3. **Select the printer:** Find the printer showing the **Offline** status and select it.
4. **Run Troubleshooter:** Click on **Manage** and use the **Troubleshooter** option to start checking the printer problem.
5. **Wait for the check:** Windows checks common problems such as connection issues, printer settings, drivers, and printer status.
6. **Follow the suggested solution:** The troubleshooter shows the problem it finds and gives steps or options to fix it.
7. **Check the result:** After applying the suggested fix, check whether the printer status changes from **Offline to Ready/Online**.

Information Provided by the Troubleshooter

The tool can show information about **connection problems, driver issues, printer settings, and other detected problems**. It also tells whether a problem was fixed or if further action is required.

