

Thermotools
Location:

Trondheim NORWAY

https:

//thermotools.github.io/
thermopack/index.html

Introduction to thermodynamics

AUTHOR DATE
Morten Hammer, Geir Skaugen and Eskil Aursand 2025-01-03

Contents

1	Introduction	2
2	Thermodynamic potentials 2.1 Internal energy	2 2 2 3 3
3	Equilibrium in multi-phase systems with given (T,P) 3.1 Systems with given (T,P)	4 4 5
4	Equilibrium in terms of an equation of state 4.1 The equation of state 4.2 The residual Helmholtz energy 4.3 Fugacity 4.3.1 Ideal gas mixtures 4.3.2 Real mixtures	6 6 6 7 7 8
5	TP Flash 5.1 General equations of phase equilibrium and stability 5.2 Tangent plane stability analysis 5.3 Mixture reduced molar Gibbs energy 5.4 Two-phase flash 5.4.1 Solution by minimization	9 10 11 12 13
6	Cubic equations of state 6.1 Mixing rules	15 15 15 15
7	Explicit Helmholtz equations of state	15
8	Ideal gas Helmholtz energy	16
\mathbf{A}	Newton's method for root finding	17
В	Newton's method for optimization (Modified Newton)	17



C Accelerated direct substitution (Dominant Eigenvalue Method)

17

1 Introduction

This document is meant as an introduction to thermodynamics for users and programmers in thermopack.

In addition to this memo, there exsist two memos written to document thermopack. These can be generated running pdflatex in the thermopack documentation folder ./doc/memo/.

Otherwise the thermodynamics book by Callen [1] and by Michelsen [6] is recommended. Much of the work done on flash algorithms are based on the work by Michelsen [3, 4, 5].

2 Thermodynamic potentials

2.1 Internal energy

As a starting point, one assumes a fundamental equation for the internal energy (U), with the extensive variables entropy (S), volume (V) and molar numbers (n) as independent variables:

$$U = U(S, V, \boldsymbol{n}) \tag{1}$$

Under the assumption that U is a first order homogeneous function of the extensive variables, one may use Euler's theorem of homogeneous functions to show that:

$$U(S, V, \mathbf{n}) = S \frac{\partial U}{\partial S} \Big|_{V, \mathbf{n}} + V \frac{\partial U}{\partial V} \Big|_{S, \mathbf{n}} + \sum_{i} n_{i} \frac{\partial U}{\partial n_{i}} \Big|_{S, V, n_{j}}$$
$$= ST - VP + \sum_{i} n_{i} \mu_{i}$$
(2)

using the definitions

$$T \equiv \frac{\partial U}{\partial S}\Big|_{V,n}, \quad P \equiv \frac{\partial U}{\partial V}\Big|_{S,n}, \quad \mu_i \equiv \frac{\partial U}{\partial n_i}\Big|_{S,V,n_i}. \tag{3}$$

The differential of U given its homogeneous property (2) is

$$dU = SdT + TdS - VdP - PdV + \sum_{i} n_i d\mu_i + \sum_{i} \mu_i dn_i,$$
(4)

while generally the total (exact) differential of (2), given its independent variables, is

$$dU = TdS - PdV + \sum_{i} \mu_{i} dn_{i}, \qquad (5)$$

which combine into the Gibbs-Duhem relation for the intensive properties:

$$SdT - VdP + \sum_{i} n_i d\mu_i = 0.$$
 (6)

2.2 Helmholtz energy

The Helmholtz energy is defined as

$$A(T, V, \mathbf{n}) \equiv U - TS,\tag{7}$$



and by using (5), one may show that

$$dA = -SdT - PdV + \sum_{i} \mu_{i} dn_{i},$$
(8)

and one may then see that

$$S = -\frac{\partial A}{\partial T}\Big|_{V,n}, \quad P = -\frac{\partial A}{\partial V}\Big|_{T,n}, \quad \mu_i = \frac{\partial A}{\partial n_i}\Big|_{T,V,n_j}. \tag{9}$$

2.3 Gibbs energy

The Gibbs energy is defined as

$$G(T, P, \mathbf{n}) \equiv U + PV - TS,\tag{10}$$

and by using (5), one may show that

$$dG = -SdT + VdP + \sum_{i} \mu_{i} dn_{i}.$$
(11)

and one may then see that

$$S = -\frac{\partial G}{\partial T}\Big|_{P,n}, \quad V = \frac{\partial G}{\partial P}\Big|_{T,n}, \quad \mu_i = \frac{\partial G}{\partial n_i}\Big|_{T,P,n_i}. \tag{12}$$

Combining (6) with (11) leads to

$$dG = \sum_{i} \mu_i dn_i + \sum_{i} n_i d\mu_i, \qquad (13)$$

which can be recognized as a total differential for the alternative expression for G:

$$G = \sum_{i} \mu_i n_i. \tag{14}$$

2.4 Enthalpy

The Enthalpy is defined as

$$H(S, P, \mathbf{n}) \equiv U + PV, \tag{15}$$

and by using (5), one may show that

$$dH = TdS + VdP + \sum_{i} \mu_{i} dn_{i}.$$
(16)

and one may then see that

$$T = \frac{\partial H}{\partial S}\Big|_{P,n}, \quad V = \frac{\partial H}{\partial P}\Big|_{S,n}, \quad \mu_i = \frac{\partial H}{\partial n_i}\Big|_{S,P,n_i}.$$
 (17)

3 Equilibrium in multi-phase systems with given (T,P)

3.1 Systems with given (T,P)

To characterize the equilibrium state, let us image that a small perturbation from equilibrium happens, and then focus on the spontaneous process (δ) leading back to the equilibrium state. For an isolated system, the second law of thermodynamics states that all spontaneous changes towards the equilibrium state involve an increase in entropy:

$$\delta S_{\text{tot}} > 0$$
 (18)

where δ indicates that it is not a change between different equilibrium states, as d is used to indicate. We are however not interested in an isolated system, but rather a system with given temperature and pressure. This may be though of as a sub-system of a total system, the latter satisfying (18). The other part of the total system is the *reservoir*, which holds the given temperature and pressure, and is large enough to force our system to keep the same values. Energy and volume (but not particles) may be freely exchanged between the system (no subscript) and the reservour (subscript r), in order to find the equilibrium of the total system. As entropy is an extensive quantity, the total entropy (which must increase) is a sum of the entropy of the system and en entropy of the reservoir:

$$\delta S + \delta S_{\rm r} = \delta S_{\rm tot} \ge 0. \tag{19}$$

Defining δQ as the heat transferred into the system, the change of entropy in the reservoir is given by

$$\delta S_{\rm r} = -\frac{\delta Q}{T} = -\left(\frac{1}{T}\delta U + \frac{P}{T}\delta V\right),\tag{20}$$

by using the first and second laws of thermodynamics. The implication of (19) is then that

$$T\delta S \ge \delta U + P\delta V. \tag{21}$$

The change in Gibbs energy at constant temperature and pressure is

$$\delta G = \delta (U + PV - TS)$$

$$= \delta U + P\delta V + V\delta P - T\delta S - S\delta T$$

$$= \delta U + P\delta V - T\delta S,$$
(22)

which combined with (21) shows that

$$\delta G \le 0. \tag{23}$$

In words, this shows that a process which increases the entropy of the total system must decrease the Gibbs energy of a sub-system, given that the rest of the total system behaves like a T, P reservoir. Given that this process characterizes returns from perturbations around the equilibrium state, the conclusion must be:

For a closed system of given temperature and pressure, the equilibrium condition is that its Gibbs energy (G) is at a minimum.

3.2 Multi-phase systems

So far the internal workings of the system have been ignored. Now we want to take into account that the system may consist of multiple phases, which essentially are sub-systems which are free to exchange energy, volume and particles. As shown in Sec. 3.1, the condition for equilibrium is that the Gibbs energy for the entire system is at an extremum with respect to perturbation. Let us assume that the perturbation is sufficiently small that the chemical potentials to not change, i.e. $\delta \mu_i \approx 0$. This may also be seen as assuming that the perturbation is so small that $\delta G \approx \mathrm{d} G$, where the latter is given by (11). For constant T and P this means that

$$\delta G = \sum_{i} \delta G_{j} = \sum_{i} \sum_{i} \mu_{i}^{(j)} \delta n_{i}^{(j)} = 0, \tag{24}$$

where j indicates the phase, and i indicates the component. The conservation of matter, given no chemical reactions, gives that any change in the mole number of a component in an arbitrary phase α , must come from a net opposite change in the same component in the other phases:

$$\delta n_i^{(\alpha)} = -\sum_{j \neq \alpha} \delta n_i^{(j)}. \tag{25}$$

Combining (24) and (25) leads to

$$\sum_{i \neq \alpha} \sum_{i} \left(\mu_i^{(j)} - \mu_i^{(\alpha)} \right) \delta n_i^{(j)} = 0.$$

$$(26)$$

Given that the above must be true for any variation of the independent mole numbers, this means that

$$\mu_i^{(\alpha)} = \mu_i^{(j)} \quad \forall \quad i, j \tag{27}$$

which in words is stated as:

For a multi-phase system of given temperature and pressure, the equilibrium condition is that for each component, the chemical potential is equal in all phases.

Additionally, there is a stability criterion for each phase, stated as:

For a multi-phase system of given temperature and pressure, the condition for phase stability is that the change in total Gibbs energy associated with the formation of a new infinitesimal phase within an existing phase is non-negative, for *any* composition of the new phase. This is called the *tangent plane condition*.

The change in Gibbs energy with the formation of a new phase of δn moles and composition w_i , from an existing phase of composition z_i , is

$$\delta G = \sum_{i} \mu_{i}(\boldsymbol{z}) \left(-w_{i}\delta n\right) + \sum_{i} \mu_{i}(\boldsymbol{w}) \left(+w_{i}\delta n\right)$$

$$= \delta n \sum_{i} w_{i} \left(\mu_{i}(\boldsymbol{w}) - \mu_{i}(\boldsymbol{z})\right), \tag{28}$$

which must be non-negative for any composition w, for the existing phase composition z:

$$\sum_{i} w_i \left(\mu_i(\boldsymbol{w}) - \mu_i(\boldsymbol{z}) \right) \ge 0. \tag{29}$$

When checking the stability of equilibrium phases, the chemical potential of each component is equal between the phases, and thus the left hand side of (29) is identical for each phase.

4 Equilibrium in terms of an equation of state

4.1 The equation of state

An equation of state is often given as an explicit pressure equation, such as

$$P = P(T, V, \boldsymbol{n}). \tag{30}$$

However, many equations of state is expressed as a Helmholtz energy function,

$$A = A(T, V, \boldsymbol{n}). \tag{31}$$

which is useful because all thermodynamical properties may be derived by differentiating it.

The Helmholtz function of new multi-parameter GERG equations of state [2, 7] and the older cubic equations of state is represented as a sum of an ideal contribution, and a departure (residual) contribution:

$$A(T, V, \mathbf{n}) = A^{ig}(T, V, \mathbf{n}) + A^{r}(T, V, \mathbf{n})$$
(32)

Often a reduced (dimensionless) form of the residual Helmholtz energy is used,

$$F(T, V, \mathbf{n}) = a \equiv \frac{A^{r}(T, V, \mathbf{n})}{nRT}$$
(33)

4.2 The residual Helmholtz energy

The relationship between pressure and the Helmholtz energy two forms is:

$$P(T, V, \boldsymbol{n}) = -\frac{\partial A}{\partial V}\Big|_{T \boldsymbol{n}} = \frac{nRT}{V} - \frac{\partial A^{r}(T, V, \boldsymbol{n})}{\partial V}\Big|_{T \boldsymbol{n}}.$$
(34)

An expression for A^{r} may be found by integrating to the limit of infinite volume at constant temperature and mole numbers:

$$A^{\mathrm{r}}(T, V, \boldsymbol{n}) = A^{\mathrm{r}}(T, \infty, \boldsymbol{n}) + \int_{\infty}^{V} \left[P^{\mathrm{ig}}(T, V', \boldsymbol{n}) - P(T, V', \boldsymbol{n}) \right] dV', \tag{35}$$

which when using that real fluids behave as an ideal gas in the limit of zero pressure $(V \to \infty)$ leads to the expression:

$$A^{r}(T, V, \boldsymbol{n}) = \int_{V}^{\infty} \left[P(T, V', \boldsymbol{n}) - \frac{nRT}{V'} \right] dV'$$
(36)

Be aware that residual quantities will depend on which set of variables they are represented with. As an example, let's show how this works out for the residual Helmholtz energy: From the state (T, V, P, \mathbf{n}) by definition being a real state, we know that

$$A(T, V, \boldsymbol{n}) = A(T, P, \boldsymbol{n}). \tag{37}$$

While the value of A is independent of representation, the distribution of it between the ideal contribution and the residual is not. This is so because the state (T, V, P, n) is not in general a valid state of an ideal gas, so generally we have that

$$A^{ig}(T, V, \boldsymbol{n}) \neq A^{ig}(T, P, \boldsymbol{n}). \tag{38}$$



Using an arbitrary valid ideal gas state at temperature T, $(T, V_0, P_0, \mathbf{n})$, we have by definition of this state that

$$A^{ig}(T, P_0, \boldsymbol{n}) = A^{ig}(T, V_0, \boldsymbol{n}) \tag{39}$$

Combining (32), (37), (39) and the ideal gas law leads to the following calculation for the difference in residuals between variable representations:

$$A^{r}(T, V, \boldsymbol{n}) - A^{r}(T, P, \boldsymbol{n}) = A^{ig}(T, P, \boldsymbol{n}) - A^{ig}(T, V, \boldsymbol{n})$$

$$= \left[A^{ig}(T, P, \boldsymbol{n}) - A^{ig}(T, P_0, \boldsymbol{n}) \right] - \left[A^{ig}(T, V, \boldsymbol{n}) - A^{ig}(T, V_0, \boldsymbol{n}) \right]$$

$$= \int_{P_0}^{P} \frac{\partial A^{ig}}{\partial P} \Big|_{T, \boldsymbol{n}} dP - \int_{V_0}^{V} \frac{\partial A^{ig}}{\partial V} \Big|_{T, \boldsymbol{n}} dV$$

$$= nRT \ln \left(\frac{PV}{P_0 V_0} \right) = nRT \ln \left(\frac{PV}{nRT} \right) = nRT \ln (Z), \qquad (40)$$

where Z is the compressibility factor, defined by

$$Z \equiv \frac{PV}{nRT} = 1 - \frac{V}{nRT} \frac{\partial A^{r}(T, V, \boldsymbol{n})}{\partial V} \bigg|_{T, \boldsymbol{n}}.$$
 (41)

Thus we have the following expression for the residual Helmholtz free energy expressed through the variables (T, P, \mathbf{n}) :

$$A^{r}(T, P, \boldsymbol{n}) = \int_{V}^{\infty} \left(P(T, V', \boldsymbol{n}) - \frac{nRT}{V'} \right) dV' - nRT \ln(Z)$$
(42)

4.3 Fugacity

For a pure ideal gas, the change in chemical potential corresponding to a change in pressure, at constant temperature, is give by

$$\frac{P}{P_0} = \exp\left(\frac{\mu^{ig}(T, P) - \mu^{ig}(T, P_0)}{RT}\right). \tag{43}$$

Real fluids do not obey this relation, but one may define an "effective pressure" called fugacity (f) such that the following relation holds:

$$\frac{f(T,P)}{P_0} = \exp\left(\frac{\mu(T,P) - \mu^{ig}(T,P_0)}{RT}\right). \tag{44}$$

The reference pressure is arbitrary, so one may set $P_0 = P$ to make an expression only in terms of the deviation from ideal gas:

$$\frac{f(T,P)}{P} = \exp\left(\frac{\mu(T,P) - \mu^{ig}(T,P)}{RT}\right),\tag{45}$$

which shows that for ideal gases, f(T, P) = P.

4.3.1 Ideal gas mixtures

An ideal gas mixture is defined as a mixture which has the following expression for the Helmholtz free energy:

$$A^{ig}(T, V, \boldsymbol{n}) \equiv \sum_{i} n_i \left(\mu_i^{ig}(T, P_0) + RT \ln \frac{n_i RT}{P_0 V} - RT \right)$$
(46)

where n_i is the mole number of component i, and $\mu_i^{ig}(T, P)$ is the chemical potential of component i in its pure form at the given temperature and pressure. This definition is consistent with the ideal gas law for the mixture as a whole, PV = nRT, where $n = \sum n_i$. From (46) one may find the Gibbs free energy of the ideal gas mixture as

$$G^{ig}(T, P, \boldsymbol{n}) = A^{ig}(T, V, \boldsymbol{n}) + (PV)^{ig} = A^{ig}(T, V, \boldsymbol{n}) + nRT$$

$$= \sum_{i} n_{i} \left(\mu_{i}^{ig}(T, P_{0}) + RT \ln \frac{x_{i}P}{P_{0}} \right)$$
(47)

where $x_i \equiv n_i/n$ is the mole fraction of component i.

From (46) and (47) one may find the chemical potential, in terms of V or P, of component i in the ideal mixture as

$$\mu_{i}^{ig}(T, V, \boldsymbol{n}) \equiv \frac{\partial A^{ig}}{\partial n_{i}} \Big|_{T, V} = \mu_{i}^{ig}(T, P_{0}) + RT \ln \frac{n_{i}RT}{P_{0}V}$$

$$\mu_{i}^{ig}(T, P, \boldsymbol{n}) \equiv \frac{\partial G^{ig}}{\partial n_{i}} \Big|_{T, P} = \mu_{i}^{ig}(T, P_{0}) + RT \ln \frac{x_{i}P}{P_{0}}, \tag{48}$$

which are equal if the state (T, V, P, n) is a valid ideal gas state (PV = nRT), as expected. Combining the two equations in (48), while setting $P_0 = P$, leads the the following useful expression:

$$\mu_i^{\text{ig}}(T, V, \boldsymbol{n}) - \mu_i^{\text{ig}}(T, P, \boldsymbol{n}) = -RT \ln (Z) \tag{49}$$

where if (T, V, P, n) is a valid state for an ideal gas, Z = 1, and the right hand side reduces to zero as expected.

The last equation in (48) may be rearranged to form the inspiration for the definition of real mixture fugacity in the next section:

$$\frac{P_i}{P_0} = \exp\left(\frac{\mu_i^{\text{ig}}(T, P, \boldsymbol{n}) - \mu_i^{\text{ig}}(T, P_0)}{RT}\right)$$
(50)

where $P_i = x_i P$ is the partial pressure of component i. For $P_0 = P$ this reduces to

$$\mu_i^{ig}(T, P, \boldsymbol{n}) - \mu_i^{ig}(T, P) = RT \ln x_i \tag{51}$$

4.3.2 Real mixtures

Similar to the case of pure components, one may define an "effective partial pressure" of a component in a mixture, the component fugacity (f_i) , such that the following relation similar to (50) holds:

$$\frac{f_i(T, P, \mathbf{n})}{P_0} \equiv \exp\left(\frac{\mu_i(T, P, \mathbf{n}) - \mu_i^{ig}(T, P_0)}{RT}\right),\tag{52}$$

where one may again set $P_0 = P$ to state it in terms of deviations from a pure ideal gas:

$$\frac{f_i(T, P, \mathbf{n})}{P} \equiv \exp\left(\frac{\mu_i(T, P, \mathbf{n}) - \mu_i^{ig}(T, P)}{RT}\right),\tag{53}$$

The chemical potential of a component in a real mixture may be decomposed into an ideal gas part and a residual part:

$$\mu_i(T, V, \mathbf{n}) = \mu_i^{ig}(T, V, \mathbf{n}) + \mu_i^{r}(T, V, \mathbf{n})$$

$$\mu_i(T, P, \mathbf{n}) = \mu_i^{ig}(T, P, \mathbf{n}) + \mu_i^{r}(T, P, \mathbf{n})$$
(54)

which may be combined with (49) to show that

$$\mu_i^{\mathrm{r}}(T, V, \boldsymbol{n}) - \mu_i^{\mathrm{r}}(T, P, \boldsymbol{n}) = RT \ln (Z)$$
(55)

Combining (53) and (51), one finds that

$$\frac{f_i(T, P, \boldsymbol{n})}{x_i P} \equiv \exp\left(\frac{\mu_i(T, P, \boldsymbol{n}) - \mu_i^{ig}(T, P, \boldsymbol{n})}{RT}\right)$$
(56)

The fugacity coefficient may now be defined, calculated using (56) and (55) as follows:

$$\phi_{i}(T, P, \mathbf{n}) \equiv \frac{f_{i}(T, P, \mathbf{n})}{x_{i}P} = \exp\left(\frac{\mu_{i}(T, P, \mathbf{n}) - \mu_{i}^{ig}(T, P, \mathbf{n})}{RT}\right)$$

$$= \exp\left(\frac{\mu_{i}^{r}(T, P, \mathbf{n})}{RT}\right)$$

$$= \exp\left(\frac{\mu_{i}^{r}(T, V, \mathbf{n})}{RT} - \ln(Z)\right)$$

$$= \exp\left(\frac{1}{RT}\frac{\partial A^{r}(T, V, \mathbf{n})}{\partial n_{i}}\Big|_{T, V, n_{i}} - \ln(Z)\right)$$
(57)

where $A^{r}(T, V, \mathbf{n})$ may be found from (36).

As shown in Sec. 3.2, the condition of phase equilibrium is that for each component, the chemical potential must be equal in all phases. Using (53), and the fact that $\mu_i^{ig}(T, P)$ is independent of phase, the condition may be restated in the more useful form:

For a multi-phase system of given temperature and pressure, the equilibrium condition is that for each component i, the quantity $x_i\phi_i$ is equal in all phases. The fugacity coefficient may be calculated from the equation of state through (57) and (41).

5 TP Flash

5.1 General equations of phase equilibrium and stability

As shown in Sec. 3.2 and 4.3.2, the criterion for equilibrium in a multi-phase system at given temperature and pressure is that for each component, the fugacity is equal in all phases.

$$f_i^{(\alpha)} = f_i^{(j)} \quad \forall \quad i, j, \alpha \tag{58}$$

Additionally, there is a phase stability criterion, stated as the tangent plane condition in Sec. 3.2. Let us define a tangent plane distance function for the composition z, a function of a trial composition w:

$$TPD_z(\boldsymbol{w}) \equiv \sum_i w_i \left(\mu_i(\boldsymbol{w}) - \mu_i(\boldsymbol{z}) \right).$$
 (59)

It is often convenient to use a reduced tangent plane distance function

$$tpd_{z}(\boldsymbol{w}) \equiv \frac{TPD(\boldsymbol{w})}{RT}$$

$$= \sum_{i} w_{i} \left[\ln w_{i} + \ln \phi_{i}(\boldsymbol{w}) - \ln z_{i} - \ln \phi_{i}(\boldsymbol{z}) \right]$$

$$= \sum_{i} w_{i} \left[\ln w_{i} + \ln \phi_{i}(\boldsymbol{w}) - d_{i}(\boldsymbol{z}) \right], \qquad (60)$$

where $d_i \equiv \ln z_i + \ln \phi_i(z)$

The phase stability criterion is then

$$tpd_z(\boldsymbol{w}) \ge 0$$
 for any valid composition \boldsymbol{w} (61)

and this may be shown to be both a necessary and sufficient condition for phase stability [6]. In practice, ensuring that $tpd_z(\boldsymbol{w})$ is non-negative everywhere in compositional space is done by finding its minima, and then checking if it is negative at these locations. Finding the minima of $tpd_z(\boldsymbol{w})$, subject to the constraint of $\sum w_i = 1$, may be solved using the method of Lagrange multipliers.

Modified (unconstrained) formulation:

$$tm_z(\boldsymbol{W}) = 1 + \sum_i W_i \left[\ln W_i + \ln \phi_i(\boldsymbol{W}) - d_i(\boldsymbol{z}) - 1 \right]$$
$$= (1 - W_T + W_T \ln W_T) + W_T t p d_z(\boldsymbol{w})$$
(62)

where $W_i = w_i W_T$ ($W_T \equiv \sum W_i$) are mole numbers, not composition, and are thus not constrained to sum to one. At stationary points of $tm_z(\mathbf{W})$ with respect to W_i :

$$\ln W_i^{\text{SP}} + \ln \phi_i(\boldsymbol{W}^{\text{SP}}) - d_i(\boldsymbol{z}) = 0 \quad \forall \quad i$$
(63)

$$tm_z(\mathbf{W}^{\mathrm{SP}}) = 1 - W_T^{\mathrm{SP}} \tag{64}$$

It may be shown [6, Ch. 9] that the stationary points of $tm_z(\mathbf{W})$ are also valid stationary points for the constrained function $tpd_z(\mathbf{w})$, and $tpd_z(\mathbf{w}^{SP})$ is positive at these minima if and only if $W_T^{SP} \leq 1$, i.e. if $tm_z(\mathbf{W}^{SP}) \geq 0$. The procedure to check stability can then be formulated as:

- 1. Find the stationary points of $tm_z(\mathbf{W})$ with respect to \mathbf{W} , *i.e* solutions of (63).
- 2. Check if $W_T^{\rm SP} \leq 1$ at all the stationary points found. If not, the mixture z is unstable.

Eq. (63) may be solved by *successive substitution* or *Newton's method*. As discussed by Michelsen [6], successive substitution will converge in most case but may suffer from a low rate of convergence, giving merit to the use of Newton's method.

A composition z is metastable as long as the Hessian matrix H(z) of $tm_z(\mathbf{W})$ is positive definite. If not, the state is *intrinsically unstable*. The limit between the two cases is the *stability limit / spinodal line*.

How to uncover all negative minima of $tm_z(\mathbf{W})$ (if any)? This cannot be done with total certainty, but one may use some clever initial estimates to perform a finite set of searches which are likely to uncover them.

5.2 Tangent plane stability analysis

Tangent plane stability analysis serves two purposes:

- Verifies that a single phase state is stable.
- If the single phase state is not stable, gives an improved K-factor guess.

🌠 Thermotools memo

As shown, a phase of composition z is stable at the specified temperature and pressure if and only if $tpd_z(\boldsymbol{w}) \geq 0$ for any trial phase composition \boldsymbol{w} . This could checked by inspecting the minima of $tm_z(\boldsymbol{W})$ (62) and checking the criterion $W_T^{\mathrm{SP}} \leq 1$.

The original composition is intrinsically unstable if the Hessian

$$H_{ij} \equiv \frac{\partial^2 t m_z}{\partial W_i \partial W_i} = \frac{\delta_{ij}}{W_i} + \frac{\partial \ln \phi_i}{\partial W_i}$$
 (65)

has any negative eigenvalues at the trivial stationary point at $\mathbf{W} = \mathbf{z}$. If it has no negative eigenvalues at this point, the mixture is either stable $(tm_z(\mathbf{W}) > 0 \text{ at all its minima})$ or metastable $(tm_z(\mathbf{W}) < 0 \text{ at some minimum where } \mathbf{W} \neq \mathbf{z})$.

By using (63), minima of $tm_z(\mathbf{W})$ may be found by successive substitution:

$$\ln W_i^{k+1} = d_i(\boldsymbol{z}) - \ln \phi_i \left(\boldsymbol{W}^k \right), \tag{66}$$

which may be shown to only converge to minima, not other stationary points. Slow convergence may be remedied by higher order methods. Outcomes of stability analysis:

- A composition W where $tm_z(W) < 0$ is found. Continue the flash calculation with w as a new phase.
- All attempts converge to either the trivial solution of a positive minimum. The composition
 z is thus stable.

5.3 Mixture reduced molar Gibbs energy

By combining (14), (56) and (51), one may show that the Gibbs energy of a multi-phase mixture is given by

$$G = \sum_{j} \sum_{i} n_{i}^{(j)} \mu_{i}^{(j)}$$

$$= \sum_{j} \sum_{i} n_{i}^{(j)} \left[\mu_{i}^{ig}(T, P, \boldsymbol{n}) + RT \ln \phi_{i}^{(j)}(T, P, \boldsymbol{n}) \right]$$

$$= \sum_{j} \sum_{i} n_{i}^{(j)} \left[\mu_{i}^{ig}(T, P) + RT \ln x_{i}^{(j)} + RT \ln \phi_{i}^{(j)}(T, P, \boldsymbol{n}) \right]$$

$$= \sum_{j} \sum_{i} n_{i}^{(j)} \mu_{i}^{ig}(T, P) + \sum_{j} \sum_{i} n_{i}^{(j)} \left[RT \ln x_{i}^{(j)} + RT \ln \phi_{i}^{(j)}(T, P, \boldsymbol{n}) \right]$$

$$= \sum_{i} \left(\sum_{j} n_{i}^{(j)} \right) \mu_{i}^{ig}(T, P) + \sum_{j} \sum_{i} n_{i}^{(j)} \left[RT \ln x_{i}^{(j)} + RT \ln \phi_{i}^{(j)}(T, P, \boldsymbol{n}) \right]$$

$$= \sum_{i} n_{i}^{(\text{tot})} \mu_{i}^{ig}(T, P) + \sum_{j} \sum_{i} n_{i}^{(j)} \left[RT \ln x_{i}^{(j)} + RT \ln \phi_{i}^{(j)}(T, P, \boldsymbol{n}) \right]$$

$$(67)$$

When wanting to compare the total Gibbs energy of different phase configurations possible from the same overall composition, the first term in (67) will cancel due to being identical in all configurations. It is thus not necessary to consider it further for these purposes. Denoting this term by $G_0 \equiv \sum_i n_i^{\text{(tot)}} \mu_i^{\text{ig}}(T, P)$, one may define a reduced molar Gibbs energy useful for comparing different phase configurations from the same feed by

$$g \equiv \frac{G - G_0}{nRT}$$

$$= \sum_{i} \sum_{j} \beta_j x_i^{(j)} \left[\ln x_i^{(j)} + \ln \phi_i^{(j)}(T, P, \boldsymbol{n}) \right], \tag{68}$$

where β_j is the fraction of moles in phase j.

5.4 Two-phase flash

Consider a mixture of C components, of overall composition z, and define the liquid and vapor compositions as x and y, respectively. When indices are used instead of vectors, the index i indicates the component. It is assumed that we have a thermodynamic model for the mixture, capable of calculating the fugacity of any component, given a set of temperature, pressure and composition.

The equilibrium condition is

$$f_i^l = f_i^v \quad \forall \quad i \tag{69}$$

Define β as the overall mole fraction of the vapor phase, giving the material balance:

$$\beta y_i + (1 - \beta)x_i = z_i \quad \forall \quad i \tag{70}$$

The mole fractions must sum to unity, a condition which may be transformed to the convenient form:

$$\sum_{i=1}^{C} (x_i - y_i) = 0. (71)$$

The above equations yield 2C + 1 relations, while the number of variables $(\boldsymbol{x}, \, \boldsymbol{y}, \, T, \, P, \, \beta)$ are 2C + 3. This shows that two additional pieces of information are needed, such as specifying (T, P). Equilibrium factors:

$$K_i \equiv \frac{y_i}{x_i} \tag{72}$$

Combining (72) and (70)

$$x_i = \frac{z_i}{1 - \beta + \beta K_i}, \qquad y_i = K_i x_i = \frac{K_i z_i}{1 - \beta + \beta K_i}$$
 (73)

At equilibrium, where (69) is satisfied, we have that

$$K_i \equiv \frac{y_i}{x_i} = \frac{\phi_i^l}{\phi_i^v} \tag{74}$$

Combining (71) with (73) leads to the Rachford-Rice equation:

$$g(\beta) \equiv \sum_{i=1}^{C} (x_i - y_i) = \sum_{i=1}^{C} \frac{z_i (K_i - 1)}{1 - \beta + \beta K_i} = 0$$
 (75)

Two-phase TP flash by successive substitution:

- 1. Use current (or initial) K in the Rachford-Rice equation (75).
- 2. Solve the Rachford-Rice equation for a value of β e.g. by Newton's method.
- 3. Find compositions x_i and y_i corresponding to the above values of K_i and β , through (73).
- 4. Find fugacity coefficients from the equation of state given the above compositions, using e.q. (57).
- 5. Find a new equilibrium factor K using the above fugacity coefficients and the equilibrium assumption (74).
- 6. Go to 1 if K has not converged yet.

Equal fugacities may also be satisfied at "false solutions", which are critical points of the Gibbs energy, but not minima. Fortunately, it may be shown that successive substitution can only converge to minima of the Gibbs energy [6]. Convergence will be slow at high pressures or close to the mixture critical point.

Initial values for K: Wilson's approximation:

$$\ln K_i = \ln \left(\frac{P_{c_i}}{P}\right) + 5.373(1+\gamma_i) \left(1 - \frac{T_{c_i}}{T}\right), \tag{76}$$

where P_{c_i} , T_{c_i} and γ_i is the critical temperature, critical pressure and acentric factor, respectively, of component i.

Single phase solution?

Convergence at $\beta < 0$ or $\beta > 0$, or convergence to the trivial solution x = y.

Flash strategy:

- 1. Find Wilson K-factors (76) to use as initial estimates.
- 2. Do three steps of successive substitution. Check for conditions:
 - Total Gibbs energy of the resulting liquid-vapor system is lower than in the feed (assuming single phase). This verifies the presence of multiple phases. Continue iteration, perhaps with higher order methods.
 - If not the above, check if $tpd_z(\boldsymbol{x})$ or $tpd_z(\boldsymbol{y})$ is negative. If the former, set $K_i = \phi_i^x/\phi_i^z$. If the latter, set $K_i = \phi_i^z/\phi_i^y$. Continue iteration.
- 3. If neither of the above conditions were met after three iterations, do tangent plane stability analysis.

If at any time β exceeds its bounds, it is very likely that the specification corresponds to a single phase state. To be certain, perform tangent plane stability analysis.

Initializing W for tangent plane analysis: Investigate both "liquid-like" and "vapor-like" trial compositions, through Wilson K-factors (76). If the feed itself may with confidence be said to be "liquid-like" or "vapor-like", one may to save time only investigate the trial composition of the opposite kind.

5.4.1 Solution by minimization

When formulating an equilibrium calculation as a minimization problem, it may be useful to use *molar amounts* as the independent variables, defined by

$$v_i \equiv \beta y_i$$

$$l_i \equiv (1 - \beta)x_i, \tag{77}$$

such that

$$v_i + l_i = z_i, (78)$$

where z is now molar amounts, but numerically identical to the feed composition.

$$y_i = \frac{v_i}{\sum v_i}, \quad x_i = \frac{l_i}{\sum l_i} \tag{79}$$

$$\beta_L \equiv 1 - \beta \tag{80}$$

$$\beta = \sum v_i \tag{81}$$

$$\beta_L = \sum l_i \tag{82}$$

The minimization problem to be solved is then

$$v = \underset{v \in \mathbb{R}^C}{\operatorname{arg \, min}} \left\{ g(v, l(v)) \right\}, \quad \text{with } l = z - v$$
 (83)

e.g. by Newton's method of optimization (ref appendix).

By using (68) for the case of two-phase systems:

$$g = \sum_{i} \left(v_i \left[\ln y_i + \ln \phi_i^v \right] + l_i \left[\ln x_i + \ln \phi_i^l \right] \right)$$
 (84)

$$\frac{\partial g}{\partial v_{j}} = \ln y_{j} - \ln x_{j} + \ln \phi_{j}^{v} - \ln \phi_{j}^{l}
+ 1 - \sum_{i} y_{i} + \sum_{i} v_{i} \frac{\partial \ln \phi_{i}^{v}}{\partial v_{j}}
- 1 + \sum_{i} x_{i} - \sum_{i} l_{i} \frac{\partial \ln \phi_{i}^{l}}{\partial l_{j}}
= \ln y_{j} - \ln x_{j} + \underbrace{\ln \phi_{j}^{v} - \ln \phi_{j}^{l}}_{\text{From EoS}},$$
(85)

where the sums involving derivatives are zero due to *Euler's theorem* for homogeneous functions, as explained in 1.8 of [6].

$$\frac{\partial^{2} g}{\partial v_{i} \partial v_{j}} = \frac{\partial \ln \phi_{j}^{v}}{\partial v_{i}} - \frac{\partial \ln \phi_{j}^{l}}{\partial v_{i}} - \left(\frac{\beta + \beta_{L}}{\beta \beta_{L}}\right) + \delta_{i,j} \left(\frac{z_{i}}{x_{i} y_{i} \beta \beta_{L}}\right)$$

$$= \frac{1}{\beta \beta_{L}} \left[\beta_{L} \left(\sum_{i} v_{i}\right) \frac{\partial \ln \phi_{j}^{v}}{\partial v_{i}} + \beta \left(\sum_{i} l_{i}\right) \frac{\partial \ln \phi_{j}^{l}}{\partial l_{i}} - 1 + \delta_{i,j} \left(\frac{z_{i}}{x_{i} y_{i}}\right)\right]$$
From EoS From EoS (86)

The function g in (84) should at the located minimum be smaller than the smallest possible value for the a single phase of feed composition:

$$g_{\text{feed}} = \min \left\{ \sum_{i} z_i \left[\ln z_i + \ln \phi_i(\boldsymbol{z}) \right] \right\}, \tag{87}$$

which is either a liquid or a vapor state, depending on which has the lowest Gibbs energy.

6 Cubic equations of state

The general cubic equation of state has the form

$$P = \frac{RT}{v - b} - \frac{\alpha a}{(v - m_1 b)(v - m_2 b)},$$
(88)

where m_1 and m_2 are dimensionless constants defining the SRK, PR and Van der Waals equation of state, v = V/n (m³/mol) is the specific volume. The parameters a (m³J/mol²) and b (m³/mol) typically depend on the composition and the dimensionless quantity α is a function of temperature.

Exercise: Find the reduced residual Helmholtz energy function for a general cubic equation of state (88).

Solution:

$$A^{r}(T, V, N) = n \left[RT \ln \left(\frac{v}{v - b} \right) + \frac{\alpha a}{(m_1 - m_2)b} \ln \left(\frac{v - m_1 b}{v - m_2 b} \right) \right]$$
(89)

6.1 Mixing rules

Mixing rules are various ways of letting a and b in (88) depend on composition.

6.1.1 Classic mixing rule

Parameters: a_{ii} , k_{ij} and b_i .

$$a = \sum_{i} x_i \sum_{j} x_j a_{ij} \tag{90}$$

$$a_{ij} = a_{ji} = \sqrt{a_{ii}a_{jj}} (1 - k_{ij})$$
 (91)

$$b = \sum_{i} x_i b_i \tag{92}$$

6.1.2 Huron-Vidal mixing rule

7 Explicit Helmholtz equations of state

Based on an explicit expression for the reduced dimensionless Helmholtz energy (33). This includes equations such as GERG2004/2008 and the Span-Wagner equation of state for CO_2 .

$$a(\delta, \tau, \boldsymbol{x}) = a^{ig}(\rho, T, \boldsymbol{x}) + a^{r}(\delta, \tau, \boldsymbol{x}), \tag{93}$$

where δ is the reduced mixture density and τ is the reduced mixture temperature, which are both generally dependent on the composition:

$$\delta = \frac{\rho}{\rho_r(\boldsymbol{x})}, \qquad \tau = \frac{T}{T_r(\boldsymbol{x})}.$$
 (94)

8 Ideal gas Helmholtz energy

The equation of state does not provide the energies. In order to find the total Helmholtz energy, and not just the residual, the ideal gas contribution A^{ig} must be found.

An ideal gas is defined by two equations. One the equation of state

$$P^{ig} = \frac{nRT}{V} \tag{95}$$

and the second is the equation for the internal energy

$$U^{ig}(T,n) = nc_v(T)T \tag{96}$$

which simply states that the internal energy depends on the temperature and the number of particles only. The function c_v is the heat capacity at constant volume:

$$C_v = nc_v \equiv \frac{\partial Q}{\partial T}\Big|_V = \frac{\partial U}{\partial T}\Big|_V.$$
 (97)

Additionally there is the *heat capacity at constant pressure*:

$$C_p = nc_p \equiv \frac{\partial Q}{\partial T} \bigg|_P = \frac{\partial H}{\partial T} \bigg|_P,$$
 (98)

where it was used that $dH = \delta Q + V dP$. For an ideal gas, the enthalpy is

$$H^{ig}(T, n) \equiv U^{ig} + p^{ig}V$$

$$= U^{ig}(T, n) + nRT$$

$$= n (c_v + R) T$$
(99)

which shows that for an ideal gas

$$c_p = c_v + R. (100)$$

Change in ideal gas enthalpy at a constant number of particles:

$$H^{ig}(T,n) - H_0^{ig} = \int_{T_0}^T \frac{\partial H}{\partial T} \Big|_P dT$$
$$= n \int_{T_0}^T c_P dT$$
(101)

Change in ideal gas entropy at a constant number of particles:

$$S^{ig}(T, V, n) - S_0^{ig} = \int_{T_0}^T \frac{\partial S}{\partial T} \Big|_V dT + \int_{V_0}^V \frac{\partial S}{\partial V} \Big|_T dV$$

$$= \int_{T_0}^T \frac{nc_v(T)}{T} dT + \int_{V_0}^V \frac{\partial P}{\partial T} \Big|_V dV$$

$$= n \int_{T_0}^T \frac{c_p(T) - R}{T} dT + nR \int_{V_0}^V \frac{1}{V} dV$$

$$= n \int_{T_0}^T \frac{c_p(T) - R}{T} dT + nR \ln \left(\frac{V}{V_0}\right), \qquad (102)$$

using

$$\frac{\partial S}{\partial T}\Big|_{V} = \frac{\partial S}{\partial U}\Big|_{V} \frac{\partial U}{\partial T}\Big|_{V} = \frac{1}{T} \frac{\partial U}{\partial T}\Big|_{V} = \frac{nc_{v}}{T}$$
(103)



and the Maxwell relation

$$\frac{\partial S}{\partial V}\Big|_{T,n} = \frac{\partial P}{\partial T}\Big|_{V,n}.$$
 (104)

The total Helmholtz energy is not provided through the cubic equation of state, only the residual part. The ideal gas part is usually specified as algebraic temperature functions for the heat capacity at constant pressure, $c_p(T)$, provided for each component in the mixture. The total Helmholtz energy may be written as

$$A \equiv U - TS$$

$$= U - TS + PV - PV$$

$$= H - TS - PV,$$
(105)

which means that the Helmholtz energy of a pure ideal gas may be expressed as:

$$\begin{split} A_{i}^{\text{ig}}(T,V,n_{i}) &= H^{\text{ig}} - TS^{\text{ig}} - nRT \\ &= \Delta H_{i}^{\text{ig}} + H_{0,i}^{\text{ig}} - T\left(\Delta S_{i}^{\text{ig}} + S_{0,i}^{\text{ig}}\right) - n_{i}RT \\ &= n_{i} \int_{T_{0}}^{T} c_{p,i}^{\text{ig}}(T) dT + H_{0,i}^{\text{ig}} - n_{i}T \left[\int_{T_{0}}^{T} \frac{c_{p,i}^{\text{ig}}(T) - R}{T} dT + R \ln\left(\frac{V}{V_{0}}\right) \right] - TS_{0,i}^{\text{ig}} - nRT. \end{split}$$

$$(106)$$

Mixing carries with it another entropy contribution, even in the case of ideal mixtures, i.e. with no interactions. The entropy change from ideal mixing at constant pressure and temperature is:

$$\Delta S_{\text{mix}}^{\text{ig}} = -nR \sum_{i} x_i \ln x_i$$

$$= -R \sum_{i} n_i \ln \left(\frac{n_i}{n}\right), \qquad (107)$$

which means that the total Helmholtz energy of an ideal mixture is given by:

$$A^{ig}(T, V, \boldsymbol{n}) = \sum_{i} A_{i}^{ig}(T, V, n_{i}) - T\Delta S_{mix}^{ig}$$
(108)

In terms of the reduced Helmholtz energy, this becomes:

$$a^{ig}(T, V, \mathbf{x}) = \sum_{i} x_i a_i^{ig}(T, V) + \sum_{i} x_i \ln x_i,$$
 (109)

where

$$a_i^{ig}(T, V) \equiv \frac{A_i^{ig}(T, V, n_i)}{n_i RT}.$$
(110)

A Newton's method for root finding

B Newton's method for optimization (Modified Newton)

C Accelerated direct substitution (Dominant Eigenvalue Method)

References

[1] Herbert B. Callen, *Thermodynamics and an Introduction to Thermostatistics*. second edition, John Wiley & Sons Inc, 1985.



- [2] O. Kunz, R. Klimeck, W. Wagner, M. Jaeschke, *The GERG-2004: Wide-Range Equation of State for Natural Gases and Other Mixtures*. GERG TM15 Report (http://www.gerg.eu/publications/tm.htm), 2007.
- [3] Michael L. Michelsen, *The isothermal flash problem. Part I. stability*. Fluid Phase Equilibria, 9(1) pp. 1-19, 1982.
- [4] Michael L. Michelsen, The isothermal flash problem. Part II. phase-split calculation. Fluid Phase Equilibria, 9(1) pp. 21-40, 1982.
- [5] Michael L. Michelsen and Jørgen M. Mollerup, State function based flash specifications. Fluid Phase Equilibria, 158-160 pp. 617-626, 1999.
- [6] Michael L. Michelsen and Jørgen M. Mollerup, *Thermodynamic models: Fundamentals & computational aspects*. second edition Tie-Line Publication, 2007.
- [7] Roland Span and Wolfgang Wagner, A New Equation of State for Carbon Dioxide Covering the Fluid Region from the Triple-Point Temperature to 1100 K at Pressures up to 800 MPa. J. Phys. Chem. Ref. Data, 25(6) pp. 1509-1596 1996.