(just a place-keeper for a pile tech note explaining reasoning, not well written)

Physical Interconnection

We're trying to enable two basic kinds of nodes: Board with 2 connectors and box with a pig-tail cable, e.g. a handheld throttle. But we don't want to rule out e.g. a board with two connectors and three pig-tails for attaching throttles, or anything else, hence the somewhat complex wording in this section.

The assignments to particular colors are for information only. These are the colors that users will encounter in the two popular ways of wiring commercial cables. If you're building a product using commercial cable, using one of these two color codes will reduce confusion, but most NMRAnet users will never need to refer to the colors in their cables.

The discussion of connecting in parallel is to make sure that all 8 wires go through a board, whether it's got connectors, pig-tail cables or a combination of the two, so long as it's got more than one connection to other nodes.

All 8 wires don't have to go through the board if there's only one connection, e.g. a throttle with a single jack or pig-tail cable with plug. In that case, only two pairs are required.

We want all 8 wires present so people can add power later, or we can define the reserved conductors later, and still use them. The 1A on interconnects is to make sure they're at least as robust as the connectors and cable.

If your product is providing power and has e.g. two jacks, you can either connect them together and provide a max of 0.5A to both, or separately power them up to 0.5A each. This is the only case where a conductor doesn't have to pass through the board as a continuous electrical circuit.

The 100V requirement on the reserved conductors is also there to make sure that when we later find a use for it, we don't blow up existing installations.

Power Supply

The power supply section is meant to define a 12V nominal system with wide margins on production and consumption of power over the UTP cable. We expect that nodes will use this power in a range of ways, including having local power regulation ranging from simple analog regulators through more advanced supplies that increase current and/or voltage. 12V was chosen to reduce heat loads when using the simplest regulators. The current limit was required by use of 1 conductor in UTP wiring.

We expect that most power-supplying and power-consuming boards will connect PWR_NEG and the 3/7 grounds. A good way to do this is a 10 ohm resistor and a 0.1uF capacitor in parallel, but a straight copper connection is within the letter of the requirement.

The power provisions are for low-power uses that can be conveniently handled over short lengths of cable. Boards are welcome to have other connectors for power. These other connectors can be anything not otherwise forbidden by some other standard, including terminal blocks, 2.1mm jacks, Anderson PowerPole connectors, or whatever else is considered useful for the specific market.

Note the effect of the "must withstand" logic is that power supply boards must be able to be connected to each other, even if their output voltages are not exactly the same. One way to handle this is an isolating diode on the PWR_POS output.