NodeID part   **suffix**   **Meaning**

NodeID part	suffix	Meaning
OpenLCB vnode*	0xFFFF	Emergency stop of all operations
OpenLCB vnode	0xFFF8	Node recorded a new log entry (see Logging protocol doc)
OpenLCB vnode	0xFE00	Ident button combination pressed
OpenLCB vnode	0x0201	Duplicate Node ID Detected
CBUS vnode*	(any)	CBUS short-ID equivalent events

* - "OpenLCB vnode" refers to a virtual node ID assigned for global fixed events, see NidAllocations spreadsheet

* - "CBUS vnode" refers to a virtual node ID assigned for CBUS-style "short events", see NidAllocations spreadsheet