Sheet1

	NodeID part	suffix	Meaning
	OpenLCB vnode*	0xFFFF	Emergency stop of all operations
	OpenLCB vnode	0xFE00	Ident button combination pressed
	OpenLCB vnode	0xFDnn 0xFD01	Indicate capabilities (nn is the capability) Node uses Display Protocol to make one or more displays available
xxxxxx means any node ID			
	xxxxxx	0xFFF8	Node recorded a new log entry (sample only)

^{* - &}quot;OpenLCB vnode" referrs to a virtual node assigned to OpenLCB used for global fixed events.