

#### **HIGHLIGHTS**

This section of the manual contains the following major topics:

21.1	Introduction	21-2
21.2	CAN Message Formats	21-4
21.3	ECAN Registers	21-8
21.4	ECAN Message Buffers	21-29
21.5	ECAN Operating Modes	21-33
21.6	Transmitting ECAN Messages	21-34
21.7	Receiving ECAN Messages	21-43
21.8	DMA Controller Configuration	21-57
21.9	Bit Timing	21-59
21.10	ECAN Error Management	21-63
21.11	ECAN Interrupts	21-65
21.12	ECAN Low-Power Modes	21-68
21.13	ECAN Time Stamping Using Input Capture	21-68
21.14	Register Maps	21-69
21.15	Related Application Notes	21-72
	Revision History	

Note:

This family reference manual section is meant to serve as a complement to device data sheets. Depending on the device variant, this manual section may not apply to all dsPIC33E/PIC24E devices.


Please consult the note at the beginning of the "Enhanced Controller Area Network (ECAN™)" chapter in the current device data sheet to check whether this document supports the device you are using.

Device data sheets and family reference manual sections are available for download from the Microchip Worldwide Web site at: http://www.microchip.com

#### 21.1 INTRODUCTION

The dsPIC33E/PIC24E Enhanced Controller Area Network (ECAN™) module implements the CAN Specification 2.0B, which is used primarily in industrial and automotive applications. This asynchronous serial data communication protocol provides reliable communications in an electrically noisy environment. Figure 21-1 illustrates a typical CAN bus topology.

Figure 21-1: Typical CAN Bus Network




The ECAN module supports the following key features:

- · Standards Compliance:
  - Full CAN 2.0B compliance
  - Programmable bit rate up to 1 Mbps
- Message Reception:
  - 32 message buffers all of which can be used for reception
  - 16 acceptance filters for message filtering
  - Three acceptance filter mask registers for message filtering
  - Automatic response to Remote Frame
  - Up to 32-message deep First-In-First-Out (FIFO) buffer
  - DeviceNet™ addressing support
  - Direct Memory Access (DMA) interface for message reception
- · Message Transmission:
  - Eight message buffers configurable for message transmission
  - User-defined priority levels for message buffers used for transmission
  - DMA interface for message transmission
- · Other Features:
  - Loopback, Listen All Messages and Listen-Only modes for self-test, system diagnostics and bus monitoring
  - Low-power operating modes

Figure 21-2 illustrates the general structure of the ECAN module and its interaction with the DMA Controller and device RAM.

**ECAN™** Interaction with DMA Figure 21-2:



#### 21.1.1 **ECAN Module**

The ECAN module consists of a protocol engine, message acceptance filters, and separate transmit and receive DMA interfaces. The protocol engine transmits and receives messages to and from the CAN bus (as per the CAN Specification 2.0B protocol). The user-configurable acceptance filters are used by the ECAN module to examine the received message and determine if it should be stored in the DMA message buffer or discarded.

For received messages, the receive DMA interface generates a receive data interrupt to initiate a DMA cycle. The receive DMA channel reads data from the CiRXD register and writes it into the message buffer.

For transmit messages, the transmit DMA interface generates a transmit data interrupt to start a DMA cycle. The transmit DMA channel reads from the message buffer and writes to the CiTXD register for message transmission.

#### 21.1.2 Message Buffers

The ECAN module supports up to 32 message buffers for storing data transmitted or received on the CAN bus. These buffers can be located anywhere in device RAM (start address of the buffer may be needed to be aligned on an address boundary). Message buffers 0-7 can be configured for either transmit or receive operation. Message buffers 8-31 are receive-only buffers and cannot be used for message transmission.

#### 21.1.3 **DMA Controller**

The DMA controller acts as an interface between the message buffers and ECAN to transfer data back and forth without CPU intervention. The DMA controller supports up to 15 channels for transferring data between the device RAM and the dsPIC33E/PIC24E device peripherals. Two separate DMA channels are required to support the CAN message transmission and the CAN message reception.


Each DMA channel has a DMA Request register (DMAxREQ), which is used by the user application to assign an interrupt event to trigger a DMA-based message transfer.

#### 21.2 CAN MESSAGE FORMATS

The CAN bus protocol uses asynchronous communication. Information is passed from the transmitters to receivers in data frames, which are composed of byte fields that define the contents of the data frame as illustrated in Figure 21-3.

Each frame begins with a Start-of-Frame bit (SOF) and terminates with an End-of-Frame bit (EOF) field. The SOF is followed by the Arbitration and Control fields, which identify the message type, format, length and priority. This information allows each node on the CAN bus to respond appropriately to the message. The Data field conveys the message content and is of variable length, ranging from 0 bytes to eight bytes. Error protection is provided by the Cyclic Redundancy Check (CRC) and Acknowledgement (ACK) fields.

Figure 21-3: CAN Bus Message Frame



The CAN bus protocol supports four frame types:

- Data Frame carries data from transmitter to the receivers
- Remote Frame transmitted by a node on the bus, to request transmission of a data frame with the same identifier from another node
- Error Frame transmitted by any node when it detects an error
- Overload Frame provides an extra delay between successive Data or remote frames

Data frames and remote frames are separated from preceding frames by an Interframe Space. The CAN Specification 2.0B defines two additional data formats:

- Standard Data Frame intended for standard messages that use 11 identifier bits
- Extended Data Frame intended for extended messages that use 29 identifier bits

There are three CAN Specification versions:

- 2.0A considers 29-bit identifier as error
- · 2.0B Passive ignores 29-bit identifier messages
- · 2.0B Active handles both 11-bit and 29-bit identifiers

The dsPIC33E/PIC24E ECAN module is compliant with the CAN Specification 2.0B, while providing enhanced message filtering capabilities.

**Note:** For detailed information on the CAN bus protocol, refer to the Bosch CAN Specification.

#### 21.2.1 Standard Data Frame

The standard data frame message begins with an SOF bit followed by a 12-bit Arbitration field as shown in Figure 21-4. The Arbitration field contains an 11-bit identifier and RTR bit. The identifier defines the type of information contained in the message, and is used by each receiving node to determine if the message is of interest to it. The RTR bit distinguishes a data frame from a remote frame. For a standard data frame, the RTR bit is clear.

Following the Arbitration field is a 6-bit Control field, which provides more information about the contents of the message. The first bit in the Control field is an Identifier Extension bit (IDE), which distinguishes the message as either a standard data frame or extended data frame. A standard data frame is indicated by a dominant state (logic level '0') during transmission of the IDE bit. The second bit in the Control field is a reserved (RB0) bit, which is in the dominant state (logic level '0'). The last four bits in the Control field represent the Data Length Code (DLC), which specifies the number of data bytes present in the message.


The Data field follows the Control field. This field carries the message data – the actual payload of the data frame. This field is of variable length, ranging from 0 byte to eight bytes. The number of bytes is user-selectable.

The Data field is followed by the CRC field, which is a 16-bit CRC sequence with one delimiter bit.

The Acknowledgement (ACK) field is sent as a recessive bit (logic level '1'), and is overwritten as a dominant bit by any receiver that has received the data correctly. The message is acknowledged by the receiver regardless of the result of the acceptance filter comparison.

The last field is the EOF field, which consists of seven recessive bits that indicate the end of message.

Figure 21-4: Format of the Standard Data Frame




#### 21.2.2 Extended Data Frame

The extended data frame begins with an SOF bit followed by a 31-bit Arbitration field as illustrated in Figure 21-5. The Arbitration field in an extended data frame contains 29-bit identifier in two fields separated by a Substitute Remote Request bit (SRR) and an IDE bit. The SRR bit determines if the message is a remote frame (SRR = 1 for extended data frames). The IDE bit indicates the data frame type. For the extended data frame, IDE = 1.

The extended data frame Control field consists of seven bits. The first bit is the RTR. For the extended data frame, RTR = 0. The next two bits, RB1, and RB0, are reserved bits that are in the dominant state (logic level '0'). The last four bits in the Control field are the DLC, which specifies the number of data bytes present in the message.

The remaining fields in an extended data frame are identical to a standard data frame.

Figure 21-5: Format of the Extended Data Frame



#### 21.2.3 Remote Frame

A node expecting to receive data from another node can initiate transmission of the respective data by the source node, by sending a remote frame. A remote frame can be in the standard format (Figure 21-6) or the extended format (Figure 21-7).

A Remote frame is similar to a data frame, with the following exceptions:

- The RTR bit is recessive (RTR = 1)
- · There is no Data field
- The value of the DLC bits is  $0 \le DLC \le 8$

Figure 21-6: Format of the Standard Remote Frame





Figure 21-7: Format of the Extended Remote Frame



#### 21.2.4 Error Frame

An error frame is generated by any node that detects a bus error. An error frame consists of an Error Flag field followed by an Error Delimiter field. The Error Delimiter consists of eight recessive bits and allows the bus nodes to restart communication correctly after an error has occurred. There are two types of Error Flag fields, depending on the error status of the node that detects the error:

- Error Active Flag contains six consecutive dominant bits, which forces all other nodes
  on the network to generate Error Echo Flags, thereby resulting in a series of 6-12 dominant
  bits on the bus.
- Error Passive Flag contains six consecutive recessive bits, with the result that unless
  the bus error is detected by the transmitting node, the transmission of an Error Passive flag
  will not affect the communications of any other node on the network.

#### 21.2.5 Overload Frame

An Overload Frame can be generated by a node either when a dominant bit is detected during Interframe Space or when a node is not ready to receive the next message (for example, if it is still reading the previous received message). An Overload Frame has the same format as an Error Frame with an Active Error Flag, but can only be generated during Interframe Space. It consists of an Overload Flag field with six dominant bits followed by an Overload Delimiter field with eight recessive bits. A node can generate a maximum of two sequential Overload Frames to delay the start of the next message.

#### 21.2.6 Interframe Space

The Interframe Space separates the successive frames being transmitted on the CAN bus. It consists of at least three recessive bits, referred to as Intermission. The Interframe Space allows nodes time to internally process the previously received message before the start of the next frame. If the transmitting node is in the Error Passive state, additional eight recessive bits will be inserted in the Interframe Space before any other message is transmitted by the node. The additional eight recessive bits (also referred to as, Suspend Transmit field) allow time for other transmitting nodes to take control of the bus.

#### 21.3 ECAN REGISTERS

The ECAN module has a large number of Special Function Registers (SFRs) that are used to configure the message acceptance filters and the message buffers. To enable effective use of data RAM space, multiple sets of SFRs are mapped onto the same set of memory addresses. The SFR Map Window Select bit (WIN) in ECAN Control Register 1 (CiCTRL1<0>) is used to selectively access one of these sets of SFRs.

If CiCTRL1<0> = 1, the message acceptance filters, masks and filter buffer pointer registers are accessed by the user application.

If CiCTRL1<0> = 0, the buffer control and status registers, and the transmit and receive data registers are accessed by the user application.

#### 21.3.1 ECAN Baud Rate Control Registers

CiCFG1: ECAN Baud Rate Configuration Register 1

This register contains control bits to set the period of each time quantum (TQ), using the baud rate prescaler, and specifies synchronization jump width in terms of time quanta (see Register 21-1).

Note:

Each dsPIC33E/PIC24E family device variant may have one or more ECAN modules. An 'i' used in the names of pins, control/status bits and registers denotes the particular ECAN module number. Refer to the "Enhanced Controller Area Network (ECAN™)" chapter in the specific device data sheet for the number of available ECAN modules.

CiCFG2: ECAN Baud Rate Configuration Register 2

This register is used to program the number of time quanta in each CAN bit segment, including the propagation, and phase segments 1 and 2 (see Register 21-2).

#### 21.3.2 ECAN Message Filter Registers

CiFEN1: ECAN Acceptance Filter Enable Register

This register enables/disables acceptance filters 0-15 for message filtering (see Register 21-3).

CiRXFnSID: ECAN Acceptance Filter Standard Identifier Register n (n = 0-15)

These 16 registers specify the standard identifier (SID) for acceptance filters 0-15. The identifier bits are selectively masked against the incoming message identifier to determine if the message should be accepted or rejected (see Register 21-4). These registers are only accessible by the user application when the WIN bit is set (CiCTRL1<0> = 1 = use buffer window).

• CIRXFnEID: ECAN Acceptance Filter Extended Identifier Register n (n = 0-15)

These 16 registers specify the extended identifier (EID) for acceptance filters 0-15. The identifier bits are selectively masked against the incoming message identifier to determine if the message should be accepted or rejected (see Register 21-5). These registers are only accessible by the user application when the WIN bit is set (CiCTRL1<0> = 1).

CiRXMnSID: ECAN Acceptance Filter Mask Standard Identifier Register n (n = 0-2)

These three registers specify the SID mask bits for Acceptance Masks 0, 1 and 2. Any acceptance filter can optionally select one of these mask registers to selectively compare the identifier bits (see Register 21-6). These registers are only accessible by the user application when the WIN bit is set (CiCTRL1<0> = 1).

CIRXMnEID: ECAN Acceptance Filter Mask Extended Identifier Register n (n = 0-2)

There are three pairs of registers that specify Acceptance Mask bits for Mask 0, 1 and 2. Any acceptance filter can optionally select one of the mask registers to selectively compare the identifier bits (see Register 21-7). These registers are only accessible by the user application when the WIN bit is set (CiCTRL1<0> = 1).

#### CiFMSKSEL1: ECAN Filter 7-0 Mask Selection Register

This register is used with CiFMSKSEL2 to select the Acceptance mask for acceptance filter 0-7 (see Register 21-8).

#### CiFMSKSEL2: ECAN Filter 15-8 Mask Selection Register

This register is used with CiFMSKSEL1 to select the Acceptance mask for acceptance filter 8-15 (see Register 21-9).

#### CiBUFPNT1: ECAN Filter 0-3 Buffer Pointer Register

This register is used to specify the message buffer to be used for storing messages accepted by acceptance filters 0-3 (see Register 21-10). This register is only accessible by the user application when the WIN bit is set (CiCTRL1<0> = 1).

#### CiBUFPNT2: ECAN Filter 4-7 Buffer Pointer Register

This register is used to specify the message buffer to be used for storing messages accepted by acceptance filters 4-7 (see Register 21-11). This register is only accessible by the user application when the WIN bit is set (CiCTRL1<0> = 1).

#### CiBUFPNT3: ECAN Filter 8-11 Buffer Pointer Register

This register is used to specify the message buffer to be used for storing messages accepted by acceptance filters 8-11 (see Register 21-12). This register is only accessible by the user application when the WIN bit is set (CiCTRL1<0> = 1).

#### CiBUFPNT4: ECAN Filter 12-15 Buffer Pointer Register

This register is used to specify the message buffer to be used for storing messages accepted by acceptance filters 12-15 (see Register 21-13). This register is only accessible by the user application when the WIN bit is set (CiCTRL1<0> = 1).

#### **ECAN Message Buffer Status Registers** 21.3.3

#### CiRXFUL1: ECAN Receive Buffer Full Register 1

Paired with CiRXFUL2, this register indicates the buffer full status for message buffers 0-31. When a received message is stored into a message buffer, the respective buffer full flag is set (see Register 21-14). This register is only accessible by the user application when the WIN bit is cleared (CiCTRL1<0> = 0).

#### CiRXFUL2: ECAN Receive Buffer Full Register 2

Paired with CiRXFUL1, this register indicates the buffer full status for message buffers 0-31. When a received message is stored into a message buffer, the respective buffer full flag is set (see Register 21-15). This register is only accessible by the user application when the WIN bit is cleared (CiCTRL1<0> = 0).

#### CiRXOVF1: ECAN Receive Buffer Overflow Register 1

Paired with CiRXOVF2, this register indicates the overflow status for message buffers 0-31. When a received message is stored into a message buffer and the respective buffer full flag is set, the message is lost, and the respective buffer overflow flag is set (see Register 21-16). This register is only accessible by the user application when the WIN bit is cleared (CiCTRL1<0> = 0).

#### CiRXOVF2: ECAN Receive Buffer Overflow Register 2

Paired with CiRXOVF1, this register indicates the overflow status for message buffers 0-31. When a received message is stored into a message buffer and the respective buffer full flag is set, the message is lost, and the respective buffer overflow flag is set (see Register 21-17). This register is only accessible by the user application when the WIN bit is cleared (CiCTRL1<0> = 0).

#### 21.3.4 ECAN FIFO Control/Status Registers

#### • CiFCTRL: ECAN FIFO Control Register

This register controls operation of the receive buffer FIFO. It specifies the FIFO start address and the number of message buffers reserved for ECAN in the device RAM (see Register 21-18). This register is only accessible by the user application when the WIN bit is cleared (CiCTRL1<0> = 0).

#### CiFIFO: ECAN FIFO Status Register

This register contains write and read pointers. The write pointer indicates which buffer contains the most-recently received data. The read pointer tells the user application which buffer to read next (see Register 21-19). This register is only accessible by the user application when the WIN bit is cleared (CiCTRL1<0> = 0).

#### 21.3.5 ECAN Interrupt Control/Status Registers

#### • CilNTF: ECAN Interrupt Flag Register

This register provides the status of various interrupt sources in the ECAN module (see Register 21-20). This register is only accessible by the user application when the WIN bit is cleared (CiCTRL1<0> = 0).

#### CiINTE: ECAN Interrupt Enable Register<sup>(1)</sup>

This register is used to selectively enable/disable the seven main sources of interrupt: transmit buffer interrupt, receive buffer interrupt, receive buffer overflow interrupt, FIFO almost full interrupt, error interrupt, wake-up interrupt, and invalid message received interrupt (see Register 21-21). This register is only accessible by the user application when the WIN bit is cleared (CiCTRL1<0> = 0).

#### · CiVEC: ECAN Interrupt Code Register

This register provides interrupt code bits that can be used with a jump table for efficient handling of interrupts (see Register 21-22). This register is only accessible by the user application when the WIN bit is cleared (CiCTRL1<0> = 0).

#### 21.3.6 ECAN Control and Error Counter Registers

#### CiCTRL1: ECAN Control Register 1

This register sets the ECAN module operation modes (see Register 21-23). This register is only accessible by the user application when the WIN bit is cleared (CiCTRL1<0> = 0).

#### CiCTRL2: ECAN Control Register 2

This register contains the DeviceNet™ filtering control bits (see Register 21-24).

#### • CiTRmnCON: ECAN TX/RX Buffer m Control Register (m = 0,2,4,6; n = 1,3,5,7)

These registers configure and control the message buffers (see Register 21-25).

#### CiEC: ECAN Transmit/Receive Error Count Register

This register counts the transmit and receive errors. The user application can read this register to determine the current number of transmit and receive errors (see Register 21-26).

#### CiRXD: ECAN Receive Data Register

This register temporarily holds every received word. This is the register from which the DMA controller reads data into the DMA buffer.

#### CiTXD: ECAN Transmit Data Register

This register temporarily holds every transmission. This is the register to which the DMA Controller writes data from the DMA buffer.

#### Register 21-1: CiCFG1: ECAN Baud Rate Configuration Register 1

U-0	U-0	U-0	U-0	U-0	U-0	U-0	U-0
_	_	_	_	_	_	_	_
bit 15							bit 8

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0
SJW<1:0>				BRP	P<5:0>		
bit 7							bit 0

Legend:			
R = Readable bit	W = Writable bit	U = Unimplemented bit, read	l as '0'
-n = Value at POR	'1' = Bit is set	'0' = Bit is cleared	x = Bit is unknown

**Note 1:** FCAN is either FP or twice FP depending on the CANCKS bit (CiCTRL<11>) selection.

#### Register 21-2: CiCFG2: ECAN Baud Rate Configuration Register 2

U-0	R/W-x	U-0	U-0	U-0	R/W-x	R/W-x	R/W-x
_	WAKFIL	_	_	_	;	SEG2PH<2:0>	
bit 15							bit 8

R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x
SEG2PHTS	SAM	;	SEG1PH<2:0>	•		PRSEG<2:0>	
bit 7							bit 0

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15 Unimplemented: Read as '0'

bit 14 WAKFIL: Select CAN Bus Line Filter for Wake-up bit

1 = Use CAN bus line filter for wake-up

0 = CAN bus line filter is not used for wake-up

bit 13-11 Unimplemented: Read as '0'

bit 10-8 **SEG2PH<2:0>:** Phase Segment 2 bits

111 = Length is 8 x TQ

.

•

 $000 = \text{Length is } 1 \times \text{TQ}$ 

bit 7 SEG2PHTS: Phase Segment 2 Time Select bit

1 = Freely programmable

0 = Maximum of SEG1PH bits or Information Processing Time (IPT), whichever is greater

bit 6 SAM: Sample CAN Bus Line bit

1 = Bus line is sampled three times at the sample point

0 = Bus line is sampled once at the sample point

bit 5-3 SEG1PH<2:0>: Phase Segment 1 bits

111 = Length is 8 x TQ

•

000 = Length is 1 x TQ

bit 2-0 PRSEG<2:0>: Propagation Time Segment bits

111 = Length is 8 x TQ

•

•

•

 $000 = \text{Length is } 1 \times \text{TQ}$ 

#### CiFEN1: ECAN Acceptance Filter Enable Register Register 21-3:

R/W-1	R/W-1	R/W-1	R/W-1	R/W-1	R/W-1	R/W-1	R/W-1		
FLTEN<15:8>									
bit 15									

R/W-1	R/W-1	R/W-1	R/W-1	R/W-1	R/W-1	R/W-1	R/W-1			
	FLTEN<7:0>									
bit 7 bit 0										

Legend:

R = Readable bit U = Unimplemented bit, read as '0' W = Writable bit

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-0 **FLTENn:** Enable Filter n bits (n = 0-15)

1 = Enable filter n to accept messages

0 = Disable filter n

#### Register 21-4: CiRXFnSID: ECAN Acceptance Filter Standard Identifier Register n (n = 0-15)

R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x
SID10	SID9	SID8	SID7	SID6	SID5	SID4	SID3
bit 15							bit 8

R/W-x	R/W-x	R/W-x	U-0	R/W-x	U-0	R/W-x	R/W-x
SID2	SID1	SID0	_	EXIDE <sup>(1)</sup>	_	EID17	EID16
bit 7							bit 0

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-5 SID<10:0>: Standard Identifier bits

> 1 = Message address bit, SIDx, must be '1' to match filter 0 = Message address bit, SIDx, must be '0' to match filter

bit 4 Unimplemented: Read as '0'

**EXIDE:** Extended Identifier Enable bit<sup>(1)</sup> bit 3

If MIDE = 1:

1 = Match only messages with extended identifier addresses

0 = Match only messages with standard identifier addresses

If MIDE = 0: Ignore EXIDE bit.

bit 2 Unimplemented: Read as '0'

bit 1-0 EID<17:16>: Extended Identifier bits

1 = Message address bit, EIDx, must be '1' to match filter

0 = Message address bit, EIDx, must be '0' to match filter

If no mask is applied to a filter, the following occurs: The filter accepts only standard frames. The filter does not accept extended frames even if the EXIDE bit is set to '1'.

#### Register 21-5: CiRXFnEID: ECAN Acceptance Filter Extended Identifier Register n (n = 0-15)

R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x			
EID<15:8>										
bit 15	bit 15 bit 8									

R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x		
EID<7:0>									
bit 7									

#### Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

#### bit 15-0 **EID<15:0>:** Extended Identifier bits

1 = Message address bit, EIDx, must be '1' to match filter

0 = Message address bit, EIDx, must be '0' to match filter

#### Register 21-6: CIRXMnSID: ECAN Acceptance Filter Mask Standard Identifier Register n (n = 0-2)

R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x
SID10	SID9	SID8	SID7	SID6	SID5	SID4	SID3
bit 15							bit 8

R/W-x	R/W-x	R/W-x	U-0	R/W-x	U-0	R/W-x	R/W-x
SID2	SID1	SID0	_	MIDE	_	EID17	EID16
bit 7							bit 0

#### Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-5 SID<10:0>: Standard Identifier bits

1 = Include bit, SIDx, in filter comparison

0 = Bit, SIDx, is a "don't care" in filter comparison

bit 4 Unimplemented: Read as '0'

bit 3 MIDE: Identifier Receive Mode bit

1 = Match only message types (standard or extended address) that correspond to EXIDE bit in filter

0 = Match either standard or extended address message if filters match

(that is, if (Filter SID) = (Message SID), or if (Filter SID/EID) = (Message SID/EID))

bit 2 Unimplemented: Read as '0'

bit 1-0 **EID<17:16>:** Extended Identifier bits

1 = Include bit, EIDx, in filter comparison

0 = Bit, EIDx, is a don't care in filter comparison

#### Register 21-7: CiRXMnEID: ECAN Acceptance Filter Mask Extended Identifier Register n (n = 0-2)

R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x		
EID<15:8>									
bit 15							bit 8		

R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x		
EID<7:0>									
bit 7							bit 0		

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-0 **EID<15:0>:** Extended Identifier bits

1 = Include bit, EIDx, in filter comparison

0 = Bit, EIDx, is a "don't care" in filter comparison

#### Register 21-8: CiFMSKSEL1: ECAN Filter 7-0 Mask Selection Register

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	
F7MSł	<<1:0>	F6MSł	F6MSK<1:0>		F5MSK<1:0>		F4MSK<1:0>	
bit 15							bit 8	

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0
F3MSk	<1:0> F2MSK<1:0>		<<1:0>	F1MSK<1:0>		F0MSK<1:0>	
bit 7							bit 0

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-14 F7MSK<1:0>: Mask Source for Filter 7 bits

11 = Reserved; do not use

10 = Acceptance Mask 2 registers contain mask

01 = Acceptance Mask 1 registers contain mask

	00 = Acceptance Mask 0 registers contain mask
bit 13-12	<b>F6MSK&lt;1:0&gt;:</b> Mask Source for Filter 6 bits (same values as bits 15-14)
bit 11-10	<b>F5MSK&lt;1:0&gt;:</b> Mask Source for Filter 5 bits (same values as bits 15-14)
bit 9-8	<b>F4MSK&lt;1:0&gt;:</b> Mask Source for Filter 4 bits (same values as bits 15-14)
bit 7-6	<b>F3MSK&lt;1:0&gt;:</b> Mask Source for Filter 3 bits (same values as bits 15-14)
bit 5-4	<b>F2MSK&lt;1:0&gt;:</b> Mask Source for Filter 2 bits (same values as bits 15-14)
bit 3-2	<b>F1MSK&lt;1:0&gt;:</b> Mask Source for Filter 1 bits (same values as bits 15-14)
bit 1-0	<b>F0MSK&lt;1:0&gt;:</b> Mask Source for Filter 0 bits (same values as bits 15-14)

#### Register 21-9: CiFMSKSEL2: ECAN Filter 15-8 Mask Selection Register

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0
F15MS	F15MSK<1:0> F14MSK<1:		K<1:0>	F13MS	F13MSK<1:0>		SK<1:0>
bit 15		•				•	bit 8

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0
F11MS	MSK<1:0> F10MSK		K<1:0>	F9MS	SK<1:0>	F8MSI	<<1:0>
bit 7							bit 0

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-14 F15MSK<1:0>: Mask Source for Filter 15 bits

11 = Reserved; do not use

10 = Acceptance Mask 2 registers contain mask 01 = Acceptance Mask 1 registers contain mask 00 = Acceptance Mask 0 registers contain mask

bit 13-12 **F14MSK<1:0>:** Mask Source for Filter 14 bits (same values as bits 15-14) bit 11-10 **F13MSK<1:0>:** Mask Source for Filter 13 bits (same values as bits 15-14)

bit 9-8 F12MSK<1:0>: Mask Source for Filter 12 bits (same values as bits 15-14)

bit 7-6 **F11MSK<1:0>:** Mask Source for Filter 11 bits (same values as bits 15-14) bit 5-4 **F10MSK<1:0>:** Mask Source for Filter 10 bits (same values as bits 15-14)

bit 3-2 **F9MSK<1:0>:** Mask Source for Filter 9 bits (same values as bits 15-14)

bit 1-0 F8MSK<1:0>: Mask Source for Filter 8 bits (same values as bits 15-14)

#### Register 21-10: CiBUFPNT1: ECAN Filter 0-3 Buffer Pointer Register

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	
	F3BP<	3:0>		F2BP<3:0>				
bit 15							bit 8	

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	
	F1BP<	<3:0>		F0BP<3:0>				
bit 7							bit 0	

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-12 F3BP<3:0>: RX Buffer Mask for Filter 3 bits

1111 = Filter hits received in RX FIFO buffer

1110 = Filter hits received in RX Buffer 14

•

0001 = Filter hits received in RX Buffer 1

0000 = Filter hits received in RX Buffer 0

bit 11-8 F2BP<3:0>: RX Buffer mask for Filter 2 bits (same values as bits 15-12)

bit 7-4 **F1BP<3:0>:** RX Buffer mask for Filter 1 bits (same values as bits 15-12)

bit 3-0 **F0BP<3:0>:** RX Buffer mask for Filter 0 bits (same values as bits 15-12)

#### Register 21-11: CiBUFPNT2: ECAN Filter 4-7 Buffer Pointer Register

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	
	F7BP<	<3:0>		F6BP<3:0>				
bit 15							bit 8	

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	
	F5BP<	<3:0>		F4BP<3:0>				
bit 7							bit 0	

Legend:

R = Readable bit U = Unimplemented bit, read as '0' W = Writable bit

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-12 F7BP<3:0>: RX Buffer mask for Filter 7 bits

1111 = Filter hits received in RX FIFO buffer

1110 = Filter hits received in RX Buffer 14

0001 = Filter hits received in RX Buffer 1

0000 = Filter hits received in RX Buffer 0

bit 11-8 F6BP<3:0>: RX Buffer mask for Filter 6 bits (same values as bits 15-12)

bit 7-4 F5BP<3:0>: RX Buffer mask for Filter 5 bits (same values as bits 15-12)

bit 3-0 F4BP<3:0>: RX Buffer mask for Filter 4 bits (same values as bits 15-12)

#### Register 21-12: CiBUFPNT3: ECAN Filter 8-11 Buffer Pointer Register

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	
	F11BP	<3:0>		F10BP<3:0>				
bit 15							bit 8	

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	
	F9BP<	<3:0>		F8BP<3:0>				
bit 7							bit 0	

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

'0' = Bit is cleared -n = Value at POR '1' = Bit is set x = Bit is unknown

bit 15-12 F11BP<3:0>: RX Buffer mask for Filter 11

1111 = Filter hits received in RX FIFO buffer

1110 = Filter hits received in RX Buffer 14

0001 = Filter hits received in RX Buffer 1 0000 = Filter hits received in RX Buffer 0

bit 11-8 F10BP<3:0>: RX Buffer mask for Filter 10 (same values as bit 15-12) bit 7-4

F9BP<3:0>: RX Buffer mask for Filter 9 (same values as bit 15-12)

bit 3-0 F8BP<3:0>: RX Buffer mask for Filter 8 (same values as bit 15-12)

#### Register 21-13: CiBUFPNT4: ECAN Filter 12-15 Buffer Pointer Register

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	
	F15BP	<3:0>		F14BP<3:0>				
bit 15							bit 8	

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	
	F13BP	<3:0>		F12BP<3:0>				
bit 7							bit 0	

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-12 F15BP<3:0>: RX Buffer mask for Filter 15 bits

1111 = Filter hits received in RX FIFO buffer

1110 = Filter hits received in RX Buffer 14

•

٠

•

0001 = Filter hits received in RX Buffer 1 0000 = Filter hits received in RX Buffer 0

bit 11-8 F14BP<3:0>: RX Buffer mask for Filter 14 bits (same values as bits 15-12) bit 7-4 F13BP<3:0>: RX Buffer mask for Filter 13 bits (same values as bits 15-12)

bit 3-0 F12BP<3:0>: RX Buffer mask for Filter 12 bits (same values as bits 15-12)

#### Register 21-14: CiRXFUL1: ECAN Receive Buffer Full Register 1

R/C-0	R/C-0	R/C-0	R/C-0	R/C-0	R/C-0	R/C-0	R/C-0		
RXFUL<15:8>									
bit 15									

R/C-0	R/C-0	R/C-0	R/C-0	R/C-0	R/C-0	R/C-0	R/C-0				
	RXFUL<7:0>										
bit 7											

Legend:

R = Readable bit C = Writable bit, but only '0' can be written to clear the bit

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-0 RXFUL<15:0>: Receive Buffer n Full bits

1 = Buffer is full (set by module)

0 = Buffer is empty (cleared by software)

#### Register 21-15: CiRXFUL2: ECAN Receive Buffer Full Register 2

| R/C-0   |
|---------|---------|---------|---------|---------|---------|---------|---------|
| RXFUL31 | RXFUL30 | RXFUL29 | RXFUL28 | RXFUL27 | RXFUL26 | RXFUL25 | RXFUL24 |
| bit 15  |         |         |         |         |         |         | bit 8   |

| R/C-0   |
|---------|---------|---------|---------|---------|---------|---------|---------|
| RXFUL23 | RXFUL22 | RXFUL21 | RXFUL20 | RXFUL19 | RXFUL18 | RXFUL17 | RXFUL16 |
| bit 7   |         |         |         |         |         |         | bit 0   |

Legend:

R = Readable bit C = Writable bit, but only '0' can be written to clear the bit

'0' = Bit is cleared -n = Value at POR '1' = Bit is set x = Bit is unknown

bit 15-0 RXFUL<31:16>: Receive Buffer n Full bits

1 = Buffer is full (set by module)

0 = Buffer is empty (cleared by user software)

#### Register 21-16: CiRXOVF1: ECAN Receive Buffer Overflow Register 1

R/C-0	R/C-0	R/C-0	R/C-0	R/C-0	R/C-0	R/C-0	R/C-0		
RXOVF<15:8>									
bit 15									

R/C-0	R/C-0	R/C-0	R/C-0	R/C-0	R/C-0	R/C-0	R/C-0		
RXOVF<7:0>									
bit 7							bit 0		

Legend:

R = Readable bit C = Writable bit, but only '0' can be written to clear the bit

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-0 RXOVF<15:0>: Receive Buffer n Overflow bits

1 = Module attempted to write to a full buffer (set by module)

0 = No overflow condition (cleared by user software)

#### Register 21-17: CiRXOVF2: ECAN Receive Buffer Overflow Register 2

| R/C-0   |
|---------|---------|---------|---------|---------|---------|---------|---------|
| RXOVF31 | RXOVF30 | RXOVF29 | RXOVF28 | RXOVF27 | RXOVF26 | RXOVF25 | RXOVF24 |
| bit 15  |         |         |         |         |         |         | bit 8   |

| R/C-0   |
|---------|---------|---------|---------|---------|---------|---------|---------|
| RXOVF23 | RXOVF22 | RXOVF21 | RXOVF20 | RXOVF19 | RXOVF18 | RXOVF17 | RXOVF16 |
| bit 7   |         |         |         |         |         |         | bit 0   |

Legend:

C = Writable bit, but only '0' can be written to clear the bit R = Readable bit

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-0 RXOVF<31:16>: Receive Buffer n Overflow bits

1 = Module attempted to write to a full buffer (set by module)

0 = No overflow condition (cleared by user software)

#### Register 21-18: CiFCTRL: ECAN FIFO Control Register

R/W-0	R/W-0	R/W-0	U-0	U-0	U-0	U-0	U-0
	DMABS<2:0>		_	_	_	_	_
bit 15							bit 8

U-0	U-0	U-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0
_	_	_			FSA<4:0>		
bit 7							bit 0

Legend:			
R = Readable bit	W = Writable bit	U = Unimplemented bit, read	d as '0'
-n = Value at POR	'1' = Bit is set	'0' = Bit is cleared	x = Bit is unknown

bit 15-13 **DMABS<2:0>:** Message Buffer Size bits

111 = Reserved; do not use

110 = 32 buffers in device RAM

101 = 24 buffers in device RAM

100 = 16 buffers in device RAM

011 = 12 buffers in device RAM

010 = Eight buffers in device RAM

001 = Six buffers in device RAM

000 = Four buffers in device RAM

bit 12-5 **Unimplemented:** Read as '0' bit 4-0 **FSA<4:0>:** FIFO Start Area bits

11111 = Read buffer RB31

11110 = Read buffer RB30

•

•

00010 = TX/RX buffer TRB2

00001 = TX/RX buffer TRB1

00000 = TX/RX buffer TRB0

#### Register 21-19: CiFIFO: ECAN FIFO Status Register

U-0	U-0	R-0	R-0	R-0	R-0	R-0	R-0
_	_			FBP	<5:0>		
bit 15							bit 8

U-0	U-0	R-0	R-0	R-0	R-0	R-0	R-0
_	_			FNRI	B<5:0>		
bit 7							bit 0

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-14 Unimplemented: Read as '0'

bit 13-8 **FBP<5:0>:** FIFO Buffer Pointer bits

011111 = RB31 buffer 011110 = RB30 buffer

•

•

•

000001 = TRB1 buffer 000000 = TRB0 buffer

bit 7-6 **Unimplemented:** Read as '0'

bit 5-0 FNRB<5:0>: FIFO Next Read Buffer Pointer bits

011111 = RB31 buffer 011110 = RB30 buffer

•

•

-

000001 = TRB1 buffer 000000 = TRB0 buffer

### Register 21-20: CilNTF: ECAN Interrupt Flag Register

U-0	U-0	R-0	R-0	R-0	R-0	R-0	R-0
_	_	TXBO	TXBP	RXBP	TXWAR	RXWAR	EWARN
bit 15							bit 8

R/C-0	R/C-0	R/C-0	U-0	R/C-0	R/C-0	R/C-0	R/C-0
IVRIF	WAKIF	ERRIF	_	FIFOIF	RBOVIF	RBIF	TBIF
bit 7							bit 0

Legend:	C = Writable bit, but only '0	C = Writable bit, but only '0' can be written to clear the bit					
R = Readable bit	W = Writable bit	U = Unimplemented bit, read	l as '0'				
-n = Value at POR	'1' = Bit is set	'0' = Bit is cleared	x = Bit is unknown				

bit 15-14	Unimplemented: Read as '0'
bit 13	<b>TXBO:</b> Transmitter in Error State Bus OFF bit
	1 = Transmitter is in Bus OFF state
	0 = Transmitter is not in Bus OFF state
bit 12	<b>TXBP:</b> Transmitter in Error State Bus Passive bit
	1 = Transmitter is in Bus Passive state 0 = Transmitter is not in Bus Passive state
bit 11	RXBP: Receiver in Error State Bus Passive bit
DIL 11	1 = Receiver is in Bus Passive state
	0 = Receiver is not in Bus Passive state
bit 10	TXWAR: Transmitter in Error State Warning bit
	1 = Transmitter is in Error Warning state
	0 = Transmitter is not in Error Warning state
bit 9	RXWAR: Receiver in Error State Warning bit
	<ul><li>1 = Receiver is in Error Warning state</li><li>0 = Receiver is not in Error Warning state</li></ul>
bit 8	<b>EWARN:</b> Transmitter or Receiver in Error State Warning bit
Dit O	1 = Transmitter or receiver is in Error State Warning state
	0 = Transmitter or receiver is not in Error State Warning state
bit 7	IVRIF: Invalid Message Interrupt Flag bit
	1 = Interrupt request has occurred
1 '' 0	0 = Interrupt request has not occurred
bit 6	WAKIF: Bus Wake-up Activity Interrupt Flag bit  1 = Interrupt request has occurred
	0 = Interrupt request has not occurred
bit 5	<b>ERRIF:</b> Error Interrupt Flag bit (multiple sources in CiINTF<13:8> bits)
	1 = Interrupt request has occurred
	0 = Interrupt request has not occurred
bit 4	Unimplemented: Read as '0'
bit 3	FIFOIF: FIFO Almost Full Interrupt Flag bit
	1 = Interrupt request has occurred
F# 0	0 = Interrupt request has not occurred
bit 2	RBOVIF: RX Buffer Overflow Interrupt Flag bit  1 = Interrupt request has occurred
	0 = Interrupt request has not occurred
bit 1	RBIF: RX Buffer Interrupt Flag bit
	1 = Interrupt request has occurred
	0 = Interrupt request has not occurred
bit 0	TBIF: TX Buffer Interrupt Flag bit
	1 = Interrupt request has occurred 0 = Interrupt request has not occurred
	U - Interrupt request has not occurred

#### Register 21-21: CilNTE: ECAN Interrupt Enable Register<sup>(1)</sup>

U-0	U-0	U-0	U-0	U-0	U-0	U-0	U-0
_	_	_	_	_	_	_	_
bit 15							bit 8

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0
IVRIE	WAKIE	ERRIE	_	FIFOIE	RBOVIE	RBIE	TBIE
bit 7							bit 0

Legend:

bit 5

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-8 **Unimplemented:** Read as '0'

bit 7 IVRIE: Invalid Message Interrupt Enable bit

1 = Interrupt request enabled0 = Interrupt request not enabled

bit 6 WAKIE: Bus Wake-up Activity Interrupt Flag bit

1 = Interrupt request enabled0 = Interrupt request not enabledERRIE: Error Interrupt Enable bit

1 = Interrupt request enabled0 = Interrupt request not enabled

bit 4 **Unimplemented:** Read as '0'

bit 3 FIFOIE: FIFO Almost Full Interrupt Enable bit

1 = Interrupt request enabled0 = Interrupt request not enabled

bit 2 RBOVIE: RX Buffer Overflow Interrupt Enable bit

1 = Interrupt request enabled0 = Interrupt request not enabled

bit 1 RBIE: RX Buffer Interrupt Enable bit

1 = Interrupt request enabled0 = Interrupt request not enabled

bit 0 TBIE: TX Buffer Interrupt Enable bit

1 = Interrupt request enabled0 = Interrupt request not enabled

**Note 1:** Setting a bit in the CilNTE register only enables the corresponding interrupt source. To generate a Ci interrupt, the CilE bit must be set in the Interrupt module.

#### Register 21-22: CiVEC: ECAN Interrupt Code Register

U-0	U-0	U-0	R-0	R-0	R-0	R-0	R-0
_	_	_			FILHIT<4:0>	_	
bit 15							bit 8

U-0	R-1	R-0	R-0	R-0	R-0	R-0	R-0
_				ICODE<6:0>(1,	,2)		
bit 7							bit 0

Legend:R = Readable bitW = Writable bitU = Unimplemented bit, read as '0'-n = Value at POR'1' = Bit is set'0' = Bit is clearedx = Bit is unknown

```
bit 15-13
               Unimplemented: Read as '0'
bit 12-8
               FILHIT<4:0>: Filter Hit Number bits
               10000-11111 = Reserved; do not use
               01111 = Filter 15
               00001 = Filter 1
               00000 = Filter 0
bit 7
               Unimplemented: Read as '0'
               ICODE<6:0>: Interrupt Flag Code bits<sup>(1,2)</sup>
bit 6-0
               1000101-1111111 = Reserved; do not use
               1000100 = FIFO almost full interrupt
               1000011 = Receiver overflow interrupt
               1000010 = Wake-up interrupt
               1000001 = Error interrupt
               1000000 = No interrupt
               0100000-0111111 = Reserved; do not use
               0011111 = RB31 buffer Interrupt
               0011110 = RB30 buffer Interrupt
               0001001 = RB9 buffer interrupt
               0001000 = RB8 buffer interrupt
               0000111 = TRB7 buffer interrupt
               0000110 = TRB6 buffer interrupt
               0000101 = TRB5 buffer interrupt
               0000100 = TRB4 buffer interrupt
               0000011 = TRB3 buffer interrupt
               0000010 = TRB2 buffer interrupt
               0000001 = TRB1 buffer interrupt
               0000000 = TRB0 Buffer interrupt
```

- **Note 1:** The ICODE<6:0> bits are cleared when the corresponding interrupts flag bits in the CiINTF register are cleared.
  - 2: The ICODE<6:0> bits only reflect the status of enabled interrupt sources. The corresponding bits in the CilNTE register must be set.

#### Register 21-23: CiCTRL1: ECAN Control Register 1

U-0	U-0	R/W-0	R/W-0	R/W-0	R/W-1	R/W-0	R/W-0
_	_	CSIDL	ABAT	CANCKS		REQOP<2:0>	
bit 15							bit 8

R-1	R-0	R-0	U-0	R/W-0	U-0	U-0	R/W-0
	OPMODE<2:0>		_	CANCAP	_	_	WIN
bit 7							bit 0

Legend:	r = Reserved		
R = Readable bit	W = Writable bit	U = Unimplemented bit	, read as '0'
-n = Value at POR	'1' = Bit is set	'0' = Bit is cleared	x = Bit is unknown

bit 15-14 Unimplemented: Read as '0' bit 13 CSIDL: Stop in Idle Mode bit 1 = Discontinue module operation when device enters Idle mode 0 = Continue module operation in Idle mode bit 12 **ABAT:** Abort All Pending Transmissions bit 1 = Signal all transmit buffers to abort transmission 0 = Module will clear this bit when all transmissions are aborted bit 11 CANCKS: ECAN Module Clock (FCAN) Source Select bit 1 = FCAN is equal to 2 \* FP 0 = FCAN is equal to FP bit 10-8 REQOP<2:0>: Request Operation Mode bits 111 = Set Listen All Messages mode 110 = Reserved; do not use 101 = Reserved; do not use 100 = Set Configuration mode 011 = Set Listen-Only mode 010 = Set Loopback mode 001 = Set Disable mode 000 = Set Normal Operation mode bit 7-5 OPMODE<2:0>: Operation Mode bits 111 = Module is in Listen All Messages mode 110 = Reserved; do not use 101 = Reserved; do not use 100 = Module is in Configuration mode 011 = Module is in Listen-Only mode 010 = Module is in Loopback mode 001 = Module is in Disable mode

000 = Module is in Normal Operation modebit 4 Unimplemented: Read as '0'

bit 3

CANCAP: CAN Message Receive Timer Capture Event Enable bit

1 = Enable input capture based on CAN message receive

0 = Disable CAN capture

bit 2-1 **Unimplemented:** Read as '0' bit 0 **WIN:** SFR Map Window Select bit

1 = Use filter window0 = Use buffer window

#### Register 21-24: CiCTRL2: ECAN Control Register 2

U-0	U-0	U-0	U-0	U-0	U-0	U-0	U-0
_	_	_	_	_	_	_	_
bit 15							bit 8

U-0	U-0	U-0	R-0	R-0	R-0	R-0	R-0
_	_	_			DNCNT<4:0>		
bit 7							bit 0

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-5 **Unimplemented:** Read as '0'

bit 4-0 **DNCNT<4:0>:** DeviceNet™ Filter Bit Number bits

10011-11111 = Invalid selection

10010 = Compare bits <7:0> of byte 0 and bits <7:0> of byte 1 and bits <7:6> of byte 2 with EID<17:0>

10001 = Compare bits <7:0> of byte 0 and bits <7:0> of byte 1 and bit 7 of byte 2 with EID<17:1>

10000 = Compare bits <7:0> of data byte 0 and bits <7:0> of data byte 1 with EID<17:2>

01111 = Compare bits <7:0> of data byte 0 and bits <7:1> of data byte 1 with EID<17:3>

01110 = Compare bits <7:0> of data byte 0 and bits <7:2> of data byte 1 with EID<17:4>

01101 = Compare bits <7:0> of data byte 0 and bits <7:3> of data byte 1 with EID<17:5>

01100 = Compare bits <7:0> of data byte 0 and bits <7:4> of data byte 1 with EID<17:6>

01011 = Compare bits <7:0> of data byte 0 and bits <7:5> of data byte 1 with EID<17:7>

01010 = Compare bits <7:0> of data byte 0 and bits <7:6> of data byte 1 with EID<17:8>

01001 = Compare bits <7:0> of data byte 0 and bit <7> of data byte 1 with EID<17:9>

01000 = Compare bits <7:0> of data byte 0 with EID<17:10>

00111 = Compare bits <7:1> of data byte 0 with EID<17:11>

00110 = Compare bits <7:2> of data byte 0 with EID<17:12>

00101 = Compare bits <7:3> of data byte 0 with EID<17:13>

00100 = Compare bits <7:4> of data byte 0 with EID<17:14>

00011 = Compare bits <7:5> of data byte 0 with EID<17:15>

00010 = Compare bits <7:6> of data byte 0 with EID<17:16> 00001 = Compare bit 7 of data byte 0 with EID<17>

00000 = Do not compare data bytes

#### Register 21-25: CiTRmnCON: ECAN TX/RX Buffer m Control Register (m = 0,2,4,6; n = 1,3,5,7)

R/W-0	R-0	R-0	R-0	R/W-0	R/W-0	R/W-0	R/W-0
TXENn	TXABTn	TXLARBn	TXERRn	TXREQn	RTRENn	TXnPR	I<1:0>
bit 15							bit 8

R/W-0	R-0	R-0	R-0	R/W-0	R/W-0	R/W-0	R/W-0
TXENm	TXABTm <sup>(1)</sup>	TXLARBm <sup>(1)</sup>	TXERRm <sup>(1)</sup>	TXREQm	RTRENm	TXmPR	RI<1:0>
bit 7							bit 0

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-8 See definition for bits 7-0, Controls Buffer n

bit 7 TXENm: TX/RX Buffer Selection bit

1 = Buffer TRBn is a transmit buffer0 = Buffer TRBn is a receive buffer

bit 6 **TXABTm:** Message Aborted bit<sup>(1)</sup>

1 = Message was aborted

0 = Message completed transmission successfully

bit 5 **TXLARBm:** Message Lost Arbitration bit<sup>(1)</sup>

1 = Message lost arbitration while being sent

 $_{
m 0}$  = Message did not lose arbitration while being sent

bit 4 TXERRm: Error Detected During Transmission bit (1)

1 = A bus error occurred while the message was being sent

0 = A bus error did not occur while the message was being sent

bit 3 TXREQm: Message Send Request bit

1 = Requests that a message be sent. Once the message is successfully sent, the bit is automatically

leared.

0 = Setting this bit to '0' while a message is being sent, aborts the message transmission.

bit 2 RTRENm: Auto-Remote Transmit Enable bit

1 = When a remote frame is received, TXREQ bit will automatically set

0 = When a remote frame is received, TXREQ bit will be unaffected

bit 1-0 **TXmPRI<1:0>:** Message Transmission Priority bits

11 = Highest message priority

10 = High intermediate message priority

01 = Low intermediate message priority

00 = Lowest message priority

Note 1: This bit is cleared when the TXREQ bit is set.

#### Register 21-26: CiEC: ECAN Transmit/Receive Error Count Register

R-0	R-0	R-0	R-0	R-0	R-0	R-0	R-0	
TERRCNT<7:0>								
bit 15							bit 8	

R-0	R-0	R-0	R-0	R-0	R-0	R-0	R-0
			RERRC	NT<7:0>			
bit 7							bit 0

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-8 **TERRCNT<7:0>:** Transmit Error Count bits bit 7-0 **RERRCNT<7:0>:** Receive Error Count bits

#### Register 21-27: CiRXD: ECAN Receive Data Register

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0		
Received Data Word									
bit 15							bit 8		

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0
			Received	Data Word			
bit 7							bit 0

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-0 DATA<15:0>: Receive Data bits

#### Register 21-28: CiTXD: ECAN Transmit Data Register

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0
			Transmit [	Data Word			
bit 15							bit 8

R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0	R/W-0
			Transmit [	Data Word			
bit 7							bit 0

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-0 DATA<15:0>: Transmit Data bits

#### 21.4 ECAN MESSAGE BUFFERS

ECAN message buffers are located in device RAM. They are not ECAN SFRs. The user application must directly write into the device RAM area that is configured for ECAN message buffers. The location and size of the buffer area is defined by the user application.

This section provides information on how the message buffer words are organized for transmission and reception. (See also 21.2 "CAN Message Formats" for message buffer layout details and 21.8 "DMA Controller Configuration" for details on how to configure ECAN message buffers in device RAM).

#### Buffer 21-1: ECAN Message Buffer Word 0

U-x	U-x	U-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x
_	_	_			SID<10:6>		
bit 15							bit 8

| R/W-x |
|-------|-------|-------|-------|-------|-------|-------|-------|
|       |       | SID<  | 5:0>  |       |       | SRR   | IDE   |
| bit 7 |       |       |       |       |       |       | bit 0 |

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-13 Unimplemented: Read as '0'
bit 12-2 SID<10:0>: Standard Identifier bits
bit 1 SRR: Substitute Remote Request bit

When IDE = 0:

1 = In case of Transmission, this will cause a Remote Frame to be transmitted. In case of Received message, indicates a remote frame was received.

0 = Normal message When IDE = 1:

The SRR bit must be set to '1'

bit 0 **IDE:** Extended Identifier bit

- 1 = Message will transmit extended identifier or received message has an extended identifier
- 0 = Message will transmit standard identifier or received message has a standard identifier

#### Buffer 21-2: ECAN Message Buffer Word 1

U-x	U-x	U-x	U-x	R/W-x	R/W-x	R/W-x	R/W-x
_	_	_	_		EID<1	7:14>	
bit 15							bit 8

R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x		
EID<13:6>									
bit 7							bit 0		

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-12 **Unimplemented:** Read as '0' bit 11-0 **EID<17:6>:** Extended Identifier bits

#### Buffer 21-3: ECAN Message Buffer Word 2

	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x
			EID<	5:0>			RTR	RB1
t	oit 15							bit 8

U-x	U-x	U-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x
_	_	_	RB0		DLC<	<3:0>	
bit 7							bit 0

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-10 **EID<5:0>:** Extended Identifier bits bit 9 **RTR:** Remote Transmission Request bit

When IDE = 1:

 ${\tt 1}$  = In case of Transmission, this will cause a Remote Frame to be transmitted. In case of Received

message, indicates a remote frame was received.

0 = Normal message When IDE = 0:

The RTR bit is ignored.

bit 8 **RB1:** Reserved Bit 1

User application must set this bit to '0' per CAN Specification.

bit 7-5 **Unimplemented:** Read as '0'

bit 4 RB0: Reserved Bit 0

User application must set this bit to '0' per CAN Specification.

bit 3-0 **DLC<3:0>:** Data Length Code bits

#### Buffer 21-4: ECAN Message Buffer Word 3

R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x
			Byt	te 1			
bit 15							bit 8

R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x		
Byte 0									
bit 7							bit 0		

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-8 ECAN Message byte 1 bit 7-0 ECAN Message byte 0

# Controller Area Network (ECAN

# Section 21. Enhanced Controller Area Network (ECAN™)

#### Buffer 21-5: ECAN Message Buffer Word 4

R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x
			Byt	e 3			
bit 15							bit 8

R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	
Byte 2								
bit 7							bit 0	

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-8 ECAN Message byte 3 bit 7-0 ECAN Message byte 2

#### Buffer 21-6: ECAN Message Buffer Word 5

R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	
Byte 5								
bit 15								

R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	
Byte 4								
bit 7							bit 0	

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-8 ECAN Message byte 5 bit 7-0 ECAN Message byte 4

#### Buffer 21-7: ECAN Message Buffer Word 6

R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	
Byte 7								
bit 15								

R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x	
Byte 6								
bit 7								

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-8 ECAN Message byte 7 bit 7-0 ECAN Message byte 6

#### Buffer 21-8: ECAN Message Buffer Word 7

U-0	U-0	U-0	R/W-x	R/W-x	R/W-x	R/W-x	R/W-x
_	_	_			FILHIT<4:0>		
bit 15							bit 8

U-0	U-0	U-0	U-0	U-0	U-0	U-0	U-0
_	_	_	_	_	_	_	_
bit 7							bit 0

Legend:

R = Readable bit W = Writable bit U = Unimplemented bit, read as '0'

-n = Value at POR '1' = Bit is set '0' = Bit is cleared x = Bit is unknown

bit 15-13 **Unimplemented:** Read as '0' bit 12-8 **FILHIT<4:0>:** Filter Hit Code bits

Encodes the number of filter that resulted in writing this buffer (only written by module for receive

buffers, unused for transmit buffers).

bit 7-0 **Unimplemented:** Read as '0'

#### 21.5 ECAN OPERATING MODES

The ECAN module can operate in one of the several modes selected by the user application. These modes include:

- Configuration mode
- · Normal Operation mode
- · Listen-Only mode
- · Listen All Messages mode
- · Loopback mode
- · Disable mode

The operating modes are requested by the user application that is writing to the Request Operation Mode bits (REQOP<2:0>) in the ECAN Control Register 1 (CiCTRL1<10:8>). The ECAN module acknowledges entry into the requested mode by the OPMODE<2:0> bits (CiCTRL1<7:5>). Mode transition is performed in synchronization with the CAN network. That is, the ECAN module waits until it detects a bus idle sequence (11 recessive bits) before it changes mode.

#### 21.5.1 Configuration Mode

After hardware reset, the ECAN module is in the Configuration mode (OPMODE<2:0> = 100). The error counters are cleared, and all registers contain the Reset values. In order to modify the ECAN bit time control registers (CiCFG1 and CiCFG2), the ECAN module must be in the Configuration mode.

#### 21.5.2 Normal Operation Mode

In the Normal Operation mode, the ECAN module can transmit and receive the CAN messages. Normal Operation mode is requested after initialization by programming the REQOP<2:0> bits (CiCTRL1<10:8>) to '000'. When OPMODE<2:0> = 000, the module proceeds with normal operation.

#### 21.5.3 Listen-Only Mode

The Listen-Only mode is used mainly for bus monitoring without participating in the transmission process. The node in Listen-Only mode does not generate an acknowledge or error frames – one of the other nodes must do it. The Listen-Only mode can be used for detecting the baud rate on the CAN bus.

#### 21.5.4 Listen All Messages Mode

The Listen All Messages mode is used for system debugging. Basically, all messages are received, regardless of their identifier, even when there is an error. If the Listen All Messages mode is activated, the transmission and reception operate the same as Normal Operation mode, except that if a message is received with an error, it is still transferred to the message buffer.

#### 21.5.5 Loopback Mode

The Loopback mode is used for self-test to allow the ECAN module to receive its own message. In this mode, the ECAN transmit path is connected to the receive path internally. A "dummy" acknowledgement is provided, thereby eliminating the need for another node to provide the Acknowledge bit.

#### 21.5.6 Disable Mode

The Disable mode is used to ensure a safe shutdown before putting the device in Sleep or Idle mode. That is, the ECAN module waits until it detects a bus idle sequence (11 recessive bits) before it changes the mode. When the module is in Disable mode, it stops its own clocks, having no effect on the CPU or other modules. The module wakes up when the bus activity occurs or when the CPU sets the OPMODE<2:0> bits to '000'.

The CiTX pin stays in the recessive state while the module is in Disable mode.

#### 21.6 TRANSMITTING ECAN MESSAGES

A node originating a message is a transmitter of that message. The node remains a transmitter until the bus becomes Idle or the unit loses arbitration. Figure 21-8 illustrates a typical ECAN transmission process.

Message Buffers 0-7 (located in device RAM) are configured to transmit or receive CAN messages using the TX/RX Buffer Selection bit (TXENn) in the corresponding ECAN TX/RX Buffer m Control register (CiTRmnCON<7>). If the TXENn bit is set, the message buffer is configured for transmission. For the layout of standard and extended frames in the message buffer, and the states of IDE, SRR, RTR, RB0 and RB1 bits for Standard Data, Extended Data, Standard Remote, or Extended Remote frames as per the CAN Specification, refer to 21.2 "CAN Message Formats".

#### 21.6.1 Message Transmission Flow

To transmit a message over the CAN bus, the user application must perform these tasks:

- 1. Configure a message buffer for transmission and assign a priority to the buffer.
- 2. Write the CAN message in the message buffer located in device RAM.
- 3. Set the transmit request bit for the buffer to initiate message transmission.

The Message transmission is initiated by setting the Message Send Request bit (TXREQm) in the ECAN Transmit/Receive Control register (CiTRmnCON<3>). The TXREQm bit is cleared automatically after the message is transmitted. Before the SOF is sent, all the buffers ready for transmission are examined to determine which buffer has the highest priority. The transmit buffer with the highest priority is sent first.

**Note:** Setting the TXREQm bit when TXENn bit is '0' will result in unpredictable module behavior.


Each of the transmit message buffers can be assigned to any of the four user application-defined priority levels using the TXnPRI<1:0> bits (CiTRmnCON<1:0>).

TXnPRI<1:0> Message Transmission Priority selections are:

- 11 = The transmit message has the highest priority
- 10 = The transmit message has intermediate high priority
- 01 = The transmit message has intermediate low priority
- 00 = The transmit message has the lowest priority

There is a natural order of priority for message buffers that are assigned to the same user application-defined priority level. The message buffer seven has the highest natural order of priority. The user application-defined priority levels override the natural order of priority.

Figure 21-8: ECAN™ Transmission



A code example to transmit a standard frame using message buffer 0 is shown in Example 21-1.

#### Example 21-1: Code Example for Standard Data Frame Transmission

```
#include <p33Exxxx.h>
^{\prime\star} This code example demonstrates a method to configure the ECAN module to transmit
   Standard ID CAN messages. */
/* Include fuse configuration code here. Optionally the fuse configuration can be specified
   via MPLAB IDE Menu operations. */
FUSE CONFIGURATION MACROS COME HERE
#define NUM OF ECAN BUFFERS 32
^{\prime\star} This is the ECAN message buffer declaration. Note the buffer alignment. ^{\star\prime}
       unsigned int ecan1MsgBuf[NUM OF ECAN BUFFERS][8]
        attribute ((aligned(NUM OF ECAN BUFFERS * 16)));
int main (void)
    unsigned long address;
    /* Place code to set device speed here. For this example the device speed should be set at
       40 MHz (i.e., the device is operating at 40 MIPS). */
    ConfigureDeviceClockFor40MIPS();
    /* The dsPIC33E device features I/O remap. This I/O remap configuration for the ECAN
       module can be performed here. */
    SetIORemapForECANModule();
    /\star Set up the ECAN1 module to operate at 250 kbps. The ECAN module should be first placed
       in configuration mode. */
    C1CTRL1bits.REOOP = 4;
    while(C1CTRL1bits.OPMODE != 4);
    C1CTRL1bits.WIN = 0;
    /* Set up the CAN module for 250kbps speed with 10 Tq per bit. */
    C1CFG1 = 0x47; // BRP = 8 SJW = 2 Tq
    C1CFG2 = 0x2D2;
   C1FCTRL = 0xC01F; // No F1FO, 32 Buffers
/* Assign 32x8word Message Buffers for ECAN1 in device RAM. This example uses DMA0 for TX.
   Refer to 21.8.1 "DMA Operation for Transmitting Data" for details on DMA channel
   configuration for ECAN transmit. */
    DMA0CONbits.SIZE = 0x0;
    DMA0CONbits.DIR = 0x1;
    DMA0CONbits.AMODE = 0x2;
    DMA0CONbits.MODE = 0x0;
    DMAOREQ = 70;
    DMAOCNT = 7;
    DMAOPAD = (volatile unsigned int) &C1TXD;
   DMAOSTAL = (unsigned int) &ecan1msgBuf;
   DMAOSTAH = (unsigned int) &ecan1msgBuf;
    DMA0CONbits.CHEN = 0x1;
```

#### Example 21-1: Code Example for Standard Data Frame Transmission (Continued)

```
/* Configure Message Buffer 0 for Transmission and assign priority */
   C1TR01CONbits.TXEN0 = 0x1;
   C1TR01CONbits.TX0PRI = 0x3;
   /\star At this point the ECAN1 module is ready to transmit a message. Place the ECAN module in
       Normal mode. */
   C1CTRL1bits.REQOP = 0;
   while(C1CTRL1bits.OPMODE != 0);
   /* Write to message buffer 0 */
   /* CiTRBnSID = 0bxxx1 0010 0011 1100
      IDE = 0b0
      SRR = 0b0
      SID<10:0>= 0b100 1000 1111 */
   ecan1MsgBuf[0][0] = 0x123C;
   /* CiTRBnEID = 0bxxxx 0000 0000 0000
      EID<17:6> = 0b0000 0000 0000 */
   ecan1MsgBuf[0][1] = 0x0000;
/* CiTRBnDLC = 0b0000 0000 xxx0 1111
      EID<17:6> = 0b000000
      RTR = 0b0
      RB1 = 0b0
      RB0 = 0b0
      DLC = 0b1111 */
   ecan1MsgBuf[0][2] = 0x0008;
/* Write message data bytes */
   ecan1MsgBuf[0][3] = 0xabcd;
   ecan1MsgBuf[0][4] = 0xabcd;
   ecan1MsgBuf[0][5] = 0xabcd;
   ecan1MsgBuf[0][6] = 0xabcd;
   /* Request message buffer 0 transmission */
   C1TR01CONbits.TXREQ0 = 0x1;
/\star The following shows an example of how the TXREQ bit can be polled to check if transmission
   is complete. */
   while(C1TR01CONbits.TXREQ0 == 1);
   /* Message was placed successfully on the bus */
   while (1);
```

A code example to transmit an extended frame using Message Buffer 2 is shown in Example 21-2.

# Section 21. Enhanced Controller Area Network (ECAN™)

#### Example 21-2: Code Example for Extended Data Frame Transmission

```
#include <p33Exxxx.h>
  This code example demonstrates a method to configure the ECAN module to transmit Extended
   ID CAN messages. */
/* Include fuse configuration code here. Optionally the fuse configuration can be specified via
   MPLAB IDE Menu operations. */
FUSE CONFIGURATION MACROS COME HERE
#define NUM OF ECAN BUFFERS 32
^{\prime\star} This is the ECAN message buffer declaration. Note the buffer alignment. ^{\star\prime}
       unsigned int ecan1MsgBuf[NUM OF ECAN BUFFERS][8]
        attribute ((aligned(NUM OF ECAN BUFFERS * 16)));
int main(void)
    unsigned long address;
    /* Place code to set device speed here. For this example the device speed should be set at
       40 MHz (i.e., the device is operating at 40 MIPS). */
ConfigureDeviceClockFor40MIPS();
    /* The dsPIC33E device features I/O remap. This I/O remap configuration for the ECAN module
       can be performed here. */
    SetIORemapForECANModule();
  Set up the ECAN1 module to operate at 250 kbps. The ECAN module should be first placed in
   configuration mode. */
   C1CTRL1bits.REQOP = 4;
   while(C1CTRL1bits.OPMODE != 4);
    C1CTRL1bits.WIN = 0;
    /* Set up the CAN module for 250kbps speed with 10 Tq per bit. */
                      // BRP = 8 SJW = 2 Tq
    C1CFG1 = 0 \times 47:
    C1CFG2 = 0x2D2;
    C1FCTRL = 0xC01F; // No FIFO, 32 Buffers
^{\prime\star} Assign 32x8 word Message Buffers for ECAN1 in device RAM. This example uses DMA0 for TX.
   Refer to 21.8.1 "DMA Operation for Transmitting Data" for details on DMA channel
   configuration for ECAN transmit. */
   DMA0CONbits.SIZE = 0x0;
    DMA0CONbits.DIR = 0x1;
    DMA0CONbits.AMODE = 0x2;
    DMA0CONbits.MODE = 0x0;
    DMAOREQ = 70;
    DMAOCNT = 7;
    DMAOPAD = (volatile unsigned int) &C1TXD;
    DMAOSTAL = (unsigned int) &ecan1msgBuf;
    DMAOSTAH = (unsigned int) &ecan1msgBuf;
    DMA0CONbits.CHEN = 0x1;
```

#### Example 21-2: Code Example for Extended Data Frame Transmission (Continued)

```
^{\prime \star} Configure Message Buffer 2 for Transmission and assign priority ^{\star \prime}
   C1TR23CONbits.TXEN2 = 0x1;
   C1TR23CONbits.TX2PRI = 0x3;
    /\star At this point the ECAN1 module is ready to transmit a message. Place the ECAN module in
       Normal mode. */
   C1CTRL1bits.REQOP = 0;
   while(C1CTRL1bits.OPMODE != 0);
    /* Write to message buffer 2*/
    /* CiTRBnSID = 0bxxx1 0010 0011 1101
       IDE = 0b1
       SRR = 0b1
       SID<10:0> : 0b100 1000 1111 */
   ecan1MsgBuf[2][0] = 0x123D;
    /* CiTRBnEID = 0bxxxx 1111 0000 0000
      EID<17:6> = 0b1111 0000 0000 */
   ecan1MsgBuf[2][1] = 0x0F00;
/* CiTRBnDLC = 0b0000 1100 xxx0 1111
      EID<17:6> = 0b000011
      RTR = 0b0
      RB1 = 0b0
      RB0 = 0b0
      DLC = 0b1000 */
   ecan1MsgBuf[2][2] = 0x0C08;
/* Write message data bytes */
   ecan1MsgBuf[2][3] = 0xabcd;
   ecan1MsgBuf[2][4] = 0xabcd;
   ecan1MsgBuf[2][5] = 0xabcd;
   ecan1MsgBuf[2][6] = 0xabcd;
/* Request message buffer 2 transmission */
   C1TR23CONbits.TXREQ2 = 0x1;
/\star The following shows an example of how the TXREQ bit can be polled to check if transmission
   is complete. */
   while(C1TR23CONbits.TXREQ2 == 1);
    /* Message was placed successfully on the bus */
    while (1);
```

### 21.6.2 Aborting a Transmit Message

Setting the Abort All Pending Transmissions bit (ABAT) in the ECAN Control Register 1 (CiCTRL1<12>) requests an abort of all pending messages. To abort a specific message, the Message Send Request (TXREQm) bit (CiTRmnCON<3>) associated with that message buffer must be cleared. In either case, the message is only aborted if the ECAN module has not started transmitting the message on the bus.

## 21.6.3 Transmitting and Responding Remote Frames

#### 21.6.3.1 TRANSMIT A REMOTE FRAME

A node expecting to receive a data frame with a specific identifier value can initiate the transmission of the respective data by another node by sending the remote frame. The remote frame can be either in the Standard format or Extended format.

A remote frame is similar to a data frame, with the following exceptions:

- The RTR bit is recessive (RTR = 1)
- · There is no data field
- The value of the DLC bits is 0 ≤ DLC ≤ 8

To transmit a remote frame, the user application must perform these tasks:

- 1. Configure the message buffer for transmission and assign a priority to the buffer.
- 2. Write the remote frame in the appropriate message buffer. The transmitted identifier must be identical to the identifier of the data frame to be received.
- 3. Set the transmit request bit for the buffer to initiate transmission of the remote frame.

#### 21.6.3.2 RESPOND TO A REMOTE FRAME

The node acting as the source to respond to the remote frame request needs to configure an acceptance filter to match the identifier of the Remote Frame. Message buffers 0-7 can respond to remote frames, so the Acceptance Filter Buffer Pointer (FnBP) should point to one of the eight message buffers. The TX/RX Buffer Selection (TXENn) and Auto-Remote Transmit Enable (RTRENm) bits in the ECAN Transmit/Receive Control register (CiTRMNCON<7> and CiTRmnCON<2>) must be set to respond to the Remote Frame.


This is the only case where the Acceptance Filter Buffer Pointer (FnBP) points to a message buffer that is configured for transmission (TXENn = 1).

Figure 21-9 illustrates the remote frame handling process:

- 1. ECAN Node 1 sends an RTR (using message buffer 1).
- 2. ECAN Node 2 receives the request and responds by sending the data frame (using message buffer 7).
- 3. The data frame is received by ECAN Node 1.
- 4. The data frame is stored in message buffer 14 of ECAN Node 1.

**Note:** When configured for automatic response to remote frames (RTREN = 1), the ECAN module ignores the value of the DLC bits in the incoming RTR message. If the application needs to transmit a data payload size specified by DLC bits in the received RTR message, it should not enable automatic RTR response. The application should process the RTR message like any other received message. Check if the RTR bit is set and then transmit a message whose payload size is equal to the DLC bits in the receive RTR message.

Figure 21-9: Remote Frame Transmit and Response



dsPIC33E/PIC24E Family Reference Manual

- Note 1: The node transmitting the remote frame must have a transmit buffer, from which to send the remote frame, and one receive buffer to receive the data frame.
  - 2: The node receiving the remote frame must have a transmit buffer from which to transmit a data frame in response to the received remote frame.
  - 3: The FnBP bits (CiBUFPNTm) should be pointing to a transmit buffer in case of remote transmission.
  - 4: The RTREN bits (CiTRmnCON) should be set so that, when a remote transmit is received, the TXREQ bits (CiTRmnCON) will be set automatically.

# Section 21. Enhanced Controller Area Network (ECAN™)

A code example to transmit an extended remote frame using message buffer 2 is shown in Example 21-3.

#### Example 21-3: Code Example for Transmitting Extended Remote Frame

```
#include <p33Exxxx.h>
^{\prime\star} This code example demonstrates a method to configure the ECAN module to transmit Extended ID
   CAN Remote frames */
/* Include fuse configuration code here. Optionally, the fuse configuration can be specified
   via MPLAB IDE Menu operations. */
FUSE CONFIGURATION MACROS COME HERE
#define NUM_OF_ECAN_BUFFERS 32
^{\prime \star} This is the ECAN message buffer declaration. Note the buffer alignment. ^{\star \prime}
       unsigned int ecan1MsgBuf[NUM OF ECAN BUFFERS][8]
        attribute ((aligned(NUM OF ECAN BUFFERS * 16)));
int main(void)
   unsigned long address;
    /* Place code to set device speed here. For this example the device speed should be set at
   40 MHz (i.e., the device is operating at 40 MIPS). */
   ConfigureDeviceClockFor40MIPS();
^{\prime\star} The dsPIC33E device features I/O remap. This I/O remap configuration for the ECAN module can
   be performed here. */
    SetIORemapForECANModule();
    /* Set up the ECAN1 module to operate at 250 kbps. The ECAN module should be first placed
       in configuration mode. */
    C1CTRL1bits.REQOP = 4;
   while (C1CTRL1bits.OPMODE != 4);
   C1CTRL1bits.WIN = 0;
    /* Set up the CAN module for 250kbps speed with 10 Tq per bit. */
   C1CFG1 = 0x47;
                     // BRP = 8 SJW = 2 Tq
   C1CFG2 = 0x2D2;
   C1FCTRL = 0xC01F; // No F1FO, 32 Buffers
    /* Assign 32x8word Message Buffers for ECAN1 in device RAM. This example uses DMA0 for TX.
       Refer to 21.8.1 "DMA Operation for Transmitting Data" for details on DMA channel
       configuration for ECAN transmit. */
    DMA0CONbits.SIZE = 0 \times 0:
    DMA0CONbits.DIR = 0x1;
    DMA0CONbits.AMODE = 0x2;
    DMA0CONbits.MODE = 0x0;
   DMAOREQ = 70;
   DMAOCNT = 7;
    DMAOPAD = (volatile unsigned int) &C1TXD;
   DMAOSTAL = (unsigned int) &ecanlmsgBuf;
   DMAOSTAH = (unsigned int) &ecan1msgBuf;
   DMA0CONbits.CHEN = 0x1;
```

#### Example 21-3: Code Example for Transmitting Extended Remote Frame (Continued)

```
/* Configure Message Buffer 2 for Transmission and assign priority */
   C1TR23CONbits.TXEN2 = 0x1;
   C1TR23CONbits.TX2PRI = 0x3;
   /\star At this point the ECAN1 module is ready to transmit a message. Place the ECAN module
       in Normal mode. */
   C1CTRL1bits.REQOP = 0;
   while(C1CTRL1bits.OPMODE != 0);
   /* Write to message buffer 2*/
   /* CiTRBnSID = 0bxxx1 0010 0011 1101
      IDE = 0b1
       SRR = 0b1
      SID<10:0> : 0b100 1000 1111 */
   ecan1MsgBuf[2][0] = 0x123F;
   /* CiTRBnEID = 0bxxxx 1111 0000 0000
      EID<17:6> = 0b1111 0000 0000 */
   ecan1MsgBuf[2][1] = 0x0F00;
   /* CiTRBnDLC = 0b0000 1100 xxx0 1111
      EID<17:6> = 0b000011
      RTR = 0b1
      RB1 = 0b0
      RB0 = 0b0
      DLC = 0b1000 */
   /* RTR bit is set */
   ecan1MsgBuf[2][2] = 0x0E00;
   /* An RTR message does not have a data payload. */
/* Request message buffer 2 transmission */
   C1TR23CONbits.TXREQ2 = 0x1;
   /* The following shows an example of how the TXREQ bit can be polled to check if
       transmission is complete. */
   while(C1TR23CONbits.TXREQ2 == 1);
   /* Message was placed successfully on the bus */
   while (1);
```


## 21.7 RECEIVING ECAN MESSAGES

The ECAN module can receive both standard and extended frames on the CAN bus node. This module has the additional capability of automatically transferring the received messages to the user-defined buffers in device RAM, thereby eliminating the need for the user application to explicitly copy messages from hardware registers to the user-defined buffers. The storage format of each message within the DMA buffer is identical to that of transmit buffers, with each message (including the associated status register) occupying eight words in device RAM.

The two main stages that constitute the ECAN reception process are described below, with a simplified reception process example illustrated in Figure 21-10 and Figure 21-13.

## 21.7.1 Message Reception and Acceptance Filtering

As illustrated in Figure 21-10, every incoming message on the bus is received into a Message Assembly Buffer, and its identifier field is compared with a set of 16 user-defined acceptance filters. Each received standard data frame contains an 11-bit SID, and each extended data frame contains an 11-bit SID and an 18-bit EID. If all bits in the incoming identifier completely match the corresponding bits in any of the acceptance filters, the ECAN module generates a DMA transfer request to the DMA Controller so that the message can be received into the appropriate buffer in device RAM.



#### 21.7.1.1 ACCEPTANCE FILTERS

Figure 21-11 illustrates the incoming message identifier being compared with the filter/mask bits for standard frames. Figure 21-12 illustrates the incoming message identifier being compared with the filter/mask bits for extended frames.

Figure 21-11: Acceptance Filtering for a Standard Message





Figure 21-12: Acceptance Filtering for a Extended Message



The acceptance filters 0-15 can be individually enabled or disabled using the Enable Filter bits (FLTENn) in the ECAN Acceptance Filter Enable register (CiFEN1<15:0>). The value of 'n' signifies the register bit and corresponds to the index of the acceptance filter.

The acceptance filters 0-15 specify the identifiers that must be contained in an incoming message for its contents to be passed to a receive buffer. Each of these filters consists of two registers – one for the SIDs and the other for EIDs. These registers are identified as:

- CiRXFnSID: ECAN Acceptance Filter Standard Identifier Register n (n = 0-15)
- CiRXFnEID: ECAN Acceptance Filter Extended Identifier Register n (n = 0-15)

# Section 21. Enhanced Controller Area Network (ECAN™)

#### 21.7.1.2 ACCEPTANCE FILTER MASKS

As shown in Figure 21-11 and Figure 21-12, an acceptance filter mask determines which bits in the incoming message identifiers are examined with the acceptance filters.

The acceptance filters optionally select one of the Acceptance filter masks using the Mask Source Select (FnMSK<1:0>) mask select bits in the CiFMSKSEL1 and CiFMSKSEL2 registers:

- CiFMSKSEL1: ECAN Filter 7-0 Mask Selection Register
- CiFMSKSEL2: ECAN Filter 15-8 Mask Selection Register

The selection values for the FnMSK<1:0> bit are:

- 11 = Reserved
- 10 = Select acceptance filter mask 2
- 01 = Select acceptance filter mask 1
- 00 = Select acceptance filter mask 0

Table 21-1 is a truth table that indicates how each bit in the identifier is compared to the masks and filters to determine if the message should be accepted or rejected. The mask bit essentially determines which bits to apply the filter to. If any mask bit is set to '0', that bit is automatically accepted, regardless of the filter bit.

Table 21-1: **Acceptance Filter/Mask Truth Table** 

Mask (SIDn/EIDn)	Filter (SIDn/EIDn)	Message (SIDn/EIDn)	Accept or Reject bit n
0	Х	X	Accept
1	0	0	Accept
1	0	1	Reject
1	1	0	Reject
1	1	1	Accept

#### 21.7.1.3 MESSAGE TYPE SELECTION

The Extended Identifier Enable bit (EXIDE) in the ECAN Acceptance Filter n Standard Identifier register (CiRXFnSID<3>) enables reception of either SID or EID messages. The Identifier Receive Mode bit (MIDE) in the ECAN Acceptance Filter Mask n SID register (CiRXMnSID<3>) enables the EXIDE bit. If the MIDE bit is set, only the type of message selected by the EXIDE bit is accepted. If the MIDE bit is clear, the EXIDE bit is ignored and all messages that match the filter are accepted.

Table 21-2: **Message Type Selections** 

EXIDE	MIDE	Selection
0	1	Acceptance filter to check for SID
1	1	Acceptance filter to check for EID
Х	0	Acceptance filter to check for SID/EID

#### 21.7.1.4 ACCEPTANCE FILTER CONFIGURATION

A sample code used to configure the acceptance filter 0 to receive the SID messages using the acceptance filter mask register to mask SID<2:0> bits is shown in Example 21-4.

#### Example 21-4: Code Example for Filtering Standard Data Frame

```
#include <p33Exxxx.h>
/* This code example demonstrates a method to configure the ECAN module to receive Standard ID
   CAN messages. SID Messages with SID range 0x1D0-0x1D7 will be accepted. */
/* Include fuse configuration code here. Optionally the fuse configuration can be specified via
   MPLAB IDE Menu operations. */
FUSE CONFIGURATION MACROS COME HERE
#define NUM OF ECAN BUFFERS 32
^{\prime\star} This is the ECAN message buffer declaration. Note the buffer alignment. ^{\star\prime}
   unsigned int ecan1MsgBuf[NUM OF ECAN BUFFERS][8]
   attribute ((aligned(NUM OF ECAN BUFFERS * 16)));
int main(void)
   unsigned long address;
   /\star Place code to set device speed here. For this example the device speed should be set at
       40 MHz (i.e., the device is operating at 40 MIPS). */
   ConfigureDeviceClockFor40MIPS();
   /\star The dsPIC33E device features I/O remap. This I/O remap configuration for the ECAN module
       can be performed here. */
   SetIORemapForECANModule();
   /* Set up the ECAN1 module to operate at 250 kbps. The ECAN module should be first placed
       in configuration mode. */
   C1CTRL1bits.REQOP = 4;
   while (C1CTRL1bits.OPMODE != 4);
   C1CTRL1bits.WIN = 1;
   /* Set up the CAN module for 250kbps speed with 10 Tq per bit. */
                      // BRP = 8 SJW = 2 Tq
   C1CFG1 = 0x47;
   C1CFG2 = 0x2D2;
   C1FCTRL = 0xC01F; // No FIFO, 32 Buffers
    /* Assign 32x8word Message Buffers for ECAN1 in device RAM. This example uses DMA1 for RX.
       Refer to 21.8.1 "DMA Operation for Transmitting Data" for details on DMA channel
       configuration for ECAN transmit. */
   DMA1CONbits.SIZE = 0x0;
   DMA1CONbits.DIR = 0x0;
   DMA1CONbits.AMODE = 0x2;
   DMA1CONbits.MODE = 0x0;
   DMA1REQ = 34;
   DMA1CNT = 7;
   DMA1PAD = (volatile unsigned int) &C1RXD;
   DMA1STAL = (unsigned int) &ecan1msgBuf;
   DMA1STAH = (unsigned int) &ecan1msgBuf;
   DMA1CONbits.CHEN = 0x1;
```

#### Example 21-4: Code Example for Filtering Standard Data Frame (Continued)

```
/* Select Acceptance Filter Mask 0 for Acceptance Filter 0 */
C1FMSKSEL1bits.F0MSK=0x0;
/* Configure Acceptance Filter Mask 0 register to mask SID<2:0>
 * Mask Bits (11-bits) : 0b111 1111 1000 */
C1RXMOSIDbits.SID = 0x7F8;
/* Configure Acceptance Filter 0 to match standard identifier
   Filter Bits (11-bits): 0b011 1010 xxx with the mask setting, message with SID
   range 0x1D0-0x1D7 will be accepted by the ECAN module. */
C1RXF0SIDbits.SID = 0x01D0;
/* Acceptance Filter 0 to check for Standard Identifier */
C1RXM0SIDbits.MIDE = 0x1;
C1RXF0SIDbits.EXIDE= 0x0;
/st Acceptance Filter 0 to use Message Buffer 10 to store message st/
C1BUFPNT1bits.F0BP = 0xA;
/* Filter 0 enabled for Identifier match with incoming message */
C1FEN1bits.FLTEN0=0x1;
/* Clear Window Bit to Access ECAN
 * Control Registers */
C1CTRL1bits.WIN=0x0;
/* Place the ECAN module in normal
 * mode. */
C1CTRL1bits.REQOP = 0;
while(C1CTRL1bits.OPMODE != 0);
/* The following code shows one example of how the application can wait
   for a message to be received in message buffer 10 */
while(1)
    /* Message was received. */
   while (C1RXFUL1bits.RXFUL10 == 0);
    C1RXFUL1bits.RXFUL10 = 0;
```

A code example used to configure acceptance filter 2 to receive EID messages using the acceptance filter mask register to mask EID<5:0> bits is shown in Example 21-5.

#### Example 21-5: Code Example for Filtering Extended Data Frame

```
#include <p33Exxxx.h>
/* This code example demonstrates a method to configure the ECAN module to receive Extended
   ID CAN messages. EID Messages with EID range 0x3FFC0-0x3FFFF will be accepted. */
/* Include fuse configuration code here. Optionally the fuse configuration can be specified
   via MPLAB IDE Menu operations. */
FUSE CONFIGURATION MACROS COME HERE
#define NUM OF ECAN BUFFERS 32
^{\prime\star} This is the ECAN message buffer declaration. Note the buffer alignment. ^{\star\prime}
   unsigned int ecan1MsgBuf[NUM OF ECAN BUFFERS][8]
   __attribute__((aligned(NUM OF ECAN BUFFERS * 16)));
int main (void)
   unsigned long address;
^{\prime \star} Place code to set device speed here. For this example the device speed should be set at
   40 MHz (i.e., the device is operating at 40 MIPS). */
   ConfigureDeviceClockFor40MIPS();
   /* The dsPIC33E device features I/O remap. This I/O remap configuration for the ECAN
       module can be performed here. */
   SetIORemapForECANModule();
   /\star Set up the ECAN1 module to operate at 250 kbps. The ECAN module should be first placed
       in configuration mode. */
   C1CTRL1bits.REQOP = 4;
   while (C1CTRL1bits.OPMODE != 4);
   C1CTRL1bits.WIN = 1;
   /* Set up the CAN module for 250 kbps speed with 10 Tq per bit. */
   C1CFG1 = 0x47;
                       // BRP = 8 SJW = 2 Tq
   C1CFG2 = 0x2D2;
   C1FCTRL = 0xC01F; // No FIFO, 32 Buffers
/* Configure Acceptance Filter Mask 1
    * register to mask EID<5:0>
    * Mask Bits (29-bits) : 0b1 1111 1111 1111 1111 1110 0000
    * SID<10:0> : 0b11111111111 ..SID<10:0> or EID<28:18>
    * EID<17:16> : 0b11 ..EID<17:16>
* EID<15:0> : 0b1111111111000000 ..EID<15:0> */
   C1RXM1SID = 0xFFEB;
   C1RXM1EID = 0xFFC0;
    /* Configure Acceptance Filter 2 to match extended identifier
     * Filter Bits (29-bits) : 0b0 0000 0000 0011 1111 1111 11xx xxxx
     * SID<10:0> : 0b0000000000 ..SID<10:0> or EID<28:18>
    * EID<17:16> : 0b11 ..EID<17:16>
    * EID<15:0> : Ob1111111111111xxxxxx ..EID<15:0> */
   C1RXF2SID = 0xB;
   C1RXF2EID = 0xFFFF;
    /\star Acceptance Filter 2 to use Message Buffer 6 to store message \star/
   C1BUFPNT1bits.F2BP = 0x6;
   /* Filter 2 enabled for Identifier match with incoming message */
   C1FEN1 = 0;
   C1FEN1bits.FLTEN2 = 0x1;
```

#### Example 21-5: Code Example for Filtering Extended Data Frame (Continued)

```
Assign 32x8word Message Buffers for ECAN1 in device RAM. This example uses DMA1 for RX.
   Refer to 21.8.1 "DMA Operation for Transmitting Data" for details on DMA channel
   configuration for ECAN transmit. */
   DMA1CONbits.SIZE = 0x0;
   DMA1CONbits.DIR = 0x0;
   DMA1CONbits.AMODE = 0x2;
   DMA1CONbits.MODE = 0x0;
   DMA1REQ = 34;
   DMA1CNT = 7;
   DMA1PAD = (volatile unsigned int) &C1RXD;
   DMAOSTAL = (unsigned int) &ecan1msgBuf;
   DMAOSTAH = (unsigned int) &ecan1msgBuf;
   DMA1CONbits.CHEN = 0x1;
   /* Select Acceptance Filter Mask 1 for Acceptance Filter 2 */
   C1FMSKSEL1bits.F2MSK=0x1;
   /* Clear Window Bit to Access ECAN Control Registers */
   C1CTRL1bits.WIN = 0 \times 0;
   C1CTRL1bits.REQOP = 0;
   while (C1CTRL1bits.OPMODE != 0);
^{\prime \star} The following code shows one example of how the application can wait for a message to be
   received in message buffer 6 */
   while(1)
        /* Message was received. */
        while (CIRXFUL1bits.RXFUL6 == 0);
       C1RXFUL1bits.RXFUL6 = 0;
```

#### 21.7.2 Buffer Selection and DMA Transfer

As illustrated in Figure 21-13, if a filter match occurs, a DMA transfer request is generated by the ECAN module to the DMA Controller to automatically copy the received message into the appropriate message buffer in a user-defined device RAM area. The ECAN module supports up to 32 message buffers. The user application can use the DMA Buffer Size bits (DMABS<2:0>) in the ECAN FIFO Control register (CiFCTRL<15:13>) to select either 4, 6, 8, 12, 16, 24 or 32 message buffers. The selection of the receive buffer index (and therefore the device RAM addresses in which a message is written by the DMA Controller) is dependent on which filter matched the incoming identifier, and is configurable by the user application. The DMA Controller moves the data into the appropriate addresses in the device RAM area and generates a DMA interrupt after the user-specified number of words are transferred. For more details on DMA channel configuration for ECAN data transfers, refer to 21.8 "DMA Controller Configuration".




Figure 21-13: Buffer Selection and DMA Transfer

# Section 21. Enhanced Controller Area Network (ECAN™)

#### 21.7.2.1 BUFFER SELECTION

There are four Acceptance Filter Buffer Pointer registers that select which message buffer the received message is stored into for acceptance filters 0-15.

- CiBUFPNT1: ECAN Filter 0-3 Buffer Pointer Register
- CiBUFPNT2: ECAN Filter 4-7 Buffer Pointer Register
- CiBUFPNT3: ECAN Filter 8-11 Buffer Pointer Register
- CiBUFPNT4: ECAN Filter 12-15 Buffer Pointer Register

When the incoming message identifier is matched by one of the acceptance filters, the internal logic looks up the buffer pointer (FnBP<3:0>) and uses that as an address for the corresponding message buffer. The address is provided to the DMA channel by the peripheral. Therefore, the DMA channel must be configured in the Peripheral Indirect mode.

The values for FnBP<3:0> are interpreted as follows:

- 1111 = Message is received in receive FIFO buffer
- 1110 = Message is received in message buffer 14
  - •
- 0001 = Message is received in message buffer 1
- 0000 = Message is received in message buffer 0

**Note:** Multi message buffering can be implemented by a user application by configuring multiple acceptance filters with the same value. In this case, a received message may match multiple filters, and the ECAN module will assign the message to the lowest-numbered matching filter pointing to an empty buffer.

#### 21.7.2.2 RECEIVING MESSAGES INTO MESSAGE BUFFERS 0-7

The message buffers 0-7 can be configured to transmit or receive the CAN messages using the TX/RX Buffer Selection bit (TXENm) in the ECAN TX/RX Buffer m Control register (CiTRmnCON<7>). The Acceptance Filter Buffer Pointer (FnBP) selects one of the message buffers to store the received message, provided it is configured as a receive buffer (TXENm = 0).

If a message buffer is set up as a transmitter with the RTRENm bit (CiTRmnCON<2>) set, and an acceptance filter pointing to that message buffer detects a message, the message buffer will handle the RTR instead of storing the message. This is the only case where the Acceptance Filter Buffer Pointer (FnBP) points to a message buffer that is configured for transmission (TXENn = 1).

**Note:** The user application should not set the TXREQ bits (CiTRmnCON) when the buffer is configured for receive operation (TXEN = 0). This could result in unpredictable module behavior.

#### 21.7.2.3 RECEIVING MESSAGES INTO MESSAGE BUFFERS 8-14

The message buffers 8-14 are receive buffers. The Acceptance Filter Buffer Pointer (FnBP) determines which message buffer to use.

#### 21.7.2.4 RECEIVING MESSAGES INTO MESSAGE BUFFERS 15-31

The message buffers 15-31 are receive buffers and are only usable as FIFO buffers because the Acceptance Filter Buffer Pointer bits (FnBP<3:0>) can only directly address 16 entities. When FnBP<3:0> = 1111, the results of a hit on that filter will write to the next available buffer location within the FIFO.

#### 21.7.2.5 RECEIVE BUFFER STATUS BITS

The receive buffers contain two status bits per message buffer, the Message Buffer Full Flag (RXFULn), and the Message Buffer Overflow Flag (RXOVFn). These status bits are grouped into registers for buffer-full status and buffer-overflow status.

- CiRXFUL1: ECAN Receive Buffer Full Register 1
- CiRXFUL2: ECAN Receive Buffer Full Register 2
- CiRXOVF1: ECAN Receive Buffer Overflow Register 1
- CiRXOVF2: ECAN Receive Buffer Overflow Register 2

When a received message is stored into a message buffer, the respective Buffer Full Flag (RXFULn) is set in the Receive Buffer Full register, and a received buffer interrupt (CilNTF<1>) is generated. If an incoming message caused a filter match, and the message buffer assigned to the matching filter is full (that is, the RXFULn bit associated with that buffer is already '1'), the corresponding RXOVFn bit (where 'n' is the number of the message buffer associated with that buffer) is set and a received buffer overflow interrupt is generated (CilNTF<2>). The message is lost.

If multiple filters match the identifier of the incoming message, and all the message Note: buffers assigned to all the matching filters are full, the RXOVFn bit corresponding to the lowest numbered matching filter is set.

#### 21.7.3 FIFO Buffer Operation

The ECAN module supports up to 32 message buffers. The user application can employ the DMA Buffer Size bits (DMABS<2:0>) in the ECAN FIFO Control register (CiFCTRL<15:13>) to specify the 4, 6, 8, 12, 16, 24 or 32 message buffers. The FIFO Start Area (FSA<4:0>) bits (CiFCTRL<4:0>) are used to specify the start of the FIFO within the buffer area. The end of FIFO is based on the number of message buffers defined in the DMABS<2:0> bits.

The user application should not allocate a FIFO area that contains the transmit buffers. Should this condition occur, the module will attempt to point to the transmit buffer, but when a message is received for that buffer, an overflow condition will cause the message contents to be lost.

Figure 21-14 illustrates that one of the message acceptance filters is set to store a received message in FIFO (FnBP = 1111). The start of FIFO is set to message buffer 5 (CiFCTRL<4:0> = 00101) and the end of FIFO is set to message buffer 11 (CiFCTRL<15:13> = 011) by allocating 12 message buffers.

Message Acceptance Filters Device RAM Filter Masks FIFO Message Buffer 0 MASK 2 Filter 15 Message Buffer 1 MASK 1 FIFO Buffer 0 MASK 0 FIFO Buffer 1 Filter 0 (2 Message Buffer 5 FIFO Start FnBP Message Buffer 11 FIFO End FIFO Buffer n Message Buffer 31 Note 1: The Acceptance Filter Buffer Pointer (FnBP) should be '1111' to store the received message in FIFO. The starting address of the FIFO is specified by the FSA<4:0> bits (CiFCTRL<4:0>). In the figure, FSA <4:0> = 00101. 3: The end address of the FIFO is specified by DMABS<2:0> = 011 (CiFCTRL<15:13>).

Figure 21-14: Receiving Messages in FIFO

# Section 21. Enhanced Controller Area Network (ECAN™)

#### 21.7.3.1 RECEIVING MESSAGES INTO FIFO AREA

The acceptance filter stores the received message in the FIFO area when FnBP<3:0> = 1111. It uses a simple buffer pointer, beginning with the start of the FIFO as defined above, and incrementing sequentially through the set of buffers within the FIFO area. When the end of the buffer is reached, the counter wraps and points to the start of the FIFO area.

The write pointer value is accessible and is readable only by the user software in the FBP<5:0> bits (CiFIFO<13:8>). When the message is stored in the buffer, the RXFUL bit associated with the buffer is set, and the FIFO buffer counter increments.

If the FBP<5:0> value points to a buffer, and the RXFUL bit associated with that buffer is already '1' at the time of the filter hit and before writing of the message contents, the RXOVL bit associated with that buffer is set and the message is lost. After the message is lost, the FBP<5:0> value increments normally.

If the FBP<5:0> value points to a transmit/receive buffer that is selected as a transmit buffer at the time of the filter hit and before writing of the message contents, the RXOVL bit associated with that buffer is set and the message is lost. After the message is lost, the FBP<5:0> value increments normally.

The user software unloads the FIFO by reading the contents of a buffer. Once the buffer location is read, the user software clears the RXFUL bit corresponding to that buffer. When an RXFUL bit is cleared, the number of that corresponding buffer, plus one, is written to the FNRB<5:0> bits (CiFIFO<5:0>) by the module. Only the user software can read this value; left shift it by four bits and use it as an address offset for the next buffer to be read. The user software should read the buffers sequentially.

The module generates an interrupt condition, if the FIFO is about to be full. This condition is computed as shown in Equation 21-1.

#### Equation 21-1: FIFO Interrupt Calculation

$$FNRB - FBP = 1$$
Or
 $(FNRB = START)$  and  $(FBP = END)$ 

The interrupt is generated as the RXFUL bit is set for the buffer that was just written to, and after the FBP bit has been updated. The computation uses the updated FBP value.

#### 21.7.4 FIFO Example

Figure 21-15 illustrates seven case examples of FIFO operation. The cases illustrated assume that the Start of FIFO is set to message buffer 5 (CiFCTRL<4:0> = 101) and the End of FIFO is set to message buffer 11 (CiFCTRL<15:13> = 011).

- Case 1 is the initialized case of the FIFO before any messages are received. The FIFO Buffer Pointer points to message buffer 5 (FRB = 5), and the FIFO Next Read Buffer Pointer points to message buffer 6 (FNRB = 5).
- Case 2 shows the FIFO after one message is received and transferred to message buffer 5. The FIFO Buffer Pointer is incremented (FBP = 6), and the RXFUL status bit for message buffer 5 is set (RXFUL = 1).
- Case 3 shows the FIFO after the sixth received message. The FIFO Buffer Pointer points to the last location in the FIFO area (FBP = 5 + 6 = 11), and the FIFO Next Read Pointer points to start of the FIFO (FNRB = 5). In this case, the FIFO is almost full and generates a FIFO interrupt.
- Case 4 shows the FIFO after the user software reads the first received message. When the
  user software clears the RXFUL status bit for message buffer 5, the module writes the FIFO
  Next Read Buffer Pointer with message buffer 5 plus 1 (FNRB = 5 + 1 = 6).
- Case 5 shows the FIFO after the seventh message is received and written to message buffer 11. The RXFUL status bit for message buffer 11 is set (RXFUL = 1). Instead of incrementing, the FIFO Buffer Pointer is reloaded with the FIFO Start address (FBP = FSA = 5). Note that FBP is now mathematically one less than FNRB, which is the condition that generates the FIFO interrupt at the time the RXFUL status bit is set for message buffer 11.

- Case 6 shows the FIFO after the eighth message is received and written to message buffer 5. Now the FIFO is full. There is no interrupt signalled for this condition.
- Case 7 shows the FIFO after the ninth received message. Now the FIFO has overflowed. The module sets the RXOVL bit for the buffer intended for writing. The message is lost. The module generates a receive overflow interrupt.

Figure 21-15: Example of FIFO Operation

#### Case 5: FIFO 7th Write Case 1: FIFO at Start (About to Fill) FNRB = 5, FBP = 5 MB5 - RXFUL = 0 FBP = 5 MB5 - RXFUL = 0MB6 - RXFUL = 0FNRB = 6 MB6 - RXFUL = 1MB7 - RXFUL = 0 MB7 - RXFUL = 1MB8 - RXFUL = 0MB8 - RXFUL = 1**MB9 - RXFUL =** 0 MB9 - RXFUL = 1MB10 - RXFUL = 0 MB10 - RXFUL = 1**MB11 – RXFUL =** 0 MB11 - RXFUL = 1 Case 2: FIFO 1st Write Case 6: FIFO 8th Write FIFO Full FNRB = 5 MB5 - RXFUL = 1MB5 - RXFUL = 1FBP = 6 MB6 - RXFUL = 0FNRB = 6, FBP = 6 MB6 - RXFUL = 1MB7 - RXFUL = 0 MB7 - RXFUL = 1MB8 - RXFUL = 0 MB8 - RXFUL = 1**MB9 – RXFUL =** 0 MB9 - RXFUL = 1MB10 - RXFUL = 0 MB10 - RXFUL = 1 **MB11 – RXFUL =** 0 MB11 - RXFUL = 1 Case 3: FIFO 6th Write (About to Fill) Case 7: FIFO 9th Write **FIFO Overflow** FNRB = 5 MB5 - RXFUL = 1MB5 - RXFUL = 1MB6 - RXFUL = 1FNRB = 6 MB6 - RXFUL = 1 RXOVL = 1 MB7 - RXFUL = 1FBP = 7MB7 - RXFUL = 1MB8 - RXFUL = 1MB8 – RXFUL = 1 MB9 - RXFUL = 1MB9 – RXFUL = 1 MB10 - RXFUL = 1 MB10 – RXFUL = 1 FBP = 11 **MB11 – RXFUL =** 0 MB11 - RXFUL = 1 Case 4: FIFO 1st Read MB5 - RXFUL = 0 FNRB = 6MB6 - RXFUL = 1MB7 - RXFUL = 1MB8 - RXFUL = 1MB9 - RXFUL = 1MB10 - RXFUL = 1Shaded message buffers indicate the presence of a **MB11 - RXFUL =** 0 FBP = 11 received message ready to be read by the user application.

- Note 1: MBn represents message buffers 5-11.
  - 2: 'Write' signifies that a message is stored in the FIFO message buffer and the RXFUL flag associated with that buffer is set.
  - 3: 'Read' signifies that the user software unloads the FIFO message buffer by reading the contents of that buffer. Once the buffer location is read, the user software clears the RXFUL bit corresponding to that buffer.

#### 21.7.5 DeviceNet™ Filtering

The DeviceNet filtering feature is based on the CAN Specification 2.0A protocol, in which up to 18 bits of the data field can be compared with the EID of the message acceptance filter in addition to the SID.


The DeviceNet feature is enabled or disabled by the DeviceNet Filter Bit Number (DNCNT<4:0>) control bits in ECAN Control Register 2 (CiCTRL2<4:0>). The value specified in the DNCNT field determines the number of data bits to be used for comparison with the EID bits of the message acceptance filter. If the DNCNT<4:0> bits (CiCTRL2<4:0>) are cleared, the DeviceNet feature is disabled.

For a message to be accepted, the 11-bit SID must match the SID<10:0> bits in the message acceptance filter and the first 'n' data bits in the message should match the EID<17:0> bits in the message acceptance filter. For example, as illustrated in Figure 21-16, the first 18 data bits of the received message are compared with the corresponding identifier bits (EID<17:0>) of the message acceptance filter.

**Note:** The DeviceNet filtering feature will function only when all of the following are true:

- The IDE bit (ECAN Message Buffer Word 0<0>) = 0, which means the message is a standard ID message
- The EXIDE bit (CiRXFn<3>) = 0
- The MIDE bit (CiRXMnSID<3> = 1
- The value of the DNCNT<4:0> bits (CiCTRL2<4:0>) is non-zero

Figure 21-16: ECAN™ Operation with DeviceNet™ Filtering



#### 21.7.5.1 FILTER COMPARISONS

Table 21-3 shows the filter comparisons configured by the DNCNT<4:0> control bits (CiCTRL2<4:0>). For example, if DNCNT<4:0> = 00011, a message in which only the 11-bit SID matches the SID acceptance filter (SID<10:0>), and bits 7, 6 and 5 of Data Byte 0 match the EID filter (EID<2:0>) is accepted.

Table 21-3: DeviceNet™ Filter Bit Configurations

DeviceNet™ Filter Configuration (DNCNT<4:0>)	Received Message Data Bits to be Compared (Byte bits>)	EID Bits Used for Acceptance Filter
00000	No comparison	No comparison
00001	Data Byte 0<7>	EID<17>
00010	Data Byte 0<7:6>	EID<17:16>
00011	Data Byte 0<7:5>	EID<17:15>
00100	Data Byte 0<7:4>	EID<17:14>
00101	Data Byte 0<7:3>	EID<17:13>
00110	Data Byte 0<7:2>	EID<17:12>
00111	Data Byte 0<7:1>	EID<17:11>
01000	Data Byte 0<7:0>	EID<17:10>
01001	Data Byte 0<7:0> and Data Byte 1<7>	EID<17:9>
01010	Data Byte 0<7:0> and Data Byte 1<7:6>	EID<17:8>
01011	Data Byte 0<7:0> and Data Byte 1<7:5>	EID<17:7>
01100	Data Byte 0<7:0> and Data Byte 1<7:4>	EID<17:6>
01101	Data Byte 0<7:0> and Data Byte 1<7:3>	EID<17:5>
01110	Data Byte 0<7:0> and Data Byte 1<7:2>	EID<17:4>
01111	Data Byte 0<7:0> and Data Byte 1<7:1>	EID<17:3>
10000	Data Byte 0<7:0> and Data Byte 1<7:0>	EID<17:2>
10001	Byte 0<7:0> and Byte 1<7:0> and Byte 2<7>	EID<17:1>
10010	Byte 0<7:0> and Byte 1<7:0> and Byte 2<7:6>	EID<17:0>
10011	Invalid Selection	Invalid Selection
•		
11111		

#### 21.7.5.2 SPECIAL CASES

There may be special cases when the message contains fewer data bits than are called for by the DeviceNet filter configuration:

- Case 1 If DNCNT<4:0> is greater than 18, indicating that the user application selected a
  number of bits greater than the total number of EID bits, the filter comparison terminates
  with the 18th bit of the data (bit 6 of data byte 2). If the SID and all 18 data bits match, the
  message is accepted.
- Case 2 If DNCNT<4:0> is greater than 16, and the received message DLC is 2 (indicating a payload of two data bytes), the filter comparison terminates with the 16th bit of data (bit 0 of data byte 1). If the SID and all 16 bits match, the message is accepted.
- Case 3 If DNCNT<4:0> is greater than 8, and the received message has DLC = 1 (indicating a payload of one data byte), the filter comparison terminates with the 8th bit of data (bit 0 of data byte 0). If the SID and all 8 bits match, the message is accepted.
- Case 4 If DNCNT<4:0> is greater than 0, and the received message has DLC = 0, indicating no data payload, the filter comparison terminates with the SID. If the SID matches, the message is accepted.

## 21.8 DMA CONTROLLER CONFIGURATION

The ECAN module uses device RAM for the message buffers to support both transmission and reception of CAN messages. The number of message buffers to be used by the ECAN module is specified by the DMA Buffer Size bits (DMABS<2:0>) in the ECAN FIFO Control register (CiFCTRL<15:13>). The DMAxSTAL and DMAxSTAH registers in the DMA controller defines the start of the CAN buffer area. The DMA controller moves data between ECAN and the message buffers (placed in device RAM) without CPU intervention.

For more information on configuring and using the DMA module, refer to **Section 22.** "**Direct Memory Access (DMA)**" (DS70348) of the "dsPIC33E/PIC24E Family Reference Manual", which is available from the Microchip web site (www.microchip.com).

#### 21.8.1 DMA Operation for Transmitting Data

The user application selects a message for transmission by setting the Message Send Request bit (TXREQ) in the ECAN TX/RX Buffer m or n Control register (CiTRmnCON<3>). The ECAN controller uses DMA to read the message from the message buffer and transmit the message. The ECAN module generates a transmit data interrupt to start a DMA cycle. In response to the interrupt, the DMA channel that is configured for ECAN message transmission reads from the message buffer in device RAM and stores the message in the ECAN Transmit Data register (CiTXD). Eight words are transferred for every message transmitted by the ECAN controller. The detailed layout of the transmit message buffer is provided in 21.2 "CAN Message Formats". A sample code for configuring the DMA channel for ECAN1 transmission is shown in Example 21-6.

#### **Example 21-6: DMA Channel 0 Configuration for ECAN1 Transmission**

```
/\star This code snippet shows an example of configuring a DMA channel for ECAN
transmission. Refer to Example 21-1 for an application example */
/* Data Transfer Size: Word Transfer Mode */
DMA0CONbits.SIZE = 0x0;
/* Data Transfer Direction: device RAM to Peripheral */
DMA()CONbits DTR = 0x1:
/* DMA Addressing Mode: Peripheral Indirect Addressing mode */
DMA0CONbits.AMODE = 0x2;
/* Operating Mode: Continuous, Ping-Pong modes disabled */
DMA0CONbits.MODE = 0x0;
/* Assign ECAN1 Transmit event for DMA Channel 0 */
DMAOREQ = 70;
/* Set Number of DMA Transfer per ECAN message to 8 words */
DMAOCNT = 7:
/* Peripheral Address: ECAN1 Transmit Register */
DMAOPAD = (volatile unsigned int); & CITxD;
unsigned long address;
DMA1STAL = (unsigned int) &ecan1msgBuf;
DMA1STAH = (unsigned int) &ecan1msgBuf;
/* Channel Enable: Enable DMA Channel 0 */
DMA0CONbits.CHEN = 0x1;
/* Channel Interrupt Enable: Enable DMA Channel 0 Interrupt */
IECObits DMA0IE = 1;
```

#### 21.8.2 DMA Operation for Receiving Data

When the ECAN controller completes a received message (eight words), the completed message is transferred to a message buffer in device RAM by the DMA module. The ECAN module generates a receive data interrupt to start a DMA cycle. In response to this interrupt, the DMA channel that is configured for ECAN message reception reads from the ECAN Receive Data register (CiRXD) and stores the message in the device RAM buffer. Eight words are transferred for every message that is received by the ECAN controller. The detailed layout of the received message is provided in 21.2 "CAN Message Formats". A sample code for configuring the DMA channel for ECAN1 reception is shown in Example 21-7.

Example 21-7: DMA Channel 1 Configuration for ECAN1 Reception

```
/* This code snippet shows an example of configuring a DMA channel for the
ECAN message reception. Refer to Example 21-4 for an application example */
/* Data Transfer Size: Word Transfer Mode */
DMA1CONbits.SIZE = 0x0;
/* Data Transfer Direction: Peripheral to device RAM */
DMA1CONbits.DIR = 0x0;
/* DMA Addressing Mode: Peripheral Indirect Addressing mode */
DMA1CONbits.AMODE = 0x2;
/* Operating Mode: Continuous, Ping-Pong modes disabled */
DMA1CONbits.MODE = 0x0;
/* Assign ECAN1 Receive event for DMA Channel 0 */
DMA1REQ = 34;
^{\prime \star} Set Number of DMA Transfer per ECAN message to 8 words ^{\star \prime}
DMA1CNT = 7;
/* Peripheral Address: ECAN1 Receive Register */
DMA1PAD = (volatile unsigned int) &C1RXD;
unsigned long address;
DMA1STAL = (unsigned int) &ecan1msgBuf;
DMA1STAH = (unsigned int) &ecan1msgBuf;
/* Channel Enable: Enable DMA Channel 1 */
DMA1CONbits.CHEN = 0x1;
/* Channel Interrupt Enable: Enable DMA Channel 1 Interrupt */
IECObits.DMA1IE = 1;
```

**Note:** For more information on how to configure the DMA Controller, refer to **Section 22**. "**Direct Memory Access (DMA)**" (DS70348).

## 21.9 BIT TIMING


The nominal bit rate is the number of bits per second transmitted on the CAN bus.

Nominal Bit Time = 1 ÷ Nominal Bit Rate

There are four time segments in a bit time to compensate for any phase shifts due to oscillator drifts or propagation delays. These time segments do not overlap each other and are represented in terms of TQ. One TQ is a fixed unit of time derived from the oscillator clock. The total number of time quanta in a nominal bit time must be programmed between 8 TQ and 25 TQ.

Figure 21-17 illustrates how the time quantum frequency (FTQ) is obtained from the system clock and also how the different time segments are programmed.

Figure 21-17: ECAN™ Bit Timing



#### 21.9.1 Bit Segments

Each bit transmission time consists of four time segments:

- Synchronization Segment This time segment synchronizes the different nodes connected on the CAN bus. A bit edge is expected to be within this segment. Based on CAN protocol, the Synchronization Segment is assumed to be 1 TQ.
- **Propagation Segment** This time segment compensates for any time delay that may occur due to the bus line or due to the various transceivers connected on that bus.
- Phase Segment 1 This time segment compensates for errors that may occur due to
  phase shift in the edges. The time segment may be lengthened during resynchronization to
  compensate for the phase shift.
- Phase Segment 2 This time segment compensates for errors that may occur due to phase shift in the edges. The time segment may be shortened during resynchronization to compensate for the phase shift. The Phase Segment 2 time can be configured to be either programmable or specified by the Phase Segment 1 time.

#### 21.9.2 Sample Point

The sample point is the point in a CAN bit time interval where the sample is taken and the bus state is read and interpreted. It is situated between Phase Segment 1 and Phase Segment 2. The CAN bus can be sampled once or three times at the sample point, as configured by the Sample CAN bus Line bit (SAM) in ECAN Baud Rate Configuration register (CiCFG2<6>).

- If CiCFG2<6> = 1, the CAN bus is sampled three times at the sample point. The most common of the three samples determines the bit value.
- If CiCFG2<6> = 0, the CAN bus is sampled only once at the sample point.

#### 21.9.3 Synchronization

Two types of synchronization are used: Hard Synchronization and Resynchronization. A Hard Synchronization occurs once at the SOF. Resynchronization occurs inside a frame.

- **Hard synchronization** takes place on the recessive-to-dominant transition of the start bit. The bit time is restarted from that edge.
- Resynchronization takes place when a bit edge does not occur within the Synchronization Segment in a message. One of the Phase Segments is shortened or lengthened by an amount that depends on the phase error in the signal. The maximum amount that can be used is determined by the Synchronization Jump Width parameter (CiCFG1<7:6>).

The length of Phase Segment 1 and Phase Segment 2 can be changed depending on oscillator tolerances of the transmitting and receiving node. Resynchronization compensates for any phase shifts that may occur due to the different oscillators used by the transmitting and receiving nodes.

- Bit Lengthening If the transmitting node in ECAN has a slower oscillator than the receiving node, the next falling edge, and therefore, the sample point can be delayed by lengthening Phase Segment 1 in the bit time.
- **Bit Shortening** If the transmitting node in ECAN has a faster oscillator than the receiving node, the next falling edge, and therefore, the sample point of the next bit can be reduced by shortening the Phase Segment 2 in the bit time.
- Synchronization Jump Width (SJW) The SJW<1:0> bits (CiCFG1<7:6>) determine the synchronization jump width by limiting the amount of lengthening or shortening that can be applied to the Phase Segment 1 and Phase Segment 2 time intervals. This segment should not be longer than Phase Segment 2 time. The width can be 1 TQ 4 TQ.

#### 21.9.4 ECAN Bit Time Calculations

The steps that must be performed by the user application to configure the bit timing for the ECAN module are described below along with examples. It is assumed that the CANCKS bit (CiCTRL<11>) is cleared resulting in FCAN = FP.

#### 21.9.4.1 STEP 1: CALCULATE THE TIME QUANTUM FREQUENCY (FTQ)

- Select the Baud Rate (FBAUD) for the CAN Bus.
- Select the number of time quanta in a bit time, based on your system requirements.

Equation 21-2 shows the formula for computing FTQ.

#### Equation 21-2: Time Quantum Frequency (FTQ)

$$F_{TQ} = N \times F_{BAUD}$$

- **Note 1:** The total number of time quanta in a nominal bit time must be programmed between 8 TQ and 25 TQ. Therefore, the FTQ is between 8 to 25 times the baud rate (FBAUD).
  - **2:** Ensure that FTQ is an integer multiple of FBAUD to get the precise bit time. Otherwise, the oscillator input frequency or the FBAUD may need to be changed.

21.9.4.2 STEP 2: CALCULATE THE BAUD RATE PRESCALER (BRP<5:0> (CiCFG1<5:0>))

Equation 21-3 shows the formula for computing the baud rate prescaler.

#### Equation 21-3: Baud Rate Prescaler

$$BRP < 5:0 > (CiCFG1 < 5:0 >) = \frac{F_{CAN}}{(2 \times F_{TQ})} - 1$$

#### 21.9.4.3 STEP 3: SELECT THE INDIVIDUAL BIT TIME SEGMENTS

The Individual Bit Time Segments are selected using the CiCFG2 register:

Bit Time = Sync Segment + Propagation Segment + Phase Segment 1 + Phase Segment 2

- **Note 1:** (Propagation Segment + Phase Segment 1) must be greater than or equal to the length of Phase Segment 2.
  - 2: Phase Segment 2 must be greater than the Synchronous Jump Width.

Example 21-8 shows the procedure to calculate the FTQ, to obtain a CAN Bus speed of 1 Mbps when the dsPIC33E/PIC24E device is operating at 40 MHz.

#### Example 21-8: CAN Bit Timing Calculation Example

Step 1: Calculate the FTQ.

If FBAUD = 1 Mbps, and the number of time quanta 'N' = 20, then FTQ = 20 MHz

Step 2: Calculate the baud rate prescaler.

BRP<5:0> (CiCFG1<5:0>) = [40000000/(2 \* FTQ)] - 1 = 1 - 1 = 0

Step 3: Select the individual bit time segments.

Synchronization Segment = 1 TQ (constant)

Based on system characteristics, if Propagation Delay = 5 TQ, if the sample point is to be at 70% of Nominal Bit Time, then:

Phase Segment 2 = 30% of Nominal Bit Time = 6 TQ

Phase Segment 1 = 20 TQ - (1 TQ + 5 TQ + 6 TQ) = 8 TQ

A code example for configuring the ECAN bit timing parameters is shown in Example 21-9.

#### **Example 21-9:** Code Example for Configuring ECAN™ Bit Timing Parameters

```
/* This code snippet shows an example of configuring the ECAN module to
   operate at 1 Mbps while the device is operating at 40 MHz ^{*}/
/* Set the Operating Frequency of the device to be 40 MHz */
#define FP 40000000
/* Set the ECAN module for Configuration Mode before writing into the Baud
   Rate Control Registers */
C1CTRL1bits.REQOP = 4;
/* Wait for the ECAN module to enter into Configuration Mode */
while(C1CTRL1bits.OPMODE! = 4);
/* FCAN is selected to be FP by clearing the CANCKS bit
/* FCAN = FP = 40 MHz */
C1CTRL1bits.CANCKS = 0x0;
/* Phase Segment 1 time is 8 TQ */
C1CFG2bits.SEG1PH = 0x7;
/* Phase Segment 2 time is set to be programmable */
C1CFG2bits.SEG2PHTS = 0x1;
/* Phase Segment 2 time is 6 TQ */
C1CFG2bits.SEG2PH = 0x5;
/* Propagation Segment time is 5 TQ */
C1CFG2bits.PRSEG = 0x4;
/* Bus line is sampled three times at the sample point */
C1CFG2bits.SAM = 0x1;
/* Synchronization Jump Width set to 4 TQ */
C1CFG1bits.SJW = 0x3;
/* Baud Rate Prescaler bits set to 1:1, (i.e., TQ = (2*1*1)/FCAN) */
C1CFG1bits.BRP = 0x0;
/* Put the ECAN Module into Normal Operating Mode */
C1CTRL1bits.REQOP = 0;
/\star Wait for the ECAN module to enter into Normal Operating Mode \star/
while(C1CTRL1bits.OPMODE! = 0);
```

## 21.10 ECAN ERROR MANAGEMENT

#### 21.10.1 CAN Bus Errors

The CAN specification defines five different ways of detecting errors:

- · Bit Error
- · Acknowledge Error
- · Form Error
- · Stuffing Error
- CRC Error

The bit error and the acknowledge error occur at the bit level; the other three errors occur at the message level.

#### 21.10.1.1 BIT ERROR

A node that is sending a bit on the bus also monitors the bus. A bit error is detected when the bit value that is monitored is different from the bit value that is sent. An exception is when a recessive bit is sent during the stuffed bit stream of the Arbitration field or during the ACK slot. In this case, no bit error occurs when a dominant bit is monitored. A transmitter sending a passive error frame and detecting a dominant bit does not interpret this as a bit error.

#### 21.10.1.2 ACKNOWLEDGE ERROR

In the Acknowledge field of a message, the transmitter checks if the Acknowledge Slot (which it has sent out as a recessive bit) contains a dominant bit. If not, this implies that no other node has received the frame correctly. An acknowledge error has occurred, and as a result, the message must be repeated. No error frame is generated in this case.

#### 21.10.1.3 FORM ERROR

A form error is detected when a fixed-form bit field (EOF, Inter-frame Space, Acknowledge Delimiter or CRC Delimiter) contains one or more illegal bits. For a receiver, a dominant bit during the last bit of EOF is not treated as a form error.

#### 21.10.1.4 STUFFING ERROR

A stuffing error is detected at the bit time of the sixth consecutive equal bit level in a message field that should be coded by the method of bit stuffing.

#### 21.10.1.5 CRC ERROR

The node transmitting a message computes and transmits the CRC corresponding to the transmitted message. Every receiver on the bus performs the same CRC calculation as the transmitter. A CRC error is detected if the calculated result is not the same as the CRC value obtained from the received message.

#### 21.10.2 Fault Confinement

Every CAN controller on a bus tries to detect the errors outlined above within each message. If an error is found, the discovering node transmits an error frame, thus destroying the bus traffic. The other nodes detect the error caused by the error frame (if they have not already detected the original error) and take appropriate action (that is, discard the current message).

The ECAN module maintains two error counters:

- Transmit Error Counter (CiEC<15:8>)
- Receive Error Counter (CiEC<7:0>)

There are several rules governing how these counters are incremented and/or decremented. That is, a transmitter detecting a fault increments its transmit error counter faster than the listening nodes will increment their receive error counter. This is because there is a good chance that it is the transmitter that is at fault.

Note: The error counters are modified according to the CAN Specification 2.0B.


# dsPIC33E/PIC24E Family Reference Manual

A node starts out in the Error Active mode. When any one of the two Error Counters equals or exceeds a value of 127, the node enters a state known as Error Passive. When the Transmit Error Counter exceeds a value of 255, the node enters the Bus OFF state.

- · An Error Active node transmits an Active Error Frame when it detects errors
- · An Error Passive node transmits a Passive Error Frame when it detects errors
- · A node that is in the Bus OFF state transmits nothing on the bus

In addition, the ECAN module employs an error warning feature that warns the user application (when the Transmit Error Counter equals or exceeds 96) before the node enters the Error Passive state, as illustrated in Figure 21-18.

Figure 21-18: Error Modes



#### 21.10.2.1 TRANSMITTER IN ERROR PASSIVE STATE

The Transmitter Error Passive (TXBP) bit (CilNTF<12>) is set when the Transmit Error Counter equals or exceeds 128 and generates an error interrupt (CilNTF<5>) upon entry into the Error Passive state. The Transmit Error Passive flag is cleared automatically by the hardware, if the Transmit Error Counter becomes less than 128 or greater than 255.

#### 21.10.2.2 RECEIVER IN ERROR PASSIVE STATE

The Receiver Error Passive (RXBP) bit (CilNTF<11>) is set when the Receive Error Counter equals or exceeds 128 and generates an error interrupt (CilNTF<5>) upon entry into the Error Passive state. The Receive Error Passive flag is cleared automatically by the hardware, if the Receive Error Counter becomes less than 128 or greater than 255.

#### 21.10.2.3 TRANSMITTER IN BUS OFF STATE

The Transmitter Bus OFF (TXBO) bit (CiINTF<13>) is set when the Transmit Error Counter equals or exceeds 256 and generates an error interrupt (CiINTF<5>)

#### 21.10.2.4 TRANSMITTER IN ERROR WARNING STATE

The Transmitter Error Warn (TXWAR) bit (CilNTF<10>) is set when the Transmit Error Counter is in the range of 96 and 127 (inclusive), and generates an error interrupt (CilNTF<5>) upon entry into the Error Warn state. The Transmit Error Warn flag is cleared automatically by the hardware, if the Transmit Error Counter becomes less than 96 or greater than 127.

#### 21.10.2.5 RECEIVER IN ERROR WARNING STATE

The Receiver Error Warn (RXWAR) bit (CilNTF<9>) is set when the Receive Error Counter is in the range of 96 and 127 (inclusive) and generates an error interrupt (CilNTF<5>) upon entry into the Error Warn state. The Receive Error Warn flag is cleared automatically by the hardware if the Receive Error Counter becomes less than 96.

Additionally, there is an Error State Warning Flag (EWARN) bit (CiINTF<8>), which is set if at least one of the error counters equals or exceeds the error warning limit of 96. EWARN is reset if both error counters are less than the error warning limit.

## 21.11 ECAN INTERRUPTS

The ECAN module generates three different interrupts, each with its own interrupt vector, interrupt enable control bit, interrupt status flag and interrupt priority control bit. These interrupts are:

- CiTX ECAN Transmit Data Request
- · CiRX ECAN Receive Data Ready
- Ci ECAN Event Interrupt

#### 21.11.1 ECAN Transmit Data Request Interrupt

The transmit data request interrupt represents the transmission of a single word in an ECAN message through the ECAN Transmit Data register (CiTXD). The user application needs to assign the ECAN transmit data request interrupt to a DMA channel to automatically transfer messages from the appropriate device RAM buffers to the ECAN module (CiTXD register).

#### 21.11.2 ECAN Receive Data Ready Interrupt

The receive data request interrupt represents the reception of a single word of an ECAN message through the ECAN Receive Data register (CiRXD). The user application needs to assign the ECAN receive data ready interrupt to a DMA channel to automatically transfer messages from the ECAN module (CiRXD register) to the appropriate device RAM buffers.

#### 21.11.3 ECAN Event Interrupt

The ECAN event interrupt has seven main sources, each of which can be individually enabled. The Interrupt Flag register (CiINTF) contains the interrupt flags, and the Interrupt Enable register (CiINTE) contains the enable bits. The Interrupt Flag Code bits (ICODE<6:0>) in the ECAN Interrupt Code register (CiVEC<6:0>) can be used in combination with a jump table for efficient handling of interrupts. All interrupts have one source, with the exception of the Error Interrupt. Any of five error interrupt sources (TX Error Warn, RX Error Warn, TX Error Passive, RX Error Passive and TX Bus OFF) can set an error interrupt flag. The source of the error interrupt is determined by reading the CiINTF register.

**Note:** The ICODE<6:0> bits will reflect the highest priority CAN interrupt condition that is active. For this, the interrupt should be enabled (the IE bit in the CilNTE register should be set) and the interrupt condition should be active (the IF bit in the CilNTF register should be set).

Figure 21-19 illustrates the ECAN event interrupt generation from various interrupt sources.




Figure 21-19: ECAN™ Event Interrupts

#### 21.11.3.1 TRANSMIT BUFFER INTERRUPT

The message buffers 0 to 7 that are configured for message transmission set the Transmit Buffer Interrupt (TBIF) bit (CiINTF<0>) after the CAN message is transmitted. The ICODE<6:0> bits (CiVEC<6:0>) indicate the specific message buffer that generated the transmit buffer interrupt. Transmit buffer interrupt must be cleared in the Interrupt Service Routine (ISR) by clearing the TBIF bit.

# Section 21. Enhanced Controller Area Network (ECAN™)

#### 21.11.3.2 RECEIVE BUFFER INTERRUPT

When a message is successfully received and loaded into one of the receive buffers (message buffers 0 to 31), the receive buffer interrupt (CiINTF<1>) is activated after the module sets the RXFULn bits in the CiRXFULm registers. The ICODE<6:0> bits (CiVEC<6:0>) will indicate the particular buffer that generated the interrupt. The receive buffer interrupt must be cleared in the ISR by clearing the RBIF bit.

#### 21.11.3.3 RECEIVE BUFFER OVERFLOW INTERRUPT

When a message is successfully received but the designated buffer is full, the receive overflow interrupt (CilNTF<2>) is activated after the module sets the RXOVFn bits in the CiRXOVFm registers. The ICODE<6:0> bits (CiVEC<6:0>) indicate which buffer generated the interrupt. The receive buffer overflow interrupt must be cleared in the ISR by clearing the RBOVIF bit (CilNTF<2>).

#### 21.11.3.4 FIFO ALMOST FULL INTERRUPT

When the FIFO has only one remaining available buffer, the FIFO interrupt (CilNTF<3>) is activated after the module sets the RXFULn bits in the CiRXFULm registers for the next to last available buffer. The ICODE<6:0> bits (CiVEC<6:0>) indicate the FIFO overflow condition. The FIFO almost full interrupt must be cleared in the ISR by clearing the FIFOIF bit (CilNTF<3>).

#### 21.11.3.5 ERROR INTERRUPT

The error interrupt (CiINTF<5>) is generated by five sources:

- TX Error Warn
- RX Error Warn
- TX Frror Passive
- RX Error Passive
- · TX Bus Off

The ICODE<6:0> bits (CiVEC<6:0>) indicate the Error condition. The error interrupt must be cleared in the ISR by clearing the ERRIF bit (CiINTF<5>).

#### 21.11.3.6 WAKE-UP INTERRUPT

In Sleep mode, the device monitors the ECAN receive pin (CiRX) for bus activity. A wake-up (CilNTF<6>) interrupt is generated when bus activity is detected. The ICODE<6:0> bits (CiVEC<6:0>) indicate the wake-up condition. The wake-up interrupt must be cleared in the ISR by clearing the WAKIF bit (CilNTF<6>).

#### 21.11.3.7 INVALID MESSAGE INTERRUPT

The invalid message/transmission interrupt is generated for any other type of errors during message reception or transmission.

#### 21.12 ECAN LOW-POWER MODES

The ECAN module can respond to the CPU PWRSAV instruction.

#### 21.12.1 Sleep Mode

A CPU PWRSAV, 1 instruction stops the crystal oscillator and shuts down all system clocks. The user application must ensure that the module is not active when the CPU goes into Sleep mode. To protect the CAN bus system from fatal consequences due to violations of the above rule, the module drives the CiTX pin into the recessive state while in Sleep mode. The recommended procedure is to bring the module into Disable mode before the CPU PWRSAV, 1 instruction is executed.

#### 21.12.2 Idle Mode

A CPU PWRSAV, 0 instruction signals the module to optionally shut down clocks. The module powers down, if the Stop in Idle Mode bit (CSIDL) in the ECAN Control Register 1 (CiCTRL1<13>) is '1'. The user application must ensure that the module is not active when the CPU goes into Idle mode. To protect the CAN bus system from fatal consequences due to violations of the above rule, the module drives the CiTX pin into the recessive state while in Sleep mode. The recommended procedure is to bring the module into Disable mode before the CPU PWRSAV, 0 instruction is executed.

## 21.12.3 Wake-up Functions

The module monitors the RX line for activity while the device is in Sleep mode. If the WAKIE bit is set, the module generates an interrupt if bus activity is detected. Due to the delays in starting up the oscillator and CPU, the message activity that caused the wake-up is lost.

After the CPU wakes up from Sleep, the CPU executes the CAN event ISR (if interrupts are enabled); however, the CAN module itself would still be disabled. The CAN bus wake-up feature only wakes when the device is in Sleep mode.

The module features a low-pass filter on the CiRX input line, which should be enabled when the module is in CPU Sleep mode. This filter protects the module from wake-up due to short glitches on the CAN bus. The filter is enabled by setting the WAKFIL bit (CiCFG2<14>).

**Note:** The ECAN wake-up filter must be enabled for the module to wake-up from Sleep mode on detecting CAN bus activity.

#### 21.13 ECAN TIME STAMPING USING INPUT CAPTURE

The ECAN module generates a signal that can be sent to a timer capture input whenever a valid frame has been accepted. This is useful for time-stamping and network synchronization. Because the CAN Specification defines a frame to be valid if no errors occurred before the EOF field has been transmitted successfully, the timer signal will be generated right after the EOF. A pulse of one bit time is generated. Time-stamping is enabled by the CAN Message Receive Timer Capture Event Enable (CANCAP) control bit (CiCTRL1<3>). The IC2 capture input is used for time-stamping.

**Note:** If the CAN capture is enabled, the IC2 pin becomes unusable as a general input capture pin. In this mode, the IC2 channel derives its input signal from the C1RX or C2RX pin instead of the IC2 pin.

#### **REGISTER MAPS** 21.14

Table 21-4 through Table 21-6 map the bit functions for the Enhanced Controller Area Network (ECAN™) registers.

Table 21-4: ECAN Register Map When C1CTRL1.WIN = 0 or 1

File Name	Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	All Resets	
CiCTRL1		-	CSIDL	ABAT	CANCKS	R	EQOP<2:0	>	OPI	MODE<2:0	>	_	CANCAP	_	_	WIN	0480	
CiCTRL2	_	_	_	_	_	_	_	_	_	_	_		D	NCNT<4:0>	•		0000	
CiVEC	_	_	_		F	ILHIT<4:0>	_		_				ICODE<6:0>	•		WIN  RBIF TBIF RBIE TBIE  EG<2:0> .TEN1 FLTEN0		
CiFCTRL	[	DMABS<2:0	>	_	_	_	_	_	_	_	_		FSA<4:0>					
CiFIFO	_	_			FBP<	5:0>			_	_		FNRB<5:0>				0000		
CiINTF	-	-	TXBO	TXBP	RXBP	TXWAR	RXWAR	EWARN	IVRIF	WAKIF	ERRIF	_	FIFOIF	RBOVIF	RBIF	TBIF	0000	
CiINTE	-	_	_	_	_	_	_	_	IVRIE	WAKIE	ERRIE	_	FIFOIE	RBOVIE	RBIE	TBIE	0000	
CiEC				TERRON	NT<7:0>							RERRCN	T<7:0>				0000	
CiCFG1	ı	1	_	_	_	ı	_	_	SJW<1	1:0>			BRP<	5:0>			0000	
CiCFG2	ı	WAKFIL	ı	_	_	SE	EG2PH<2:0	)>	SEG2PHTS	SAM	S	EG1PH<2:	0>	Р	RSEG<2:0	RBIE TBIE  SEG<2:0> FLTEN1 FLTEN0 FOMSK<1:0>		
CiFEN1	FLTEN15	FLTEN14	FLTEN13	FLTEN12	FLTEN11	FLTEN10	FLTEN9	FLTEN8	FLTEN7	FLTEN6	FLTEN5	FLTEN4	FLTEN3	FLTEN2	FLTEN1	FLTEN0	FFFF	
CiFMSKSEL1	F7MSI	<<1:0>	F6MSI	K<1:0>	F5MS	K<1:0>	F4MS	K<1:0>	F3MSK<	<1:0>	F2MSk	<<1:0>	F1MSk	<1:0>	F0MS	0000		
CiFMSKSEL2	F15MS	K<1:0>	F14MS	K<1:0>	F13MS	K<1:0>	F12MS	SK<1:0>	F11MSK	<1:0>	F10MS	K<1:0>	F9MSk	<1:0>	F8MS	- WIN  RBIF TBIF RBIE TBIE  SEG<2:0> CITEN1 FLTEN0		

— = unimplemented, read as '0'. Reset values are shown in hexadecimal.

Not all bits are available for all devices. Please refer to the "Enhanced Controller Area Network (ECAN™)" chapter in the specific device data sheet for more details.

**ECAN Register Map When C1CTRL1.WIN = 0** Table 21-5:

File Name	Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	All Resets
							Se	e definition	when WIN =	= x							
CiRXFUL1	RXFUL15	RXFUL14	RXFUL13	RXFUL12	RXFUL11	RXFUL10	RXFUL9	RXFUL8	RXFUL7	RXFUL6	RXFUL5	RXFUL4	RXFUL3	RXFUL2	RXFUL1	RXFUL0	0000
CiRXFUL2	RXFUL31	RXFUL30	RXFUL29	RXFUL28	RXFUL27	RXFUL26	RXFUL25	RXFUL24	RXFUL23	RXFUL22	RXFUL21	RXFUL20	RXFUL19	RXFUL18	RXFUL17	RXFUL16	0000
CiRXOVF1	RXOVF15	RXOVF14	RXOVF13	RXOVF12	RXOVF11	RXOVF10	RXOVF9	RXOVF8	RXOVF7	RXOVF6	RXOVF5	RXOVF4	RXOVF3	RXOVF2	RXOVF1	RXOVF0	0000
CiRXOVF2	RXOVF31	RXOVF30	RXOVF29	RXOVF28	RXOVF27	RXOVF26	RXOVF25	RXOVF24	RXOVF23	RXOVF22	RXOVF21	RXOVF20	RXOVF19	RXOVF18	RXOVF17	RXOVF16	0000
CiTR01CON	TXEN1	TXABT1	TXLARB1	TXERR1	TXREQ1	RTREN1	TX1PF	RI<1:0>	TXEN0	TXABAT0	TXLARB0	TXERR0	TXREQ0	RTREN0	TX0PF	RI<1:0>	0000
Ci1TR23CON	TXEN3	TXABT3	TXLARB3	TXERR3	TXREQ3	RTREN3	TX3PF	RI<1:0>	TXEN2	TXABAT2	TXLARB2	TXERR2	TXREQ2	RTREN2	TX2PF	RI<1:0>	0000
CiTR45CON	TXEN5	TXABT5	TXLARB5	TXERR5	TXREQ5	RTREN5	TX5PF	RI<1:0>	TXEN4	TXABAT4	TXLARB4	TXERR4	TXREQ4	RTREN4	TX4PF	RI<1:0>	0000
CiTR67CON	TXEN7	TXABT7	TXLARB7	TXERR7	TXREQ7	RTREN7	TX7PF	RI<1:0>	TXEN6	TXABAT6	TXLARB6	TXERR6	TXREQ6	RTREN6	TX6PF	RI<1:0>	xxxx
CiRXD			•					Received	Data Word								xxxx
CiTXD								Transmit I	Data Word								xxxx

x = unknown value on Reset, — = unimplemented, read as '0'. Reset values are shown in hexadecimal.

Not all bits are available for all devices. Please refer to the "Enhanced Controller Area Network (ECAN™)" chapter in the specific device data sheet for more details.

Section 21. Enhanced Controller Area Network (ECAN™

Table 21-6: ECAN Register Map When C1CTRL1.WIN = 1

File Name	Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	All Resets
								See defini	tion when WIN = x								
CiBUFPNT1		F3BF	P<3:0>			F2BI	P<3:0>		F1BP<3:0> F0BP<3:0>								0000
CiBUFPNT2		F7BF	P<3:0>			F6BI	P<3:0>			F5BP	<3:0>			0000			
CiBUFPNT3		F11BP<3:0> F10BP<3:0>								F9BP	<3:0>			F8BP	<3:0>		0000
CiBUFPNT4		F15BI	P<3:0>			F14B	P<3:0>			F13BF	P<3:0>			F12BP	<3:0>		0000
CiRXM0SID				SID<	<10:3>					SID<2:0>		_	MIDE	_	EID<	17:16>	xxxx
CIRXM0EID				EID<	<15:8>							EID<	7:0>				xxxx
CiRXM1SID				SID<	<10:3>					SID<2:0>		_	MIDE	_	EID<	17:16>	xxxx
CiRXM1EID				EID<	<15:8>							EID<	7:0>				xxxx
CiRXM2SID				SID	<10:3>					SID<2:0>		_	MIDE	_	EID<	17:16>	xxxx
CiRXM2EID				EID<	<15:8>							EID<	7:0>				xxxx
CiRXF0SID				SID<	<10:3>								EID<	17:16>	xxxx		
CiRXF0EID		EID<15:8>										EID<	7:0>	-1			xxxx
CiRXF1SID	SID<10:3> EID<15:8>									SID<2:0>		_	EXIDE	_	EID<	17:16>	xxxx
CiRXF1EID				EID<	<15:8>							EID<	7:0>				xxxx
CiRXF2SID				SID	<10:3>					SID<2:0>		_	EXIDE	_	EID<	17:16>	xxxx
CiRXF2EID				EID<	<15:8>				EID<7:0>							xxxx	
CiRXF3SID				SID<	<10:3>				SID<2:0> — EXIDE — EID<17:1						17:16>	xxxx	
CiRXF3EID				EID<	<15:8>							EID<	7:0>				xxxx
CiRXF4SID				SID	<10:3>					SID<2:0>		_	EXIDE	_	EID<	17:16>	xxxx
CiRXF4EID				EID<	<15:8>							EID<	7:0>				XXXX
CiRXF5SID				SID	<10:3>					SID<2:0>		_	EXIDE	_	EID<	17:16>	xxxx
CiRXF5EID				EID<	<15:8>							EID<	7:0>				xxxx
CiRXF6SID				SID	<10:3>					SID<2:0>		_	EXIDE	_	EID<	17:16>	xxxx
CiRXF6EID				EID<	<15:8>							EID<	7:0>				xxxx
CiRXF7SID				SID	<10:3>					SID<2:0>		_	EXIDE	_	EID<	17:16>	xxxx
CiRXF7EID				EID<	<15:8>							EID<	7:0>				xxxx
CiRXF8SID				SID	<10:3>					SID<2:0>		_	EXIDE	_	EID<	17:16>	xxxx
CiRXF8EID				EID<	<15:8>							EID<	7:0>		•		xxxx
CiRXF9SID				SID	<10:3>					SID<2:0>		_	EXIDE	_	EID<	17:16>	xxxx
CiRXF9EID				EID<	<15:8>							EID<	7:0>		•		xxxx
CiRXF10SID				SID<	<10:3>					SID<2:0>		_	EXIDE	_	EID<	17:16>	xxxx
CiRXF10EID				EID<	<15:8>							EID<	7:0>		•		xxxx
CiRXF11SID				SID<	<10:3>					SID<2:0>		_	EXIDE	_	EID<	17:16>	xxxx
CiRXF11EID				EID<	<15:8>							EID<	7:0>		•		xxxx

dsPIC33E/PIC24E Family Reference Manual

**Legend:** x = unknown value on Reset, — = unimplemented, read as '0'. Reset values are shown in hexadecimal.

Note 1: Not all bits are available for all devices. Please refer to the "Enhanced Controller Area Network (ECAN™)" chapter in the specific device data sheet for more details.

Table 21-6: ECAN Register Map When C1CTRL1.WIN = 1 (Continued)

File Name	Bit 15	Bit 14	Bit 13	Bit 12	Bit 11	Bit 10	Bit 9	Bit 8	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0	All Resets	
CiRXF12SID				SID<	:10:3>					SID<2:0>		_	EXIDE	_	EID<17:16	xxxx		
CiRXF12EID				EID<	:15:8>				EID<7:0>									
CiRXF13SID	SID<10:3>									SID<2:0> — EXIDE — EID<17:16>						>	xxxx	
CiRXF13EID				EID<	:15:8>				EID<7:0>								xxxx	
CiRXF14SID				SID<	:10:3>					SID<2:0>		1	EXIDE	_	EID<17:16	>	xxxx	
CiRXF14EID				EID<	:15:8>				EID<7:0>								xxxx	
CiRXF15SID				SID<	:10:3>				SID<2:0>		·	-	EXIDE	_	EID<17:16	>	xxxx	
CiRXF15EID				EID<	:15:8>					EID<7:0>							xxxx	

Legend: x = unknown value on Reset, — = unimplemented, read as '0'. Reset values are shown in hexadecimal.

Note 1: Not all bits are available for all devices. Please refer to the "Enhanced Controller Area Network (ECAN™)" chapter in the specific device data sheet for more details.

## 21.15 RELATED APPLICATION NOTES

This section lists application notes that are related to this section of the manual. These application notes may not be written specifically for the dsPIC33E/PIC24E device family, but the concepts are pertinent and could be used with modification and possible limitations. The current application notes related to the Enhanced Controller Area Network (ECAN™) module are:

Title Application Note #

No application notes at this time.

N/A

**Note:** Please visit the Microchip web site (www.microchip.com) for additional Application Notes and code examples for the dsPIC33E/PIC24E family of devices.

#### 21.16 REVISION HISTORY

#### **Revision A (November 2008)**

This is the initial released version of this document.

#### Revision B (March 2011)

This revision incorporates the following updates:

- · Updated all DMA RAM references to device RAM
- Updated all time quanta clock (FTQ) references to time quantum frequency (FTQ)
- Updated all Remote Request Frame references to Remote Frame
- Updated all dsPIC33E references to dsPIC33E/PIC24E
- · Buffers:
  - Updated the bit value description for bit 1 and bit 0 in ECAN Message Buffer Word 0
  - Updated the bit value description for bit 9 in ECAN Message Buffer Word 2
- · Figures:
  - Updated Figure 21-1
  - Updated the label Message Buffer (DMA RAM) as Message Buffer (Device RAM) in Figure 21-2
  - Updated the logical value of SRR bit from '0' to '1' in Figure 21-5
  - Removed "Figure 21-17: ECAN™ Message Buffer Memory Usage" in 21.8 "DMA Controller Configuration"
  - Updated the figure title for Figure 21-9
  - Changed Baud Rate Prescaler input Fcy to Fcan in Figure 21-17
  - Updated Figure 21-18
- · Examples:
  - Updated Example 21-1 through Example 21-7 and Example 21-9
- · Equations:
  - Changed Fcy to Fcan in Equation 21-3
- · Notes:
  - Added a note on setting the TXREQm bit in 21.6.1 "Message Transmission Flow"
  - Deleted the following note in 21.6.1 "Message Transmission Flow": Avoid setting
    the TXREQ bit for a buffer that is configured for RX. Doing so can result in erroneous
    operation
  - Added a note in 21.6.3.2 "Respond to a Remote Frame"
  - Added a note on 21.7.2.2 "Receiving Messages Into Message Buffers 0-7"
  - Updated the entire note in Figure 21-14
  - Added a note on DeviceNet Filtering feature in 21.7.5 "DeviceNet™ Filtering"
  - Added a note that provides additional details on the highest priority CAN interrupt condition in 21.11.3 "ECAN Event Interrupt"
  - Updated the note on ECAN wake-up filter in 21.12.3 "Wake-up Functions"
- · Registers:
  - A general notes was added and FCY was changed to FCAN for the BRP<5:0> bit value definitions in Register 21-1
  - Updated the bit description for bit 15-13 in Register 21-18
  - Added the CANCKS bit in Register 21-23
  - Updated the bit value description for bit 2 in Register 21-25
- · Sections:
  - Updated the Message Reception key feature in 21.1 "Introduction"
  - Removed the following frame type from the list of CAN bus protocol supports four frame types, in 21.2 "CAN Message Formats": Interframe Space – provides a separation between successive frames
  - Updated 21.1.2 "Message Buffers" and 21.1.3 "DMA Controller"

#### Revision B (March 2011) (Continued)

- · Sections (Continued):
  - Updated the logical value of the SRR but from '0' to '1' in 21.2.2 "Extended Data Frame"
  - Updated the remote frame exceptions in 21.2.3 "Remote Frame"
  - Updated 21.2.6 "Interframe Space"
  - Updated the register description for CiCTRL1: ECAN Control Register 1 and CiCTRL2: ECAN Control Register 2 in 21.3.6 "ECAN Control and Error Counter Registers"
  - Changed the section title for 21.6.3 "Transmitting and Responding Remote Frames"
  - Changed the sub section title for 21.6.3.1 "Transmit a Remote Frame" and 21.6.3.2 "Respond to a Remote Frame"
  - Updated the remote frame exceptions in 21.6.3.1 "Transmit a Remote Frame"
  - Updated 21.8 "DMA Controller Configuration"
  - Updated the first paragraph of 21.9.4 "ECAN Bit Time Calculations"
  - Updated the transmit error counter range in 21.10.2.4 "Transmitter in Error Warning State"
  - Updated the receive error counter range in 21.10.2.5 "Receiver in Error Warning State"
  - Updated 21.11.3.7 "Invalid Message Interrupt"
  - Updated the term "TXCAN" to "CiTX" in 21.12.1 "Sleep Mode" and 21.12.2 "Idle Mode"
  - Updated 21.12.3 "Wake-up Functions"
- · Tables:
  - Added the CANCKS bit to the ECAN1 Register Map When C1CTRL1.WIN = 0 or 1 (see Table 21-4)
- Updated the Family Reference Manual name to dsPIC33E/PIC24E Family Reference Manual
- Additional minor corrections such as language and formatting updates were incorporated throughout the document

#### Revision C (December 2011)

This revision includes the following updates:

- · Throughout the document, all occurrences of FCY were updated to: FP
- · The following code examples were updated:
  - Code Example for Standard Data Frame Transmission (see Example 21-1)
  - Code Example for Extended Data Frame Transmission (see Example 21-2)
  - Code Example for Transmitting Extended Remote Frame (see Example 21-3)
  - Code Example for Filtering Standard Data Frame (see Example 21-4)
  - Code Example for Filtering Extended Data Frame (see Example 21-5)
  - DMA Channel 0 Configuration for ECAN1 Transmission (see Example 21-6)
  - DMA Channel 1 Configuration for ECAN1 Reception (see Example 21-7)
  - Code Example for Configuring ECAN™ Bit Timing Parameters (see Example 21-9)
- Updated 21.8 "DMA Controller Configuration"
- All register maps were updated (ECAN1 was changed to ECAN and the File Names were updated) (see Table 21-4 through Table 21-6)
- Table 21-8, Table 21-9, and Table 21-10 were removed
- Additional minor corrections such as language and formatting updates were incorporated throughout the document

#### Note the following details of the code protection feature on Microchip devices:

- Microchip products meet the specification contained in their particular Microchip Data Sheet.
- Microchip believes that its family of products is one of the most secure families of its kind on the market today, when used in the intended manner and under normal conditions.
- There are dishonest and possibly illegal methods used to breach the code protection feature. All of these methods, to our knowledge, require using the Microchip products in a manner outside the operating specifications contained in Microchip's Data Sheets. Most likely, the person doing so is engaged in theft of intellectual property.
- Microchip is willing to work with the customer who is concerned about the integrity of their code.
- Neither Microchip nor any other semiconductor manufacturer can guarantee the security of their code. Code protection does not mean that we are guaranteeing the product as "unbreakable."

Code protection is constantly evolving. We at Microchip are committed to continuously improving the code protection features of our products. Attempts to break Microchip's code protection feature may be a violation of the Digital Millennium Copyright Act. If such acts allow unauthorized access to your software or other copyrighted work, you may have a right to sue for relief under that Act.

Information contained in this publication regarding device applications and the like is provided only for your convenience and may be superseded by updates. It is your responsibility to ensure that your application meets with your specifications. MICROCHIP MAKES NO REPRESENTATIONS OR WARRANTIES OF ANY KIND WHETHER EXPRESS OR IMPLIED, WRITTEN OR ORAL, STATUTORY OR OTHERWISE, RELATED TO THE INFORMATION, INCLUDING BUT NOT LIMITED TO ITS CONDITION, QUALITY, PERFORMANCE, MERCHANTABILITY OR FITNESS FOR PURPOSE. Microchip disclaims all liability arising from this information and its use. Use of Microchip devices in life support and/or safety applications is entirely at the buyer's risk, and the buyer agrees to defend, indemnify and hold harmless Microchip from any and all damages, claims, suits, or expenses resulting from such use. No licenses are conveyed, implicitly or otherwise, under any Microchip intellectual property rights.

#### **Trademarks**

The Microchip name and logo, the Microchip logo, dsPIC, Keeloq, Keeloq logo, MPLAB, PIC, PICmicro, PICSTART, PIC<sup>32</sup> logo, rfPIC and UNI/O are registered trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

FilterLab, Hampshire, HI-TECH C, Linear Active Thermistor, MXDEV, MXLAB, SEEVAL and The Embedded Control Solutions Company are registered trademarks of Microchip Technology Incorporated in the U.S.A.

Analog-for-the-Digital Age, Application Maestro, chipKIT, chipKIT logo, CodeGuard, dsPICDEM, dsPICDEM.net, dsPICworks, dsSPEAK, ECAN, ECONOMONITOR, FanSense, HI-TIDE, In-Circuit Serial Programming, ICSP, Mindi, MiWi, MPASM, MPLAB Certified logo, MPLIB, MPLINK, mTouch, Omniscient Code Generation, PICC, PICC-18, PICDEM, PICDEM.net, PICkit, PICtail, REAL ICE, rfLAB, Select Mode, Total Endurance, TSHARC, UniWinDriver, WiperLock and ZENA are trademarks of Microchip Technology Incorporated in the U.S.A. and other countries.

SQTP is a service mark of Microchip Technology Incorporated in the U.S.A.

All other trademarks mentioned herein are property of their respective companies.

© 2008-2011, Microchip Technology Incorporated, Printed in the U.S.A., All Rights Reserved.

Printed on recycled paper.

ISBN: 978-1-61341-893-2

Microchip received ISO/TS-16949:2009 certification for its worldwide headquarters, design and wafer fabrication facilities in Chandler and Tempe, Arizona; Gresham, Oregon and design centers in California and India. The Company's quality system processes and procedures are for its PIC® MCUs and dsPIC® DSCs, KEELOQ® code hopping devices, Serial EEPROMs, microperipherals, nonvolatile memory and analog products. In addition, Microchip's quality system for the design and manufacture of development systems is ISO 9001:2000 certified.

# QUALITY MANAGEMENT SYSTEM CERTIFIED BY DNV ISO/TS 16949:2009



## Worldwide Sales and Service

#### **AMERICAS**

Corporate Office 2355 West Chandler Blvd.

Chandler, AZ 85224-6199 Tel: 480-792-7200 Fax: 480-792-7277

Technical Support: http://www.microchip.com/

support Web Address:

www.microchip.com

Atlanta Duluth, GA

Tel: 678-957-9614 Fax: 678-957-1455

**Boston** 

Westborough, MA Tel: 774-760-0087 Fax: 774-760-0088

Chicago Itasca, IL

Tel: 630-285-0071 Fax: 630-285-0075

Cleveland

Independence, OH Tel: 216-447-0464 Fax: 216-447-0643

**Dallas** 

Addison, TX Tel: 972-818-7423 Fax: 972-818-2924

Detroit

Farmington Hills, MI Tel: 248-538-2250 Fax: 248-538-2260

Indianapolis Noblesville, IN Tel: 317-773-8323

Fax: 317-773-5453
Los Angeles

Mission Viejo, CA Tel: 949-462-9523 Fax: 949-462-9608

**Santa Clara** Santa Clara, CA Tel: 408-961-6444 Fax: 408-961-6445

Toronto

Mississauga, Ontario,

Canada

Tel: 905-673-0699 Fax: 905-673-6509

#### ASIA/PACIFIC

**Asia Pacific Office** 

Suites 3707-14, 37th Floor Tower 6, The Gateway Harbour City, Kowloon Hong Kong

Tel: 852-2401-1200 Fax: 852-2401-3431

**Australia - Sydney** Tel: 61-2-9868-6733 Fax: 61-2-9868-6755

**China - Beijing** Tel: 86-10-8569-7000 Fax: 86-10-8528-2104

**China - Chengdu** Tel: 86-28-8665-5511 Fax: 86-28-8665-7889

**China - Chongqing** Tel: 86-23-8980-9588 Fax: 86-23-8980-9500

**China - Hangzhou** Tel: 86-571-2819-3187 Fax: 86-571-2819-3189

China - Hong Kong SAR Tel: 852-2401-1200 Fax: 852-2401-3431

**China - Nanjing** Tel: 86-25-8473-2460 Fax: 86-25-8473-2470

**China - Qingdao** Tel: 86-532-8502-7355 Fax: 86-532-8502-7205

**China - Shanghai** Tel: 86-21-5407-5533 Fax: 86-21-5407-5066

**China - Shenyang** Tel: 86-24-2334-2829 Fax: 86-24-2334-2393

**China - Shenzhen** Tel: 86-755-8203-2660 Fax: 86-755-8203-1760

**China - Wuhan** Tel: 86-27-5980-5300 Fax: 86-27-5980-5118

**China - Xian** Tel: 86-29-8833-7252 Fax: 86-29-8833-7256

**China - Xiamen**Tel: 86-592-2388138
Fax: 86-592-2388130 **China - Zhuhai** 

Tel: 86-756-3210040 Fax: 86-756-3210049

#### ASIA/PACIFIC

India - Bangalore Tel: 91-80-3090-4444 Fax: 91-80-3090-4123

India - New Delhi Tel: 91-11-4160-8631 Fax: 91-11-4160-8632

India - Pune Tel: 91-20-2566-1512 Fax: 91-20-2566-1513

**Japan - Osaka** Tel: 81-66-152-7160 Fax: 81-66-152-9310

**Japan - Yokohama** Tel: 81-45-471- 6166 Fax: 81-45-471-6122

Korea - Daegu

Tel: 82-53-744-4301 Fax: 82-53-744-4302 **Korea - Seoul** 

Tel: 82-2-554-7200 Fax: 82-2-558-5932 or 82-2-558-5934

Malaysia - Kuala Lumpur Tel: 60-3-6201-9857

Fax: 60-3-6201-9859 **Malaysia - Penang** Tel: 60-4-227-8870 Fax: 60-4-227-4068

**Philippines - Manila** Tel: 63-2-634-9065 Fax: 63-2-634-9069

**Singapore** Tel: 65-6334-8870 Fax: 65-6334-8850

**Taiwan - Hsin Chu** Tel: 886-3-5778-366 Fax: 886-3-5770-955

**Taiwan - Kaohsiung** Tel: 886-7-536-4818 Fax: 886-7-330-9305

**Taiwan - Taipei** Tel: 886-2-2500-6610 Fax: 886-2-2508-0102

**Thailand - Bangkok** Tel: 66-2-694-1351 Fax: 66-2-694-1350

#### **EUROPE**

Austria - Wels

Tel: 43-7242-2244-39 Fax: 43-7242-2244-393

**Denmark - Copenhagen** Tel: 45-4450-2828

Fax: 45-4450-2828

France - Paris Tel: 33-1-69-53-63-20 Fax: 33-1-69-30-90-79

**Germany - Munich** Tel: 49-89-627-144-0 Fax: 49-89-627-144-44

**Italy - Milan** Tel: 39-0331-742611 Fax: 39-0331-466781

**Netherlands - Drunen** Tel: 31-416-690399 Fax: 31-416-690340

**Spain - Madrid** Tel: 34-91-708-08-90 Fax: 34-91-708-08-91

**UK - Wokingham** Tel: 44-118-921-5869 Fax: 44-118-921-5820

11/29/11