
NMRA Technical Note			
Layout Command Control [®] (LCC)			
Event Identifiers			
Feb 17, 2015	9.7.0.4-TN		

Adopted as a NMRA Technical Note

The OpenLCB Standard document appended to this cover sheet has been formally adopted as a NMRA Standard by the NMRA Board of Directors on the date shown in the *Adopted* column in the *Version History* table below.

5 Version History

Date	Adopted	Summary of Changes
Feb 17, 2015		Initial version



OpenLCB Technical Note		
Event Identifiers		
Feb 15, 2015	Adopted	

1 Introduction

This technical note contains informative discussion and background for the corresponding "OpenLCB Event Identifiers Standard". This explanation is not normative in any way.

2 Annotations to the Standard

5 This section provides background information on corresponding sections of the Standard document. It's expected that two documents will be read together.

2.1 Introduction

Although event identifiers generally take the format of a unique Node ID plus a 16-bit extension, there are some exceptions to this noted in the Event Identifiers Standard which will be detailed in this document.

2.2 Intended Use

10

15

20

An Event Identifier is intended to be globally unique and for a specific purpose defined either by user configuration or enforced by the Event Identifiers Standard. Any node may be configured to produce or consume any event, regardless of its assigned Node ID. However, logically, a unique event identifier is defined to have a unique purpose, whether assigned by user configuration or explicitly defined in the Event Identifier Standard.

The "globally unique" requirement only refers to the universe of connected nodes; nodes that never need to communicate with each other don't need to have separate Event Identifiers. In general, however, nodes can move: they can be sold or loaned for use on another layout, nodes on modular layouts can be connected to other arbitrary modules, and few assumptions can be made. Therefore, we require globally uniqueness for all Event Identifiers.

To ensure uniqueness, the top six bytes of an Event Identifier that you define are <u>required</u> to be within a Node ID space that you control. The low two bytes would be any number you prefer, so long as you use each value for only one event.

This requirement applies equally to events defined by a hardware node, like a push button, a software node in a computer, or Event Identifiers that are defined by a human writing them on a piece of paper. In each case, the thing doing the definition must ensure it has control over the Node ID corresponding to the top six bytes, so it can ensure that the Event Identifier not be reused.

Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
Node ID assigned to you					Unique exter	e 16 bit nsion	

30

50

55

The Node ID part could be from real nodes that you own. For example, the Blue/Gold algorithm for assigning Event Identifiers automatically puts the Node ID of the first node to use that event in the Event Identifier, guaranteeing it to be unique.

Not all Event Identifiers need to be assigned through the Blue/Gold algorithm. For example, a software configuration tool might define events and assign Event Identifiers to them. A board manufacturer may 35 prefer some other pushbutton configuration process. A modular club may decide that certain events form the "boundaries" of modules, and need to be assigned well-known Event Identifiers to make it easier to create large modular layouts. Whatever the method, the Event Identifiers need to be globally unique, and we ensure that by requiring Event Identifiers to be created using Node ID numbers 40 assigned to them (and therefore not assigned to anybody else), plus an additional 16 bits that they are responsible for using only once. This is worth repeating, each Event Identifier can only be used once for a specific state or meaning. It doesn't mean that multiple nodes cannot use it, but rather it should not be used for a different purpose or meaning. This is because the meaning and its use is shared across all of the nodes using it, and unless it can be guaranteed that they all have been changed there will be conflict between them. It is much safer to use a new Event Identifier, and nodes will usually have a 45 mechanism to supply new, "virgin" Event Ids.

Note that the Node ID part of an Event Identifier does not have to correspond to any physical node. So long as you have some Node ID address space assigned to you, you can use that. For example, a fast-clock manufacturer might want to define a range of Event Identifiers so that a different event is emitted every fast minute. For the sake of argument, let's say 24 bits worth of specific events are needed (it's actually smaller, but let's use this as an example). The manufacturer has a large range of Node IDs assigned already, so can use 8-bits worth of that space, plus the extra 16 bits in the Event Identifiers below the Node ID-like-part, to do this. For example, if a manufacturer had a range of Node IDs that included at least 0x123456789A00 through 0x123456789AFF (in other words, all possible values of the low byte), he could create a set of Event Identifiers with the low 24 bits used to carry a time value:

Byte 1 Byte 2 Byte 4 Byte 5 Byte 6 Byte 7 Byte 8 Byte 3 Unique 16 bit Assigned Node ID extension 0x56 0x9ATime Value 0x120x340x78

Table 2: Example of defining a Set of Events

This is guaranteed to be unique, no matter where one of these devices is taken, because the node ID range is guaranteed to belong to the manufacturer, and he'll use it only once.

60 2.3 References and Context

This Standard is in the context of the following OpenLCB Standards:

• The Message Network Standard, which defines the basic messages and how they interact. Higher-level protocols are based on this message network, but are defined elsewhere.

- The Event Transport Standard, which defines the protocol for transporting events.
- 65 The Unique Identifiers Standard which defines the format and allocation of unique 48-bit identifiers.

2.4 Format

Event Identifiers are intended to be globally unique 64-bit values.

2.5 Allocation

2.5.1 Node ID Based

The majority of event identifiers fall into this category. The six most significant bytes are derived from a globally unique six byte Node ID followed by the two least significant bytes which are typically chosen through user configuration.

2.5.1.1 MERG CBUS

OpenLCB allocates a Node ID address space specifically for mapping MERG CBUS events into
OpenLCB. CBUS events come in two types: long and short. A long event is uniquely identified by
the coEvent ID. A CBUS short event is translated into an OpenLCB event by using 0x0000 as the
Node ID in the "CBUS Node ID" field of the OpenLCB event identifier. This is allowed because in the
CBUS standard as combination of 16-bit node-id + 16-bit event-id. A short event is only identified by
its 16-bit event-id. A CBUS short event is translated into an OpenLCB Event by using 0x0000 as the
Node ID in the "CBUS Node ID" field of the OpenLCB event identifier. This is allowed because in the
CBUS standard, node-id 0x0000 is not permitted.

CBUS events can also come in the form of a request. These requests should be translated into an Identify Producer on OpenLCB in order to solicit the response that the CBUS request is asking for. Two Identify Producer messages will have to be sent, one for the ON state range and another for an OFF state range, the response of which will need to be translated back for CBUS.

2.5.2 Well-Known Automatically-Routed

Unlike Node ID Based event identifiers, the Well-Known Automatically Routed event identifiers are explicitly defined by the Event Identifiers Standard for a specific purpose. Additionally, gateways are required to route these events to all segments.

Note that it is not specified whether or not the well-known automatically routed events shall participate in producer/consumer identify. The primary purpose of the producer/consumer identify is to pair consumers with produces, especially for the purpose of routing between OpenLCB segments. Since these well-known automatically-routed events must always be routed, it could be argued that the identify events are redundant for these well-known Event Identifiers.

95 **2.5.2.1 Emergency Off**

The Emergency Off event identifier (01.00.00.00.00.00.FF.FF) is a request for a node to de-energize all of its outputs. A node receiving this event may continue to remain a powered participant of the OpenLCB bus, but shall de-energize any outputs unrelated to maintaining OpenLCB communications.

100 For example:

85

- If the node is a DCC power booster, it must disable its amplified DCC power output.
- If the node is an accessory controlling turnout motors, it must remove power from the motors

A node may revert to its previous energized state following the reception of a Clear Emergency Off event (01.00.00.00.00.00.FF.FE).

A node that has recently joined the OpenLCB network is not expected to know about or react in any specifically prescribed way to the current Emergency Off status defined prior to the node joining the network until the next Emergency Off or Clear Emergency Off event is produced.

2.5.2.2 Emergency Stop

- The Emergency Stop event identifier (01.00.00.00.00.00.FF.FD) is a request for a node to command all of its outputs to a safe state. A node receiving this event is not required to de-energize any of its outputs. A "safe state" is defined by the node. For example:
 - If the node is acting on behalf of one or more DCC trains, it may send the global emergency stop command onto the DCC signal bus.
- If the node is an accessory controlling turnout motors, it may do nothing, route its outputs to a manufacture default state, route its outputs to a user defined state, or something else altogether.

A node may revert to its previous non-Emergency Stop state following the reception of a Clear Emergency Stop event (01.00.00.00.00.00.FF.FC). A node that has recently joined the OpenLCB network is not expected to know about or react in any specifically prescribed way to the current Emergency Stop status defined prior to the node joining the network until the next Emergency Stop or Clear Emergency Stop event is produced.

2.5.3 Well-Known

120

Unlike Node ID Based Event Identifiers, the Well-Known Event Identifiers are explicitly defined by the Event Identifiers Standard for a specific purpose. Gateways are not required to actively route these events to all segments, and may maintain a static or learned routing table for these events to prevent unnecessary propagation.

Table of Contents

Introduction	1
Annotations to the Standard	1
2.1 Introduction	
2.2 Intended Use	1
2.3 References and Context.	2
2.4 Format	3
2.5 Allocation	3
2.5.1 Node ID Based	3
2.5.1.1 MERG CBUS	3
2.5.2 Well-Known Automatically-Routed	3
2.5.2.1 Emergency Off	3
2.5.2.2 Emergency Stop	
2.3.2.2 Emergency stop	4
2.5.3 Well-Known	4