

# Normal Operation -- HE-302 Shell and Tube Heat Exchanger

Document ID: SOP-HE-302-04

Issued: 2023-09-01 | Last reviewed: 2025-09-01 | Next review due: 2027-09-01

Applicable equipment: HE-302

Authority Level: 4 (Site Operating Procedure)

---

## 1. Purpose

This procedure defines normal operating parameters and monitoring requirements for HE-302 Shell and Tube Heat Exchanger.

## 2. Operating Parameters

|                                 |                                            |
|---------------------------------|--------------------------------------------|
| Maximum operating pressure      | 18.5 bar (per OEM bulletin MHT-PB-2022-07) |
| Normal operating pressure range | 12 - 16 bar                                |
| Maximum operating temperature   | 180 degC                                   |

## 3. Monitoring

Operators shall log pressure and temperature readings each shift. Any reading exceeding the maximum operating pressure shall be reported immediately to the Shift Lead.

## 4. Note on Pending Revision

OEM bulletin MHT-PB-2026-11 (issued 2026-06-01) has revised the maximum operating pressure for this equipment class to 16.2 bar. This procedure is pending update via Management of Change; the 18.5 bar figure above reflects the version currently on file.