

Overview

This section discusses the following topics:

- Scope
- Receiving and Inspecting the Equipment
- Installation Process
- Safety Information
- Obtaining Technical Assistance
- Specifications

Scope

This guide is for properly trained service personnel and technicians who need to install Arista Networks Data Center Switches.

DCS-7050QX-32S	DCS-7050TX-48	DCS-7050QX2-32S
DCS-7050TX-64	DCS-7050SX-64	DCS-7050TX-72
DCS-7050SX-72	DCS-7050TX-72Q	DCS-7050SX-72Q
DCS-7050TX-96	DCS-7050SX2-72Q	DCS-7050SX-96
DCS-7050CX3-32S	DCS-7050SX3-48YC12	DCS-7050SX3-48YC8
DCS-7050CX3M-32S	DCS-7050TX3-48C8	DCS-7050SX3-48C8
DCS-7050SX3-24YC4C-S	DCS-7050SX3-48YC8C	

Important:

Only qualified personnel should install, service, or replace this equipment.

Seul le personnel qualifié doit installer, service, ou remplacer cet équipement.

Receiving and Inspecting the Equipment

Upon receiving the switch, inspect the shipping boxes and record any external damage. Retain packing materials if you suspect that part of the shipment is damaged; the carrier may need to inspect them.

If the boxes were not damaged in transit, unpack them carefully. Ensure you do not discard any accessories packaged in the same box as the main unit.

Inspect the packing list and confirm that you received all listed items. Compare the packing list with your purchase order. The Parts List (/qsg-7050-series-1ru-gen3/7050-series-1ru-gen3-parts-list) provides a list of components included with the switch.

Installation Process

The following tasks are required to install and use the switch.

1. Select and prepare the installation site (Site Selection (/qsg-7050-series-1ru-gen3/7050-series-1ru-gen3-preparation#xx1011685)).
2. Assemble the installation tools listed (Tools and Parts Required for Installation (/qsg-7050-series-1ru-gen3/7050-series-1ru-gen3-preparation#xx1011725)).
3. Attach the mounting brackets and install the switch in an equipment rack (Rack Mounting the Switch (/qsg-7050-series-1ru-gen3/7050-series-1ru-gen3-rack-mounting-the-switch)).

4. Connect the switch to the power source and network devices (Cabling the Switch (/qsg-7050-series-1ru-gen3/7050-series-1ru-gen3-cabling-the-switch)).
5. Configure the switch (Configuring the Switch (/qsg-7050-series-1ru-gen3/7050-series-1ru-gen3-configuring-the-switch)).

Important:

Class 1 Laser Product: This product has provisions for installing Class 1 laser transceivers, which provide optical coupling to the communication network. After a Class 1 laser product is installed, the equipment is a Class 1 Laser Product (Appareil à Laser de Classe 1). The customer is responsible for selecting and installing the Class 1 laser transceiver and for ensuring that the Class 1 AEL (Allowable Emission Limit) per EN/IEC 60825, CSA E60825-1, and Code of Federal Regulations 21 CFR 1040 is not exceeded after the laser transceiver have been installed. Do not install laser products whose class rating is greater than 1. Refer to all safety instructions that accompany the transceiver before installation. Only Class 1 laser devices, certified for use in the country of installation by the cognizant agency, are to be utilized in this product.

Produit laser de classe 1: Ce produit est prévu pour l'installation d'émetteurs-récepteurs laser de classe 1, qui assurent un couplage optique au réseau de communication. Une fois qu'un produit laser de classe 1 est installé, l'équipement est un produit laser de classe 1 (Appareil à Laser de Classe 1). Le client est responsable de la sélection et de l'installation de l'émetteur-récepteur laser de classe 1 et de s'assurer que la classe 1 AEL (limite d'émission admissible) selon EN/IEC 60825,

CSA E60825-1 et Code of Federal Regulators 21 CFR 1040 n'est pas dépassée après l'installation de l'émetteur-récepteur laser de classe 1. un émetteur-récepteur laser a été installé. N'installez pas de produits laser dont la classe est supérieure à 1. Reportez-vous à toutes les instructions de sécurité qui accompagnent l'émetteur-récepteur avant l'installation. Seuls les appareils laser de classe 1, certifiés pour une utilisation dans le pays d'installation par l'agence compétente, doivent être utilisés dans ce produit.

Important:

The ultimate disposal of this product should be handled by abiding by all national laws and regulations.

L'élimination finale de ce produit doit être effectuée dans le respect de toutes les lois et réglementations nationales.

Safety Information

Refer to the Arista Networks document *Safety Information and Translated Safety Warnings* at

<http://www.arista.com/assets/data/pdf/AristaBSMIRoHS.pdf>

(<http://www.arista.com/assets/data/pdf/AristaBSMIRoHS.pdf>).

Obtaining Technical Assistance

Any customer, partner, reseller, or distributor holding a valid Arista Service Contract can obtain technical support in the following ways.

- **Email:** support@arista.com (mailto:support@arista.com).

This is the easiest way to create a new service request.

Include a detailed description of the problem and the “show tech-support” output.

- **Web:** [https://www.arista.com/en/support \(/en/support\)](https://www.arista.com/en/support (/en/support)).

You can create a support case through the support portal on our website. You may also download the most current software and documentation and view FAQs, Knowledge Base articles, Security Advisories, and Field Notices.

- **Phone:** +1 866-476-0000 or +1 408-547-5502

Important:

There are no user-serviceable parts inside. Refer all servicing to qualified service personnel.

Il n'y a aucune pièce réparable par l'utilisateur à l'intérieur. Confiez tout entretien à un personnel de service qualifié.

Specifications

This guide covers a list of specifications of Arista Data Center modular switches and components.

Table 1. Switch Specifications (Dimensions and Weights)

Switch	Size (W x H x D)	Weight
DCS-7050QX-32S	48.3 x 4.4 x 40.6 cm (19 x 1.75 x 16 inches)	9.1 kg (20.1 lbs.)
DCS-7050TX-48	48.3 x 4.4 x 40.6 cm (19 x 1.75 x 16 inches)	7.7 kg (17.0 lbs.)
DCS-7050QX2-32S	48.3 x 4.4 x 40.6 cm (19 x 1.75 x 16 inches)	9.1 kg (20.1 lbs.)
DCS-7050TX-64	48.3 x 4.4 x 40.6 cm (19 x 1.75 x 16 inches)	8.6 kg (19.0 lbs.)
DCS-7050SX-64	48.3 x 4.4 x 40.6 cm (19 x 1.75 x 16 inches)	8.6 kg (19.0 lbs.)

Switch	Size (W x H x D)	Weight
DCS-7050TX-72	48.3 x 4.4 x 40.6 cm (19 x 1.75 x 20.6 inches)	10.0 kg (22.0 lbs.)
DCS-7050SX-72	48.3 x 4.4 x 40.6 cm (19 x 1.75 x 16 inches)	8.6 kg (19.0 lbs.)
DCS-7050TX-72Q	48.3 x 4.4 x 40.6 cm (19 x 1.75 x 20.6 inches)	10.2 kg (22.5 lbs.)
DCS-7050SX-72Q	48.3 x 4.4 x 40.6 cm (19 x 1.75 x 16 inches)	7.8 kg (17.2 lbs.)
DCS-7050TX-96	48.3 x 4.4 x 40.6 cm (19 x 1.75 x 20.6 inches)	10.5 kg (23.1 lbs.)
DCS-7050SX2-72Q	48.3 x 4.4 x 40.6 cm (19 x 1.75 x 16 inches)	10.1 kg (22.3 lbs.)
DCS-7050SX-96	48.3 x 4.4 x 40.6 cm (19 x 1.75 x 16 inches)	9.1 kg (20.1 lbs.)
DCS-7050CX3-32S	48.3 x 4.4 x 40.6 cm (19 x 1.75 x 16 inches)	8.8 kg (19.4 lbs.)

Switch	Size (W x H x D)	Weight
DCS-7050SX3-48YC12	48.3 x 4.4 x 44.4 cm (19 x 1.75 x 17.5 inches)	9.2 kg (20.3 lbs.)
DCS-7050SX3-48YC8	48.3 x 4.4 x 46.8 cm (19 x 1.75 x 18.43 inches) ⁽¹⁾	9.5 kg (21.0 lbs.)
DCS-7050CX3M-32S	48.3 x 4.4 x 55.9 cm (19 x 1.75 x 22.0 inches)	12.0 kg (26.5 lbs.)
DCS-7050TX3-48C8	48.3 x 4.4 x 46.7 cm (19 x 1.75 x 18.4 inches)	9.4 kg (20.6 lbs.)
DCS-7050SX3-48C8	48.3 x 4.4 x 46.8 cm (19 x 1.75 x 18.4 inches) ⁽¹⁾	9.4 kg (20.6 lbs.)
DCS-7050SX3-24YC4C-S	48.3 x 4.4 x 46.8 cm (19 x 1.75 x 18.4 inches) ⁽¹⁾	9.3 kg (21 lbs.)
DCS-7050SX3-48YC8C	48.3 x 4.4 x 46.8 cm (19 x 1.75 x 18.4 inches)	9.3 kg (21 lbs.)

(1): Depth 50.5 cm (19.9 inches) with PSU and fans.

Table 2. Switch Specifications (Operational and Storage)

Switch	Operating Temperature	Storage Temperature	Operating Altitude	Relative Humidity
All	0° to 40°C (32° to 104°F)	-25° to 70°C (-13° to 158°F)	0 to 3,000 meters (0 to 10,000 feet)	5 to 90% (non-condensing)

Table 3. Switch Specifications (Power Input)

Power Source	PSU Models	Ratings
Power Input (AC Power)	PWR-500AC	100 - 240 VAC, 6.5 to 3.0 A, 50/60 Hz
Power Input (DC Power)	PWR-500-DC	-48 to -60 VDC, 15 A
Power Input (AC Power)	PWR-511-AC	100 - 127 / 200 - 240 VAC, 7.1 / 3.4 A, 50/60 Hz
Power Input (DC Power)	PWR-511-DC	-48 to -60 VDC, 13 A
Power Input (AC Power)	PWR-1011-AC-RED	100 - 120 / 200 - 240 VAC, 12 / 6 A, 50/60 Hz
Power Input (DC Power)	PWR-1011-DC-RED	-48 to -60 VDC, 30 A

Note: All switches do not support all PSU models. Some switches described in this guide could use power supplies that may no longer be available. Contact your local Arista representative for more information.

Table 4. Switch Specifications (Power Draw)

Switch	Power Draw (Typical / Maximum)	Supported Power Supply
DCS-7050QX-32S	150 W / 300 W	PWR-500AC PWR-500-DC
DCS-7050TX-48	305 W / 367 W	PWR-500AC PWR-500-DC
DCS-7050QX2-32S	129 W / 283 W	PWR-500AC PWR-500-DC
DCS-7050TX-64	315 W / 387 W	PWR-500AC PWR-500-DC
DCS-7050SX-64	140 W / 220 W	PWR-500AC PWR-500-DC

Switch	Power Draw (Typical / Maximum)	Supported Power Supply
DCS-7050TX-72	349 W / 440 W	PWR-500AC PWR-500-DC
DCS-7050SX-72	144 W / 276 W	PWR-500AC PWR-500-DC
DCS-7050TX-72Q	340 W / 430 W	PWR-500AC PWR-500-DC
DCS-7050SX-72Q	144 W / 261 W	PWR-500AC PWR-500-DC
DCS-7050TX-96	355 W / 455 W	PWR-500AC PWR-500-DC
DCS-7050SX2-72Q	127 W / 251 W	PWR-500AC PWR-500-DC
DCS-7050SX-96	159 W / 290 W	PWR-500AC PWR-500-DC
DCS-7050CX3-32S	206 W / 314 W	PWR-500AC PWR-500-DC

Switch	Power Draw (Typical / Maximum)	Supported Power Supply
DCS-7050SX3-48YC12	170 W / 325 W	PWR-500AC PWR-500-DC
DCS-7050SX3-48YC8	165 W / 345 W	PWR-511-AC PWR-511-DC
DCS-7050CX3M-32S	398 W / 751 W	PWR-1011-AC-RED PWR-1011-DC-RED
DCS-7050TX3-48C8	212 W / 346 W	PWR-511-AC PWR-511-DC
DCS-7050SX3-48C8	133 W / 313 W	PWR-511-AC PWR-511-DC
DCS-7050SX3-24YC4C-S	122 W / 178 W	PWR-511-AC PWR-511-DC
DCS-7050SX3-48YC8C	119 W / 290 W	PWR-511-AC PWR-511-DC