Project: Worked examples
Title: Accumulator sizing (gas law)
Status: DRAFT Author: TempestOS (2026-10-23) Checker: — (—) Issued: —

1. Scope and method

The pre-charge gas volume V0 of a hydraulic accumulator that delivers, or absorbs, a liquid volume ΔV between the lowest working pressure p1 and the highest p2, from $p \cdot V^n$ = const with absolute pressures and an exponent n between 1 (isothermal) and 1.4 (adiabatic), the gas either charged as fast as it is discharged or (a held accumulator, the default for an emergency stroke) charged slowly and isothermally to p2 and then discharged at n; the volume scaled to the lowest operating temperature (T_max/T_min) and the pre-charge pressure at the charging temperature; the next size from your own size list; and the bar·litre product PS·V of the vessel's own maximum allowable pressure and volume against the PSSR Schedule 1 250 bar·L exception. Three modes: energy storage, shock and pulsation (screening only) and emergency stroke (ΔV is the stroke volume, linkable from the cylinder circuit). Not a pressure-vessel code check. Absolute pressures: p_a = p_gauge + p_atm (or as entered, in Absolute mode) Gas volume, one exponent both ways (charged as fast as it is discharged): V0 = ΔV / [(p0/p1)^(1/n) − (p0/p2)^(1/n)], n = 1 isothermal … 1.4 adiabatic Gas volume, slow charge and discharge at n (a held accumulator): charged isothermally to p2, V2 = V0·p0/p2, then discharged at n to p1, V1 = V2·(p2/p1)^(1/n), ΔV = V1 − V2, so V0 = ΔV·(p2/p0) / [(p2/p1)^(1/n) − 1] Either volume × the real-gas factor f_rg (user input, at least 1) and × (T_max + 273.15)/(T_min + 273.15), because p0 is defined at T_max and the gas delivers less when cold Pre-charge rules (records, applied to absolute pressures): p0 ≤ r_0·p1 at T_max (default 0.9, bladder type) and p2/p0(T_min) ≤ r_p (default 4), p0(T_min) = p0·(T_min + 273.15)/(T_max + 273.15) Pre-charge at the charging temperature: p0(T_c) = p0(T_max)·(T_c + 273.15)/(T_max + 273.15) Next size: the smallest listed size not below V0 Bar·litres: PS·V, PS = the vessel's maximum allowable pressure (bar gauge, entered, not below p2 gauge), V = the vessel volume entered (default the selected size); compared with 250 bar·L (PSSR Schedule 1, indication only; not available without PS and a volume)

Ref: Pressure Systems Safety Regulations 2000 (SI 2000/128) Schedule 1 — 250 bar·litre exception, indication only
Ref: Pressure Equipment Directive 2014/68/EU and UK PER 2016 — Pressure equipment; not checked here
Ref: Esposito, Fluid Power with Applications Ch. on accumulators — Gas-charged accumulator sizing, $p \cdot V^n$ = const

2. Inputs

SYMBOL	DESCRIPTION	VALUE	UNIT	SOURCE	VALID RANGE
mode	Duty	Energy storage		assumption: Slow clamp-and-hold cycle: stored-energy duty.	any
dV	Liquid volume ΔV delivered, absorbed or (emergency stroke) needed for the stroke	14	L	spec: Hydraulic specification HS-12: clamp stroke plus leakage make-up, 14 L per cycle	0.001 … 1000 L
process	Gas process (By duty: an emergency stroke is charged slowly to p2 and discharged at n, the other duties use one exponent both ways)	By duty		default	any

SYMBOL	DESCRIPTION	VALUE	UNIT	SOURCE	VALID RANGE
p_basis	Pressures entered as	Absolute		assumption: Pressures entered as absolute bar, as the source numbers are quoted.	any
p_0	Gas pre-charge pressure p0, at the maximum operating temperature	90	bar a	spec: Hydraulic specification HS-12: pre-charge 90 bar at the maximum oil temperature	0 ... 700 bar a
p_1	Lowest working pressure p1	100	bar a	spec: Hydraulic specification HS-12: lowest clamp pressure 100 bar	0 ... 700 bar a
p_2	Highest working pressure p2	210	bar a	spec: Hydraulic specification HS-12: pump cut-out 210 bar	0 ... 700 bar a
p_atm	Atmospheric pressure (gauge to absolute)	1.01325	bar a	assumption: Standard atmosphere, derived constant.	0.5 ... 1.1 bar a
n	Gas exponent n of the discharge (1 isothermal, slow; 1.4 adiabatic, fast); with the same exponent both ways it is also the charge exponent	1		assumption: Isothermal: the clamp holds for minutes between cycles.	1 ... 1.4
f_rg	Real-gas factor on V0 (1 = ideal gas; at least 1, as nitrogen's compressibility factor exceeds 1 at high pressure; from a gas-property source above 200 bar)	1		assumption: Ideal gas; the highest pressure is just above 200 bar, so the sheet warns.	1 ... 1.5
T_max	Maximum operating temperature (p0 applies here)	50	degC	spec: Hydraulic specification HS-12: oil temperature limit 50 °C	-40 ... 150 degC
T_min	Minimum operating temperature (the gas is coldest and delivers least here; V0 is scaled by T_max/T_min)	30	degC	assumption: Oil temperature range assumed 30 to 50 °C in service (invented for this example); the gas is coldest at 30 °C.	-40 ... 150 degC
T_c	Charging temperature	20	degC	assumption: Charged in the workshop at 20 °C.	-40 ... 100 degC

SYMBOL	DESCRIPTION	VALUE	UNIT	SOURCE	VALID RANGE
r_0	Pre-charge rule: p0 (at T_max) at most this fraction of p1, on absolute pressures (state whether the manufacturer's ratio is on gauge or absolute pressures)	0.9		reference: record: accumulator pre-charge rules (bladder type), to be taken from the manufacturer's guide	0.1 ... 1
r_p	Pre-charge rule: p2/p0 (p0 at T_min) at most this ratio, on absolute pressures	4		reference: record: accumulator pre-charge rules (bladder type), to be taken from the manufacturer's guide	1 ... 20
sizes	Available accumulator sizes (from the manufacturer's range)	4 row(s)		reference: record: illustrative size list invented for this example, to be replaced by the manufacturer's range	any
sizes[1]		V = 10 L			
sizes[2]		V = 20 L			
sizes[3]		V = 32 L			
sizes[4]		V = 50 L			
PS	Vessel maximum allowable pressure PS, bar gauge (nameplate or relief setting; not below p2 gauge; needed for the PSSR indication)	230	bar g	spec: Hydraulic specification HS-12: accumulator relief setting 230 bar gauge (vessel PS; illustrative, to be replaced by the nameplate)	0 ... 1500 bar g

3. Assumptions

A1. All gas-law pressures are absolute. A gauge entry is converted with the atmospheric pressure entered here, so the same numbers read as gauge or as absolute give different volumes. ($p \cdot V^n$ = const on a fixed mass of gas.)
A2. The exponent n is the user's: 1 for a slow discharge with heat exchange (isothermal), towards 1.4 for a fast one (adiabatic). With the same exponent both ways the larger n gives the larger volume for a given ΔV. (Gas-law exponents, closed form.)
A3. The gas process is stated on the sheet. A held accumulator (an emergency stroke, by default) is charged slowly, so isothermally with charge exponent 1 ($V2 = V0 \cdot p0/p2$), and discharged at the exponent n; sizing it with one exponent from the pre-charge to both pressures understates the volume. The one-exponent form (charge exponent = n) is for a gas charged as fast as it is discharged, as in a pulsation or a fast cycle; choose it in the energy-storage duty for that case. The shock and pulsation duty always uses one exponent. (Gas-law sizing of a held accumulator: slow charge, fast discharge.)
A4. The gas is ideal unless a real-gas factor is entered (at least 1: nitrogen's compressibility factor exceeds 1 at high pressure, so the real gas needs more volume, never less); above 200 bar the sheet warns that nitrogen departs from the ideal-gas law and a factor from a gas-property source should be entered.

(Real-gas correction as a user factor.)
A5. The pre-charge p0 is defined at the maximum operating temperature T_max and V0 is sized there; at the lowest operating temperature T_min the same gas delivers only the fraction T_min/T_max (absolute) of ΔV, so V0 is multiplied by T_max/T_min, and the p2/p0 rule is checked with p0 at T_min. The temperature range is the user's; with T_min = T_max the correction is 1. (Manufacturer sizing practice; the gas law at constant mass.)
A6. The pre-charge rules (p0 ≤ 0.9·p1 and p2/p0 ≤ 4 by default) are records for the accumulator type and make and are checked as PASS/FAIL on ABSOLUTE pressures, whichever basis the pressures are entered on; the right values, and whether the manufacturer states the ratio on gauge or absolute pressures, come from the manufacturer (the same numbers read as gauge pressures give a different ratio). (Rules are records, not built-in limits.)
A7. The bar·litre product is PS times V of the vessel itself: PS is the vessel's maximum allowable pressure in bar gauge (the nameplate or relief setting, never below the highest working pressure p2) and V its internal volume (the selected size unless entered). Without PS and a volume the indication is not available. It indicates whether the 250 bar·L exception of PSSR Schedule 1 can apply; it is not a compliance statement, and PED / UK PER, PSSR examination and the vessel's own design code stay with the manufacturer and the competent person. (Regulatory gating: no pressure-vessel code check.)
A8. mode (Duty) is taken as Energy storage. (Slow clamp-and-hold cycle: stored-energy duty.)
A9. p_basis (Pressures entered as) is taken as Absolute. (Pressures entered as absolute bar, as the source numbers are quoted.)
A10. p_atm (Atmospheric pressure (gauge to absolute)) is taken as 1.01325 bar a. (Standard atmosphere, derived constant.)
A11. n (Gas exponent n of the discharge (1 isothermal, slow; 1.4 adiabatic, fast); with the same exponent both ways it is also the charge exponent) is taken as 1. (Isothermal: the clamp holds for minutes between cycles.)
A12. f_rg (Real-gas factor on V0 (1 = ideal gas; at least 1, as nitrogen's compressibility factor exceeds 1 at high pressure; from a gas-property source above 200 bar)) is taken as 1. (Ideal gas; the highest pressure is just above 200 bar, so the sheet warns.)
A13. T_min (Minimum operating temperature (the gas is coldest and delivers least here; V0 is scaled by T_max/T_min)) is taken as 30 degC. (Oil temperature range assumed 30 to 50 °C in service (invented for this example); the gas is coldest at 30 °C.)
A14. T_c (Charging temperature) is taken as 20 degC. (Charged in the workshop at 20 °C.)
A15. Energy storage duty: ΔV is the liquid volume the accumulator delivers between p_2 and p_1 over a cycle; n = 1 for a slow discharge, towards 1.4 for a fast one. (Gas-law sizing for a stored-energy duty.)

4. Working

```
[15] pa_0 = p_0
= 90 bar a
= 90 bar a
```
Pre-charge pressure, absolute
```
[16] pa_1 = p_1
= 100 bar a
= 100 bar a
```
Lowest working pressure, absolute
```
[17] pa_2 = p_2
= 210 bar a
= 210 bar a
```
Highest working pressure, absolute
```
[18] p2_g = max(pa_2 - p_atm, 0 bar)
= max(210 bar a - 1.0132 bar a, 0 bar)
= 208.99 bar g
```
Highest working pressure, gauge

[21] V0_ideal = dV / [(pa_0/pa_1)^(1/n) - (pa_0/pa_2)^(1/n)] — $p \cdot V^n = \text{const}$
= 14 L / [(0.9) - (0.42857)]
= 29.697 L
Gas volume for the displacement, ideal gas
[22] f_T = (T_max / 1 K) / (T_min / 1 K)
= 50 degC / 1 K / (30 degC / 1 K)
= 1.066
Temperature scaling of the gas volume: maximum over minimum absolute temperature
[23] V0 = V0_ideal * f_rg * f_T
= 29.697 L × 1 × 1.066
= 31.656 L
Pre-charge gas volume V0 (accumulator size required)
[24] T_ratio = (T_c / 1 K) / (T_max / 1 K)
= 20 degC / 1 K / (50 degC / 1 K)
= 0.90716
Charging over maximum absolute temperature
[25] p0 = pa_0 * T_ratio
= 90 bar a × 0.90716
= 81.645 bar a
Absolute pre-charge pressure at the charging temperature
[26] p0_min = pa_0 / f_T
= 90 bar a / 1.066
= 84.43 bar a
Absolute pre-charge pressure at the minimum operating temperature
[27] p0_set = p0
= 81.645 bar a
= 81.645 bar a
Pre-charge to set at the charging temperature (absolute)
[28] u_r0 = pa_0 / (r_0 * pa_1)
= 90 bar a / (0.9 × 100 bar a)
= 1
Pre-charge against the p0/p1 rule
[29] u_rp = (pa_2 / p0_min) / r_p
= 210 bar a / 84.43 bar a / 4
= 0.62182
Pressure ratio p2/p0 (p0 at the minimum temperature) against the rule
[30] V_sel = smallest listed size not below V0
= V0 = 31.656 L, 4 sizes listed
= 32 L
Selected accumulator size
[31] u_V = V0 / V_sel
= 31.656 L / 32 L
= 0.98926
Required volume over the selected size
[32] bar_litres = PS * V_sel
= 230 bar g × 32 L
= 7360 bar·L
Pressure-volume product PS·V (PS as entered, V the selected size)
[33] BL_pssr = 250 bar*L — PSSR Schedule 1
= 250 bar·L
PSSR Schedule 1 exception threshold (indication)

5. Results

SYMBOL	VALUE	DESCRIPTION

SYMBOL	VALUE	DESCRIPTION
V0	31.656 L	Accumulator gas volume required
V_sel	32 L	Selected size
u_V	0.98926	Selected size utilisation
p0	81.645 bar a	Pre-charge, absolute, at the charging temperature
p0_set	81.645 bar a	Pre-charge to set at the charging temperature
p0_min	84.43 bar a	Pre-charge, absolute, at the minimum operating temperature
f_T	1.066	Gas volume scaling T_max/T_min
u_r0	1	Pre-charge rule utilisation (p0/p1)
u_rp	0.62182	Pressure ratio utilisation (p2/p0 at the minimum temperature)
bar_litres	7360 bar·L	Pressure-volume product (bar·litres)
pssr	"7360 bar·L is at or above 250 bar·L: the exception does not apply; PSSR and PED / UK PER duties follow."	PSSR Schedule 1 250 bar·L exception (indication only)
process	"charged as fast as it is discharged (one exponent n = 1 from the pre-charge to both working pressures)"	Gas process the volume is sized for

6. Checks (governing first)

RESULT	CHECK	DEMAND	CAPACITY	UTILISATION	REF
PASS	Pre-charge within the p0/p1 rule	u_r0 = 1	u_r0 ≤ 1	1	accumulator.rules record
PASS	Pressure ratio within the p2/p0 rule	u_rp = 0.62182	u_rp ≤ 1	0.622	accumulator.rules record

7. Applicability

WARNING — record: Tabulated values not taken from a reference record: r_0, r_p (Pre-charge rules); sizes (Accumulator size list). Enter each as one so its source, edition and licence travel with it.
WARNING — input.process: process (Gas process (By duty: an emergency stroke is charged slowly to p2 and discharged at n, the other duties use one exponent both ways)) was not entered; the template default 'By duty' is used.
WARNING — realgas: p_2: the highest working pressure is 210 bar absolute, above 200 bar; nitrogen departs from the ideal-gas law there and the volume shown is the ideal-gas value. Enter a real-gas factor f_rg from a gas-property source.

8. Verification

```
Template fp.accumulator@1.3.1 Content hash 227b66437e399138 Engine calc-engine/1.0.0
Known-answer cases passed 10/10 Test run 2026-10-23 12:00 UTC TempestOS 0.26.0
```