

četrta številka



0 1 2 3 4 5 6 7 8 9 A B C D E F 0 1 2 3 4 5 6 7 8 9 A B C D E F

0 2 4 6 8 A C E	40 - prvi dve številki (58) naslova na zaslonu ter naslova prilastkov	1 3 5 7 9 B D F
0 2 4 6 8 A C E	48 (59)	1 3 5 7 9 B D F
0 2 4 6 8 A C E	50 (5A)	1 3 5 7 9 B D F

- tretja številka