Solar ESS Co., Ltd.
53 Moo 2, Nang Lae, Mueang, Chiang Rai 57100, Thailand
Tel. 063 151 6694, 089 632 5829 · LINE: solaress1
www.solaress.org · www.โซลาร์เอสส์.com

Solar ESS product sheet · October 2026

Smart meter

The inverter maker's own meter, at the grid connection

Needed for zero export, battery control and accurate self-consumption figures.

> **The inverter can only control what it can measure.**

What we fit

Meter	The meter specified by the inverter maker, single-phase or three-phase to match the supply
Location	At the grid connection point, after the PEA meter

Why we pick it

- Zero export and export limits depend on it. A meter in the wrong place makes the system export, or hold back solar for no reason.
- Three-phase sites get a three-phase meter, so the inverter sees each phase on its own.
- It gives the monitoring app real consumption figures, not estimates.
- Wiring, direction and phase order are checked at commissioning.

See our zero-export case studies on the Technical page.

For prices and a design for your site, book a consultation at www.solaress.org or LINE: solaress1. All qualifications and certificates will be furnished upon request or upon completion of contract.

SOLAR ESS www.solaress.org