



# KRISHNA ENTERPRISES

## JCB & Hitachi Spare Parts





KRISHNA ENTERPRISES  
JCB & Hitachi Spare Parts

# KRISHNA ENTERPRISES

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	450-10205	
DESCRIPTION:	ANNULUSRING	
KE PART NO:	KE-0001	
APPLICATION:	REARWHEELANNULUSRING	
<b>Details</b>		
PARTNO.:	450-10206	
DESCRIPTION:	PLANETGEAR	
KE PART NO:	KE-0002	
APPLICATION:	REARHUBGEAR	
<b>Details</b>		
PARTNO.:	450-10210	
DESCRIPTION:	SUNGEAR	
KE PART NO:	KE-0003	
APPLICATION:	REARHUBGEAR	
<b>Details</b>		
PARTNO.:	907-50200	
DESCRIPTION:	BEARING	
KE PART NO:	KE-0004	
APPLICATION:	REARHUBPLANETARY	
<b>Details</b>		
PARTNO.:	450-10209	
DESCRIPTION:	AXLESHAFT	
KE PART NO:	KE-0005	
APPLICATION:	REARAXLESHAFT	

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	450-10216	
DESCRIPTION:	CARRIERPLANTARYHUB	
KE PART NO:	KE-0006	
APPLICATION:	REARAXLEHUB	
<b>Details</b>		
PARTNO.:	450-10221	
DESCRIPTION:	C/WSTUD 450/11100	
KE PART NO:	KE-0007	
APPLICATION:	REARWHEELHUB CARRIER	
<b>Details</b>		 <b>Synchroniser Assembly</b>
PARTNO.:	445-03300	
DESCRIPTION:	SYNCRONIZERASSY.	
KE PART NO:	KE-0008	
APPLICATION:	GEARCHANGERASSY	
<b>Details</b>		
PARTNO.:	20-925552	
DESCRIPTION:	CHARGINGPUMP	
KE PART NO:	KE-0009	
APPLICATION:	TRANSMISSIONOILCHARGINGPUMP	
<b>Details</b>		
PARTNO.:	445-03004	
DESCRIPTION:	TRANSFERGEAR445/64401	
KE PART NO:	KE-0010	
APPLICATION:	TRANSMISSIONGEAR	



KRISHNA ENTERPRISES  
JCB & Hitachi Spare Parts

# KRISHNA ENTERPRISES

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	20-900400	
DESCRIPTION:	CHARGINGPUMP	
KE PART NO:	KE-0011	
APPLICATION:	TRANSMISSIONOILCHARGING PUMP	
<b>Details</b>		
PARTNO.:	121-39800	
DESCRIPTION:	KPCSHAFT(123-04862)	
KE PART NO:	KE-0012	
APPLICATION:	SHAFTFORCARRIAGEKINGPOST	
<b>Details</b>		
PARTNO.:	40-302447	
DESCRIPTION:	FRONTHUB	
KE PART NO:	KE-0013	
APPLICATION:	FRONTWHEELHUB	
<b>Details</b>		
PARTNO.:	121-70500	
DESCRIPTION:	KINGPOSTKARRIAGE(126-00526)	
KE PART NO:	KE-0014	
APPLICATION:	KPCCARRIAGE	
<b>Details</b>		
PARTNO.:	458-70037	
DESCRIPTION:	CROWN PINION 13/38	
KE PART NO:	KE-0015	
APPLICATION:	REARAXLE CROWN PINION 11*38	

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	453-00900	
DESCRIPTION:	CROWNPINION	
KE PART NO:	KE-0016	
APPLICATION:	REARAXLE CROWN PINION	
<b>Details</b>		
PARTNO.:	450-27200	
DESCRIPTION:	YOKE FLANGE	
KE PART NO:	KE-0017	
APPLICATION:	REARAXLEHUBFLANGE	
<b>Details</b>		
PARTNO.:	40-301257	
DESCRIPTION:	TIPPING LEVER	
KE PART NO:	KE-0018	
APPLICATION:	BKT.ATTACHMENTLEVER	
<b>Details</b>		
PARTNO.:	445-10703	
DESCRIPTION:	COUPLINGYOKE	
KE PART NO:	KE-0019	
APPLICATION:		
<b>Details</b>		
PARTNO.:	453-04402	
DESCRIPTION:	CARRIERANNULUSFORU.K.	
KE PART NO:	KE-0020	
APPLICATION:	TRANSMISSIONPLATECARRIER	

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	02-200018	
DESCRIPTION:	PULLY	
KE PART NO:	KE-0021	
APPLICATION:	ENGINE	
<b>Details</b>		
PARTNO.:	990-98300	
DESCRIPTION:	STARGEARKIT2X2	
KE PART NO:	KE-0022	
APPLICATION:	TRANSMISSIONGEAR	
<b>Details</b>		
PARTNO.:	40-301916	
DESCRIPTION:	TIPPINGLINK	
KE PART NO:	KE-0023	
APPLICATION:	BKT.LINK	
<b>Details</b>		
PARTNO.:	450-11000	
DESCRIPTION:	STARGEARKIT4X4	
KE PART NO:	KE-0024	
APPLICATION:	TRANSMISSIONGEAR	
<b>Details</b>		
PARTNO.:	914-37400	
DESCRIPTION:	PUMPDRIVESHAFT28MM	
KE PART NO:	KE-0025	
APPLICATION:	PUMPSECTION	

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	120-30003	
DESCRIPTION:	STUBAXLEWITHNUT	
KE PART NO:	KE-0026	
APPLICATION:	FRONTWHEELHUBAXLE	
<b>Details</b>		
PARTNO.:	121-38101	
DESCRIPTION:	PINION GEAR	
KE PART NO:	KE-0027	
APPLICATION:	KPC	
<b>Details</b>		
PARTNO.:	123-00928	
DESCRIPTION:	HYDRO CLAMP BOLT	
KE PART NO:	KE-0028	
APPLICATION:	K.P.CBOLT	
<b>Details</b>		
PARTNO.:	45-905400	
DESCRIPTION:	STEARINGCOUPLING	
KE PART NO:	KE-0029	
APPLICATION:	STEARINGWHEELCOUPLING	
<b>Details</b>		
PARTNO.:	450-10403	
DESCRIPTION:	NUTSIDEDIFFERENTIAL	
KE PART NO:	KE-0030	
APPLICATION:	BRAKEPISTONHOUSINGNUT	

# KRISHNA ENTERPRISES

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	445-07300	
DESCRIPTION:	ADAPTORBLOCKASSY.	
KE PART NO:	KE-0031	
APPLICATION:	SOLENOIDCHECKVALVE	
<b>Details</b>		
PARTNO.:	40-301753	
DESCRIPTION:	CARRIGE KPC	
KE PART NO:	KE-0032	
APPLICATION:	BACKHOECONNECTINGCARRIGE	
<b>Details</b>		
PARTNO.:	03-300830	
DESCRIPTION:	PUMPDRIVESHAFT	
KE PART NO:	KE-0033	
APPLICATION:	HYD.PUMPSHAFT	
<b>Details</b>		
PARTNO.:	128-10726	
DESCRIPTION:	KINGPOST	
KE PART NO:	KE-0034	
APPLICATION:	CARRIAGEKING POST	
<b>Details</b>		
PARTNO.:	829-00548	
DESCRIPTION:	BUSH	
KE PART NO:	KE-0035	
APPLICATION:	FRONTAXLECENTERPINBUSH	

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	809-00090	
DESCRIPTION:	BUSH	
KE PART NO:	KE-0036	
APPLICATION:	K.PCARRIAGE	
<b>Details</b>		
PARTNO.:	40-301633	
DESCRIPTION:	PIVOT PIN	
KE PART NO:	KE-0037	
APPLICATION:	KPC BOOMMAINPIN	
<b>Details</b>		
PARTNO.:	808-00364	
DESCRIPTION:	BRASSBUSH	
KE PART NO:	KE-0038	
APPLICATION:	BOOM MAINPINBUSH	
<b>Details</b>		
PARTNO.:	808-00246	
DESCRIPTION:	BUSH	
KE PART NO:	KE-0039	
APPLICATION:	STEARINGRAMBUSH	
<b>Details</b>	<b>Search</b>	
PARTNO.:	831-10211	
DESCRIPTION:	LINERBEARING	
KE PART NO:	KE-0040	
APPLICATION:	KPCTOP & BOTTOMPINBUSH	

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	808-00214	
DESCRIPTION:	KINGPOSTCARRIAGE BUSH	
KE PART NO:	KE-0041	
APPLICATION:	KINGPOST BUSH	
<b>Details</b>		
PARTNO.:	808-00388	
DESCRIPTION:	BRASSBUSH	
KE PART NO:	KE-0042	
APPLICATION:	SLEWTRUNIONPLATE	
<b>Details</b>		
PARTNO.:	808-00216	
DESCRIPTION:	BUSH	
KE PART NO:	KE-0043	
APPLICATION:	KPCBUSH	
<b>Details</b>		
PARTNO.:	811-50483	
DESCRIPTION:	PIVOT PIN	
KE PART NO:	KE-0044	
APPLICATION:	BOOMRAMEYESIDEPIN	
<b>Details</b>		
PARTNO.:	809-00131	
DESCRIPTION:	BOOMPINEYEPUFFER	
KE PART NO:	KE-0045	
APPLICATION:	BOOM	

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	811-50437	
DESCRIPTION:	PIVOT PIN	
KE PART NO:	KE-0046	
APPLICATION:	DIPPERRAMRODPIN	
<b>Details</b>		
PARTNO.:	550-40899	
DESCRIPTION:	BUSH	
KE PART NO:	KE-0047	
APPLICATION:	DIPPERANDBOOMRODBUSH	
<b>Details</b>		
PARTNO.:	811-50569	
DESCRIPTION:	PIVOT PIN	
KE PART NO:	KE-0048	
APPLICATION:	DIPPERJACKEYESIDEPIN	
<b>Details</b>		
PARTNO.:	550-40898	
DESCRIPTION:	BUSH	
KE PART NO:	KE-0049	
APPLICATION:	DIPPERTUBEYEYEBUSH	
<b>Details</b>		
PARTNO.:	811-50372	
DESCRIPTION:	PIVOT PIN	
KE PART NO:	KE-0050	
APPLICATION:	BOOMDIPPERJOINT PIN	

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	911-12400	
DESCRIPTION:	PIVOT PIN	
KE PART NO:	KE-0051	
APPLICATION:	BUCKETMAINPIN	
<b>Details</b>		
PARTNO.:	811-20061	
DESCRIPTION:	PIVOT PIN (DOUBLE HOLE)	
KE PART NO:	KE-0052	
APPLICATION:	DIPPERSLEEVEPIN	
<b>Details</b>		
PARTNO.:	550-40976	
DESCRIPTION:	PISTON	
KE PART NO:	KE-0053	
APPLICATION:	SLEWCYLINDERPISTON	
<b>Details</b>		
PARTNO.:	811-80001	
DESCRIPTION:	PIVOT PIN	
KE PART NO:	KE-0054	
APPLICATION:	LOADERBUCKETMAINPIN	
<b>Details</b>		
PARTNO.:	120-30001	
DESCRIPTION:	KINGPIN	
KE PART NO:	KE-0055	
APPLICATION:	FRONTWHEELCARRIER PIN	

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	808-00176	
DESCRIPTION:	BRASSBUSH	
KE PART NO:	KE-0056	
APPLICATION:	FRONTAXLEKINGPIN BUSH	
<b>Details</b>		
PARTNO.:	531-03205	
DESCRIPTION:	TOOTHFORGING	
KE PART NO:	KE-0057	
APPLICATION:	BUCKETTOOTH	
<b>Details</b>		
PARTNO.:	819-00133	
DESCRIPTION:	THRUST WASHER4mm	
KE PART NO:	KE-0058	
APPLICATION:	FRONTAXLECENTERPINWASHER	
<b>Details</b>		
PARTNO.:	445-64301	
DESCRIPTION:	38TEETHGEAR	
KE PART NO:	KE-0059	
APPLICATION:	TRANSMISSIONGEAR	
<b>Details</b>		
PARTNO.:	531-03208/09	
DESCRIPTION:	SIDE CUTTER D.F. FORGING	
KE PART NO:	KE-0060	
APPLICATION:	BUCKETSIDE CUTTER	

# KRISHNA ENTERPRISES

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	02-100284	
DESCRIPTION:	TRANS.FILTER	
KE PART NO.:	KE-0061	
APPLICATION:	TRANSMISSIONOIL	
<b>Details</b>		
PARTNO.:	808-00207	
DESCRIPTION:	THRUST WASHER6mm	
KE PART NO.:	KE-0062	
APPLICATION:	KPCTHRUST WASHER	
<b>Details</b>		
PARTNO.:	809-00090A	
DESCRIPTION:	BUSHOVERSIZE	
KE PART NO.:	KE-0063	
APPLICATION:	K.PCARRIAGE	
<b>Details</b>		
PARTNO.:	25-974602	
DESCRIPTION:	VALVERELIEF3300 PSI	
KE PART NO.:	KE-0064	
APPLICATION:	LOADERLIFTBUCKETMAIN	
<b>Details</b>		
PARTNO.:	121-38103	
DESCRIPTION:	BEARINGPLATE	
KE PART NO.:	KE-0065	
APPLICATION:	KPCPLATE	

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	914-83304	
DESCRIPTION:	CROSSHOLDER	
KE PART NO:	KE-0066	
APPLICATION:	4WDSTEERINGAXLE	
<b>Details</b>		
PARTNO.:	32-915801/02	
DESCRIPTION:	AIRFILTERSET	
KE PART NO:	KE-0067	
APPLICATION:	AIRFILTER	
<b>Details</b>		
PARTNO.:	808-00207B	
DESCRIPTION:	THRUST WASHER10mm	
KE PART NO:	KE-0068	
APPLICATION:	KPCTHRUST WASHER	
<b>Details</b>		
PARTNO.:	914-86203	
DESCRIPTION:	CROSSHOLDER	
KE PART NO:	KE-0069	
APPLICATION:	4WDSTEERINGAXLE	
<b>Details</b>		
PARTNO.:	550-41008	
DESCRIPTION:	LIFTRAMSEALKIT	
KE PART NO:	KE-0070	
APPLICATION:	LIFT CYLINDER	

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	550-42112	
DESCRIPTION:	BUCKETRAMSEAL KIT	
KE PART NO:	KE-0071	
APPLICATION:	BUCKET RAM	
<b>Details</b>		
PARTNO.:	914-86403	
DESCRIPTION:	CROSSHOLDER 3D	
KE PART NO:	KE-0072	
APPLICATION:	4WDSTEERINGAXLE	
<b>Details</b>		
PARTNO.:	G-65-0	
DESCRIPTION:	CUTBUSH	
KE PART NO:	KE-0073	
APPLICATION:	BUCKET	
<b>Details</b>		
PARTNO.:	823-10270	
DESCRIPTION:	THRUST WASHER8MM	
KE PART NO:	KE-0074	
APPLICATION:	KINGPOST CARRIAGE	
<b>Details</b>		
PARTNO.:	823-10270A	
DESCRIPTION:	THRUST WASHER10MM	
KE PART NO:	KE-0075	
APPLICATION:	KINGPOST CARRIAGE	



KRISHNA ENTERPRISES  
JCB & Hitachi Spare Parts

# KRISHNA ENTERPRISES

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	550-42098	
DESCRIPTION:	SEAL KIT	
KE PART NO:	KE-0076	
APPLICATION:	DIPPERRAM	
<b>Details</b>		
PARTNO.:	821-00216	
DESCRIPTION:	CIRCLIP	
KE PART NO:	KE-0077	
APPLICATION:	AXLESHAFT	
<b>Details</b>		
PARTNO.:	550-42085	
DESCRIPTION:	SEAL KIT	
KE PART NO:	KE-0078	
APPLICATION:	BOOMRAMCYLINDER	
<b>Details</b>		
PARTNO.:	550-42383	
DESCRIPTION:	SEAL KIT	
KE PART NO:	KE-0079	
APPLICATION:	STEARING RAM	
<b>Details</b>		
PARTNO.:	826-00533	
DESCRIPTION:	WHEELBOLT	
KE PART NO:	KE-0080	
APPLICATION:	FRONTHUB	

## SPARE PARTS OF JCB

<b>Details</b>	
<b>PARTNO.:</b> 903-04644	
<b>DESCRIPTION:</b> SEAL KIT	
<b>KE PART NO:</b> KE-0081	
<b>APPLICATION:</b> BRAKERHYD.HAMMER-360	
<b>Details</b>	
<b>PARTNO.:</b> 550-42126	
<b>DESCRIPTION:</b> SEAL KIT	
<b>KE PART NO:</b> KE-0082	
<b>APPLICATION:</b> STAB.SEALKIT	
<b>Details</b>	
<b>PARTNO.:</b> 550-40998	
<b>DESCRIPTION:</b> SEAL KIT	
<b>KE PART NO:</b> KE-0083	
<b>APPLICATION:</b> BOOMRAMCYLINDER	
<b>Details</b>	
<b>PARTNO.:</b> 35-404202	
<b>DESCRIPTION:</b> SEAL KIT	
<b>KE PART NO:</b> KE-0084	
<b>APPLICATION:</b> STEARINGUNIT	
<b>Details</b>	
<b>PARTNO.:</b> 550-41000	
<b>DESCRIPTION:</b> SEAL KIT	
<b>KE PART NO:</b> KE-0085	
<b>APPLICATION:</b> LOADERBKT.RAM	

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	826-01080	
DESCRIPTION:	BOLT	
KE PART NO:	KE-0086	
APPLICATION:	CROWN PINION BOLT	
<b>Details</b>		
PARTNO.:	826-01483	
DESCRIPTION:	NUT	
KE PART NO:	KE-0087	
APPLICATION:	CROWN PINION NUT	
<b>Details</b>		
PARTNO.:	826-01744	
DESCRIPTION:	NUT	
KE PART NO:	KE-0088	
APPLICATION:	CROWNPINION11*37NUT	
<b>Details</b>		
PARTNO.:	122-38501	
DESCRIPTION:	GEARLEVER KNOB	
KE PART NO:	KE-0089	
APPLICATION:	GEARLEVER	
<b>Details</b>		
PARTNO.:	331-16516	
DESCRIPTION:	COUNTERPLATE	
KE PART NO:	KE-0090	
APPLICATION:	TRANSMISSIONCLUTCHHOUSING PLATE	

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	991-00018	
DESCRIPTION:	SLEWSEALKIT	
KE PART NO:	KE-0091	
APPLICATION:	SLEWCYLPISTONSEALKIT	
<b>Details</b>		
PARTNO.:	331-16520	
DESCRIPTION:	FRICTIONPLATE	
KE PART NO:	KE-0092	
APPLICATION:	TRANSMISSIONCLUTCHHOUSING PLATE	
<b>Details</b>		
PARTNO.:	331-22380	
DESCRIPTION:	WEARPAD	
KE PART NO:	KE-0093	
APPLICATION:	STABLISERPAD	
<b>Details</b>		
PARTNO.:	332/Y6440	
DESCRIPTION:	SEAL KIT	
KE PART NO:	KE-0094	
APPLICATION:	BOOMCYLINDERBACKHOE	
<b>Details</b>		
PARTNO.:	332/Y6262	
DESCRIPTION:	SEAL KIT	
KE PART NO:	KE-0095	
APPLICATION:	DIPPERRAMBACKHOE	

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	332/Y6519	
DESCRIPTION:	SEAL KIT	
KE PART NO:	KE-0096	
APPLICATION:	BUCKETRAMBACKHOE	
<b>Details</b>		
PARTNO.:	123-06227	
DESCRIPTION:	TUBE DIPSTICK	
KE PART NO:	KE-0097	
APPLICATION:	OILDIPSTICK GAUGE	
<b>Details</b>		
PARTNO.:	1450-0002	
DESCRIPTION:	GREASENIPPLE	
KE PART NO:	KE-0098	
APPLICATION:	GREASENIPPLE	
<b>Details</b>		
PARTNO.:	30-600701	
DESCRIPTION:	RADIATORCAP	
KE PART NO:	KE-0099	
APPLICATION:	RADIATORCAP	
<b>Details</b>		
PARTNO.:	32-901100	
DESCRIPTION:	HYDRAULICSTRAINER	
KE PART NO:	KE-0100	
APPLICATION:	HYDRAULICTANKSTRAINER	

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	32-902200	
DESCRIPTION:	TRANSMISSIONSTRAINER	
KE PART NO:	KE-0101	
APPLICATION:	TRANSMISSIONSTRAINER	
<b>Details</b>		
PARTNO.:	32-920100	
DESCRIPTION:	AIRFILTERASSY.	
KE PART NO:	KE-0102	
APPLICATION:	AIRCLEANERASSY.	
<b>Details</b>		
PARTNO.:	914-70045	
DESCRIPTION:	YOKE25.4MM	
KE PART NO:	KE-0103	
APPLICATION:	PUMPDRIVESHAFT	
<b>Details</b>		
PARTNO.:	445-18600	
DESCRIPTION:	DISKSRING	
KE PART NO:	KE-0104	
APPLICATION:	TRANSMISSION	
<b>Details</b>		
PARTNO.:	550-40926	
DESCRIPTION:	BUSH	
KE PART NO:	KE-0105	
APPLICATION:	BUCKETRAMTUBEEYEBUSH	

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	1208-0023	
DESCRIPTION:	CUTBUSH	
KE PART NO:	KE-0106	
APPLICATION:	LOADERBKT.BUSH	
<b>Details</b>		
PARTNO.:	904-50033	
DESCRIPTION:	SEAL	
KE PART NO:	KE-0107	
APPLICATION:	REARHUB SEAL	
<b>Details</b>		
PARTNO.:	126-00200	
DESCRIPTION:	RESERVOIR	
KE PART NO:	KE-0108	
APPLICATION:	BRAKE OIL	
<b>Details</b>		
PARTNO.:	813-00456	
DESCRIPTION:	SEAL	
KE PART NO:	KE-0109	
APPLICATION:	KPCBUSH SEAL	
<b>Details</b>		
PARTNO.:	40-302795	
DESCRIPTION:	MASTERCYLINDER2HOLE	
KE PART NO:	KE-0110	
APPLICATION:	BRAKEMASTERCYLINDER	

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	550-40980	
DESCRIPTION:	PLUNGERWITH WASHER	
KE PART NO:	KE-0111	
APPLICATION:	SLEWTUBEPLUNGER	
<b>Details</b>		
PARTNO.:	25-613701	
DESCRIPTION:	RETAINERBOOTWITH WIPER	
KE PART NO:	KE-0112	
APPLICATION:	SPOOLCOVER	
<b>Details</b>		
PARTNO.:	103-23802	
DESCRIPTION:	STAB.FOOT.O.M.	
KE PART NO:	KE-0113	
APPLICATION:	STABILISERFOOT	
<b>Details</b>		
PARTNO.:	500-00011	
DESCRIPTION:	OIL FILTER	
KE PART NO:	KE-0114	
APPLICATION:	ENGINEOILFILTER	
<b>Details</b>		
PARTNO.:	550-42394	
DESCRIPTION:	CROSS	
KE PART NO:	KE-0115	
APPLICATION:	REARDRIVESHAFT CROSS	

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	500-00214	
DESCRIPTION:	FILTERFUEL	
KE PART NO:	KE-0116	
APPLICATION:	DIESELFILTER	
<b>Details</b>		
PARTNO.:	500-00151	
DESCRIPTION:	FILTERFUELSECONDARY	
KE PART NO:	KE-0117	
APPLICATION:	DIESELFILTER	
<b>Details</b>		
PARTNO.:	1315-0103Z	
DESCRIPTION:	GREASECAP BOLT	
KE PART NO:	KE-0118	
APPLICATION:	FRONTHUBCAPSCREW	
<b>Details</b>		
PARTNO.:	1370-0301Z	
DESCRIPTION:	NUT	
KE PART NO:	KE-0119	
APPLICATION:	GRUBSCREWNUT	
<b>Details</b>		
PARTNO.:	1340-0905	
DESCRIPTION:	NUT	
KE PART NO:	KE-0120	
APPLICATION:	FRONTAXLESTUBAXLENUT	

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	130-00695	
DESCRIPTION:	HUBENDCAP	
KE PART NO:	KE-0121	
APPLICATION:	FRONTHUBCAP	
<b>Details</b>		
PARTNO.:	116-00416	
DESCRIPTION:	UNIVERSALJOINT	
KE PART NO:	KE-0122	
APPLICATION:	LOADERLIFTCONTROL UNIVERSAL JOINT	
<b>Details</b>		
PARTNO.:	116-00525	
DESCRIPTION:	STRAP	
KE PART NO:	KE-0123	
APPLICATION:	REARSHAFTCROSSSTRAP	
<b>Details</b>		
PARTNO.:	121-34400	
DESCRIPTION:	RESERVOIR	
KE PART NO:	KE-0124	
APPLICATION:	BREAKOILCONTAINER	
<b>Details</b>		
PARTNO.:	1208-0021	
DESCRIPTION:	CUTBUSH	
KE PART NO:	KE-0125	
APPLICATION:	BOOMRAMEYEBUSH	

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	1208-0031	
DESCRIPTION:	CUTBUSH	
KE PART NO:	KE-0126	
APPLICATION:	LOADERBUCKETPINBUSH	
<b>Details</b>		
PARTNO.:	1208-0032	
DESCRIPTION:	CUTBUSH	
KE PART NO:	KE-0127	
APPLICATION:	LOADERBUCKETPINBUSH	
<b>Details</b>		
PARTNO.:	458-20672	
DESCRIPTION:	CROWN PINION 3DX	
KE PART NO:	KE-0128	
APPLICATION:	REARAXLECROWNPINION11*37	
<b>Details</b>		
PARTNO.:	450-10211,10218,10224,20353	
DESCRIPTION:	PLATEFRICTIONBRAKE	
KE PART NO:	KE-0129	
APPLICATION:	BRAKEAXLE PLATE	
<b>Details</b>		
PARTNO.:	445-03035	
DESCRIPTION:	SCREW	
KE PART NO:	KE-0130	
APPLICATION:	FORKSELECTORSCREW	

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	445-03206	
DESCRIPTION:	COUNTERPLATE	
KE PART NO:	KE-0131	
APPLICATION:	TRANSMISSIONCOUNTERPLATE	
<b>Details</b>		
PARTNO.:	445-10802	
DESCRIPTION:	SEAT	
KE PART NO:	KE-0132	
APPLICATION:	GEARLEVER SEAT	
<b>Details</b>		
PARTNO.:	SSE-30108	
DESCRIPTION:	SPOOL	
KE PART NO:	KE-0133	
APPLICATION:	EXCAVATORVALVEBLOCKSPOOL	
<b>Details</b>		
PARTNO.:	910-28400	
DESCRIPTION:	STOP CABLE	
KE PART NO:	KE-0134	
APPLICATION:	STOPING CABLE	
<b>Details</b>		
PARTNO.:	910-28400A	
DESCRIPTION:	STOP CABLE	
KE PART NO:	KE-0135	
APPLICATION:	BREAKINGCABLE	

# KRISHNA ENTERPRISES

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	910-24901A	
DESCRIPTION:	INNERCABLE	
KE PART NO:	KE-0136	
APPLICATION:	BREAKINGINNERCABLE	
<b>Details</b>		
PARTNO.:	904-05100	
DESCRIPTION:	SEAL	
KE PART NO:	KE-0137	
APPLICATION:	36TEETHGEARSEAL	
<b>Details</b>		
PARTNO.:	904-06200	
DESCRIPTION:	SEAL	
KE PART NO:	KE-0138	
APPLICATION:	FRONTAXLEHUBDUSTSEAL	
<b>Details</b>		
PARTNO.:	904-06201	
DESCRIPTION:	SLEEVE	
KE PART NO:	KE-0139	
APPLICATION:	FRONTAXLEHUBDUSTSEAL COVER	
<b>Details</b>		
PARTNO.:	904-06700	
DESCRIPTION:	SEAL	
KE PART NO:	KE-0140	
APPLICATION:	4WDREARAXLETRUNIONSEAL	

# KRISHNA ENTERPRISES

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	904-07100	
DESCRIPTION:	SEAL	
KE PART NO:	KE-0141	
APPLICATION:	FRONTAXLEKINGPIN SEAL	
<b>Details</b>		
PARTNO.:	904-09300	
DESCRIPTION:	SEAL	
KE PART NO:	KE-00142	
APPLICATION:	TIERODPINDUSTSEAL	
<b>Details</b>		
PARTNO.:	904-20172	
DESCRIPTION:	SEAL	
KE PART NO:	KE-0143	
APPLICATION:	TRANSMISSIONYOKEFLANGESEAL	
<b>Details</b>		
PARTNO.:	904-50023	
DESCRIPTION:	SEAL	
KE PART NO:	KE-0144	
APPLICATION:	CROWN PINION SEAL	
<b>Details</b>		
PARTNO.:	921-01900	
DESCRIPTION:	SHIMKIT	
KE PART NO:	KE-0145	
APPLICATION:	BEARINGADJUSTINSHIMKIT	

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	921-02100	
DESCRIPTION:	SHIMKIT	
KE PART NO:	KE-0146	
APPLICATION:	BEARINGADJUSTINSHIMKIT	
<b>Details</b>		
PARTNO.:	25-606504	
DESCRIPTION:	SEAL KIT	
KE PART NO:	KE-0147	
APPLICATION:	HYDROCLAMPSPOOLSEALKIT	
<b>Details</b>		
PARTNO.:	25-606812	
DESCRIPTION:	ORING	
KE PART NO:	KE-0148	
APPLICATION:		
<b>Details</b>		
PARTNO.:	25-606835	
DESCRIPTION:	WIPERSEAL	
KE PART NO:	KE-0149	
APPLICATION:	LOADERVALVESPOOLDUSTSEAL	
<b>Details</b>		
PARTNO.:	25-606836	
DESCRIPTION:	ORING	
KE PART NO:	KE-0150	
APPLICATION:	LOADERVALVESPOOLRING	

# KRISHNA ENTERPRISES

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	25-606837	
DESCRIPTION:	ORING	
KE PART NO:	KE-0151	
APPLICATION:	LOADERVALVESPOOLRING	
<b>Details</b>		
PARTNO.:	25-618901	
DESCRIPTION:	VALVERELIEF	
KE PART NO:	KE-0152	
APPLICATION:	LOADERVALVEMAINRELIEF	
<b>Details</b>		
PARTNO.:	25-975703	
DESCRIPTION:	SEAL	
KE PART NO:	KE-0153	
APPLICATION:	EXCAVATORVALVESPOOLSEAL	
<b>Details</b>		
PARTNO.:	25-932109	
DESCRIPTION:	SEAL KIT	
KE PART NO:	KE-0154	
APPLICATION:	MRVREPAIRKIT	
<b>Details</b>		
PARTNO.:	25-975704	
DESCRIPTION:	SEAL	
KE PART NO:	KE-0155	
APPLICATION:	EXCAVATORVALVESPOOLDUSTSEAL	

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	2203-0035	
DESCRIPTION:	CIRCLIP	
KE PART NO:	KE-0156	
APPLICATION:	TIERODPINCIRCLIP	
<b>Details</b>		
PARTNO.:	2203-0054	
DESCRIPTION:	CIRCLIP	
KE PART NO:	KE-0157	
APPLICATION:	TIERODPINCIRCLIP	
<b>Details</b>		
PARTNO.:	813-00182	
DESCRIPTION:	GASKET	
KE PART NO:	KE-0158	
APPLICATION:	KPCPLATE	
<b>Details</b>		
PARTNO.:	813-00316	
DESCRIPTION:	GASKET	
KE PART NO:	KE-0159	
APPLICATION:	TRANSGASKET	
<b>Details</b>		
PARTNO.:	813-00360	
DESCRIPTION:	HYDRAULICTANKGASKET	
KE PART NO:	KE-0160	
APPLICATION:	HYDRAULICTANKGASKET	


## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	813-00425	
DESCRIPTION:	SEAL	
KE PART NO:	KE-0161	
APPLICATION:	BKTPINDUST SEAL	
<b>Details</b>		
PARTNO.:	813-00426	
DESCRIPTION:	SEAL	
KE PART NO:	KE-0162	
APPLICATION:	DIPPERPINDUSTSEAL	
<b>Details</b>		
PARTNO.:	814-00221	
DESCRIPTION:	SPRING	
KE PART NO:	KE-0163	
APPLICATION:	GEARLEVERHOUSINGSPRING	
<b>Details</b>		
PARTNO.:	814-00382	
DESCRIPTION:	TENSIONSPRING	
KE PART NO:	KE-0164	
APPLICATION:	BRAKEPEDAL	
<b>Details</b>		
PARTNO.:	814-00383	
DESCRIPTION:	SPRING	
KE PART NO:	KE-0165	
APPLICATION:	BRAKESPRING	

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	819-00049A	
DESCRIPTION:	SHIM	
KE PART NO:	KE-0166	
APPLICATION:	BUCKETPINADJUSTING SHIM	
<b>Details</b>		
PARTNO.:	819-00049B	
DESCRIPTION:	SHIM3mm	
KE PART NO:	KE-0167	
APPLICATION:	BUCKETPINADJUSTING SHIM	
<b>Details</b>		
PARTNO.:	819-00100	
DESCRIPTION:	SHIM1mm	
KE PART NO:	KE-0168	
APPLICATION:	BOOMMAINPINADJUSTINGSHIM	
<b>Details</b>		
PARTNO.:	819-00100A	
DESCRIPTION:	SHIM2mm	
KE PART NO:	KE-0169	
APPLICATION:	BOOMMAINPINADJUSTINGSHIM	
<b>Details</b>		
PARTNO.:	819-00136	
DESCRIPTION:	THRUST WASHER5.5mm	
KE PART NO:	KE-0170	
APPLICATION:	FRONTAXLECENTERPINWASHER	

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	819-00137	
DESCRIPTION:	THRUST WASHER6mm	
KE PART NO:	KE-0171	
APPLICATION:	FRONTAXLECENTERPINWASHER	
<b>Details</b>		
PARTNO.:	808-00209	
DESCRIPTION:	WASHERTHRUST SIDEGEAR	
KE PART NO:	KE-0172	
APPLICATION:	STARGEARKITCOPPERWASHER	
<b>Details</b>		
PARTNO.:	808-00226	
DESCRIPTION:	BRASSBUSH	
KE PART NO:	KE-0173	
APPLICATION:	FRONTAXLESTEERINGROD BUSH	
<b>Details</b>		
PARTNO.:	808-00253	
DESCRIPTION:	BRASSBUSH	
KE PART NO:	KE-0174	
APPLICATION:	FRONTAXLETIERODBUSH	
<b>Details</b>		
PARTNO.:	809-00129	
DESCRIPTION:	BUSHNORMAL	
KE PART NO:	KE-0175	
APPLICATION:	BUCKET	

# KRISHNA ENTERPRISES

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	809-00130	
DESCRIPTION:	BUSH	
KE PART NO:	KE-0176	
APPLICATION:	BOOM	
<b>Details</b>		
PARTNO.:	809-10030	
DESCRIPTION:	BUSH	
KE PART NO:	KE-0177	
APPLICATION:	LOADERARM	
<b>Details</b>		
PARTNO.:	828-00207	
DESCRIPTION:	ORING	
KE PART NO:	KE-0178	
APPLICATION:	GEARBOX FACETO FACE	
<b>Details</b>		
PARTNO.:	828-00224	
DESCRIPTION:	ORING	
KE PART NO:	KE-0179	
APPLICATION:	TRANSMISSIONO RING	
<b>Details</b>		
PARTNO.:	828-10180	
DESCRIPTION:	ORING	
KE PART NO:	KE-0180	
APPLICATION:	TRANSMISSIONPISTONBIG	

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	823-00576	
DESCRIPTION:	WASHER	
KE PART NO:	KE-0181	
APPLICATION:	HYDRACLAMPWASHER	
<b>Details</b>		
PARTNO.:	823-00577	
DESCRIPTION:	CLAMPWASHER	
KE PART NO:	KE-0182	
APPLICATION:	HYDRACLAMPHOUSINGN.M.	
<b>Details</b>		
PARTNO.:	808-00210	
DESCRIPTION:	WASHERTHRUSTPINION	
KE PART NO:	KE-0183	
APPLICATION:	STARGEARKITCOPPERWASHER	
<b>Details</b>		
PARTNO.:	331/43118	
DESCRIPTION:	OUTSIDEDOORHANDLEWITHKEYS	
KE PART NO:	KE-0184	
APPLICATION:	DOORHANDLE	
<b>Details</b>		
PARTNO.:	331/31071	
DESCRIPTION:	CATCHWINDOWLOCK	
KE PART NO:	KE-0185	
APPLICATION:	LOCK	



KRISHNA ENTERPRISES  
JCB & Hitachi Spare Parts

# KRISHNA ENTERPRISES

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	123/05892	
DESCRIPTION:	FUEL TANK LOCK WITH KEYS	
KE PART NO:	KE-0186	
APPLICATION:	FUEL CAP	
<b>Details</b>		
PARTNO.:		
DESCRIPTION:	FUEL TANK LOCK WITH KEYS	
KE PART NO:	KE-0187	
APPLICATION:	FUEL CAP	
<b>Details</b>		
PARTNO.:	121/13400LH 121/13500RH	
DESCRIPTION:	DOOR LATCH ASSY.O/M	
KE PART NO:	KE-0188	
APPLICATION:	DOOR LOCK ASSLY.	
<b>Details</b>		
PARTNO.:	123/02451RH 123/02450LH	
DESCRIPTION:	DOOR LATCH ASSY.3DX 21"INCH	
KE PART NO:	KE-0189	
APPLICATION:	DOOR LOCK ASSLY.	
<b>Details</b>		
PARTNO.:	122/23510	
DESCRIPTION:	DOOR STOPPER	
KE PART NO:	KE-0190	
APPLICATION:	DOOR STOPPER	

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	331/38532	
DESCRIPTION:	DOORSTOPPER	
KE PART NO:	KE-0191	
APPLICATION:	DOORSTOPPER	
<b>Details</b>		
PARTNO.:	125/35000	
DESCRIPTION:	STEERINGWHEEL	
KE PART NO:	KE-0192	
APPLICATION:	WHEEL	
<b>Details</b>		
PARTNO.:	123/03842	
DESCRIPTION:	STEERINGWHEELKNOB	
KE PART NO:	KE-0193	
APPLICATION:	KNOB	
<b>Details</b>		
PARTNO.:		
DESCRIPTION:	CENTERCAPOF STEERING	
KE PART NO:	KE-0194	
APPLICATION:	CAP	
<b>Details</b>		
PARTNO.:	700/21100	
DESCRIPTION:	HEADLAMPOLDMODEL	
KE PART NO:	KE-0195	
APPLICATION:	HEADLAMP	

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	700/38400	
DESCRIPTION:	HEADLAMPNEWMODEL	
KE PART NO:	KE-0196	
APPLICATION:	HEADLAMP	
<b>Details</b>		
PARTNO.:	700/38800	
DESCRIPTION:	WORK LAMPSQUARE	
KE PART NO:	KE-0197	
APPLICATION:	WORK LAMPSQUARE	
<b>Details</b>		
PARTNO.:	700/38800	
DESCRIPTION:	WORKLAMPSQUAREYELLOW	
KE PART NO:	KE-0198	
APPLICATION:	WORK LAMPSQUARE	
<b>Details</b>		
PARTNO.:	700/10100	
DESCRIPTION:	WORKLAMPSQUARERECT	
KE PART NO:	KE-0199	
APPLICATION:	WORK LAMPRECT	
<b>Details</b>		
PARTNO.:		
DESCRIPTION:	WORKLAMPSQUAREOVAL	
KE PART NO:	KE-0200	
APPLICATION:	WORK LAMPOVAL	

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	32/913400	
DESCRIPTION:	HYDRACLICFILTER	
KE PART NO:	KE-0201	
APPLICATION:	FILTER	
<b>Details</b>		
PARTNO.:		
DESCRIPTION:	BOOT( OLD MODEL)	
KE PART NO:	KE-0202	
APPLICATION:	GEARLEVERBOOT3D	
<b>Details</b>		
PARTNO.:		
DESCRIPTION:	BOOT(NEWMODEL)	
KE PART NO:	KE-0203	
APPLICATION:	GEARLEVERBOOT3DX	
<b>Details</b>		
PARTNO.:		
DESCRIPTION:	FUSEBOX	
KE PART NO:	KE-0204	
APPLICATION:	FUSEBOX	
<b>Details</b>		
PARTNO.:		
DESCRIPTION:	SOLENOIDCOILS	
KE PART NO:	KE-0205	
APPLICATION:	SOLENOIDCOILS	



## SPARE PARTS OF JCB

<b>Details</b>	
PARTNO.:	
DESCRIPTION:	CYLINDER3HOLE
KE PART NO:	KE-0206
APPLICATION:	MASTERBRAKE CYLINDER
<b>Details</b>	
PARTNO.:	
DESCRIPTION:	OILSEAL
KE PART NO:	207
APPLICATION:	REARWHEELOILSEAL
<b>Details</b>	
PARTNO.:	335/Y1458
DESCRIPTION:	CUTTER KIT (with Fastners)
KE PART NO:	KE-0208
APPLICATION:	CUTTER KIT
<b>Details</b>	
PARTNO.:	4002/3000-20
DESCRIPTION:	HYDRAULIC OIL JCB
KE PART NO:	KE-0209
APPLICATION:	
<b>Details</b>	
PARTNO.:	4000/2500-20
DESCRIPTION:	JCBTransmissionOilPlus
KE PART NO:	KE-0210
APPLICATION:	

# KRISHNA ENTERPRISES

## SPARE PARTS OF JCB

<b>Details</b>		
PARTNO.:	4001/3200-15	
DESCRIPTION:	JCB Engine Oil Max	
KE PART NO:	KE-0211	
APPLICATION:	JCB Engine Oil	
<b>Details</b>		
PARTNO.:	4000/4600-20	
DESCRIPTION:	JCB Rear Axle Oil.	
KE PART NO:	KE-0212	
APPLICATION:	JCB Rear Axle Oil.	
<b>Details</b>		
PARTNO.:	4003/2500-18,07,03	
DESCRIPTION:	JCB Grease 18 K.G.- 7K.G.- 3K.G.	
KE PART NO:	KE-0213	
APPLICATION:	JCB Grease	
<b>Details</b>		
PARTNO.:	335/Y1458	
DESCRIPTION:	CUTTER KIT N PREMIUM	
KE PART NO:	KE-214	
APPLICATION:	CUTTER KIT	
<b>Details</b>		
PARTNO.:	400/02216	
DESCRIPTION:	Grease Gun JCB	
KE PART NO:	KE-215	
APPLICATION:	Grease Gun	