

Packet Loss Tool User Guide

Contents

Packet Loss Tool User Guide	1
1. Introduction	2
1.1 Overview	2
2 Getting Packet Loss Tool	3
2.1 Plastic Release Repo.....	3
3 Configuring Packet Loss Tool	3
3.1 Config File.....	3
4 Using Packet Loss Tool	4
4.1 Basic Usage.....	4
5 Glossary.....	5

1. Introduction

1.1 Overview

1.1.1 Purpose of this document and intended audience

This document, called the Packet Loss Tool User Guide, is both an usage guide and an reference guide. This guide is for APTIV Internal users, offering full step-by-step usage, configuration instructions and support areas.

1.1.2 Steps to take

In order to be able to use Packet Loss Tool, you must first have a Windows or Linux Environment.

The first step, illustrates getting Packet Loss Tool from Plastic Resim Release Repo Binaries onto your computer. The second step, shows how to customize a Packet Loss Tool with Config Files depending on your individual needs. The final step, covers the specific steps you can take to get the Packet Loss Tool application to run.

1.1.3 Quick start

The process of Getting and Running Packet Loss Tool can be summarized as follows:

- For the casual or new user the simplest way is to get a Binaries from Plastic Release Repository.
- Configure depending on your individual needs.
- Run Packet Loss Tool using below command

For Binaries :

```
MUDP_Log_DataExtractor.exe "path/to/Packetloss_Tool_Config.xml" "path/to/f_list.txt" "path/to/files to be generated "
```

```
MUDP_Log_DataExtractor.exe "path/to/Packetloss_Tool_Config.xml" "path/to/json" "path/to/files to be generated"
```

For Docker :

```
./GEN_LOG.sh /input/Packetloss_Tool_Config.xml "path/to/MUDP_DATA_Extractor_config.xml" "path/to/json" "path/to/files to be generated"
```

```
./GEN_LOG.sh /input/Packetloss_Tool_Config.xml /input/BMW_fList.json /input/OUTPUT_DIR
```

Author: SWATHI K

Version 1.0

Copyright © 2018 Aptiv Advanced Safety & User Experience

Confidential – Restricted Aptiv information. Do not disclose

1.2 What is Packet Loss Tool?

1.2.1 Operating System

Different software programs are designed for different operating systems, and most won't work on systems that they weren't designed for. Packet Loss Tool is Supported on Both Windows and Linux Operating System.

1.2.2 What is Packet Loss Tool, and how can it help me?

Packet Loss Tool can be used to analyze list of logs. Packet Loss tool would generate XML or txt based report for log analysis.

Packet Loss Tool report would give following information from the log-

- Log name
- Report Generation time
- CS Number
- Packet Loss Summery
 - Bad log scenarios

2 Getting Packet Loss Tool

2.1 Plastic Release Repo

By far the easiest way to get Packet Loss Tool is from Plastic Resim Release Repo. Always move to the latest Change set to have the updated version of Packet Loss Tool. These packages contain ready-to-run binary files specifically compiled in release mode for distribution, and they are tested regularly by the developers for both functionality and completeness.

We have made package easily available at

RESIM Release repository Details-

Repository: "10028634_01_SRR_RESIM_Release@plasticscm_prod1.delphiauto.net:8087"

Latest Change Set.

Path: 10028634_01_SRR_RESIM_Release\RESIM_Toolset\MUDP_LogData_Extractertool\Packetloss_Tool

3 Configuring Packet Loss Tool

3.1 Config File

Author: [SWATHI K](#)

Version 1.0

Copyright © 2018 Aptiv Advanced Safety & User Experience

Confidential – Restricted Aptiv information. Do not disclose

Packet Loss Tool can be configured using Packetloss_Tool_Config.xml.

Packetloss_Tool_Config.xml contains XML attributes to configure following items-

- Setting Report Output path

```
<!-- Resim output path selection. Options are SAME_AS_INPUT or NEW_OUTPUT_PATH or SAME_AS_OUTPUT
      SAME_AS_OUTPUT : This is Optional . Files will generated path provided in the third command line argument  -->
<Output_Path_Options>SAME_AS_OUTPUT</Output_Path_Options>
<!-- If resim output path selection is NEW_OUTPUT_PATH use the below tag to enter valid folder path -->
<Output_Path_Location>NONE</Output_Path_Location>
```

- To Generate XML based Packet Loss Report, use “Data_Extraction_Mode” and set “Log_Quality_Summary” to 1.

```
<!-- Data_Extraction_Mode User Options :
Log_Quality_Check :
      0 : Does not prints prints Packet loss Info
      1 : prints Packet loss Summary Table at the end  -->

<Data_Extraction_Mode>
      <Log_Quality_Summary>1</Log_Quality_Summary>
</Data_Extraction_Mode>
```

4 Using Packet Loss Tool


4.1 Basic Usage

This section will describe all aspects of using Packet Loss Tool, such as running executables, command line parameters, Reading the report, etc.

You can use Packet Loss Tool with following command:

Usage: ./GEN_LOG.sh /input/Packetloss_Tool_Config.xml /input/BMW_fList.json /input/OUTPUT_DIR

Run the program




Author: SWATHI K

Version 1.0

Copyright © 2018 Aptiv Advanced Safety & User Experience

Confidential – Restricted Aptiv information. Do not disclose

Logs is parsed and parsed details are captured in the packet loss report. Once the packet loss information is extracted, user would be notified with success or failure message.



```

C:\Select C:\WINDOWS\system32\cmd.exe
MUDP_Log_DataExtractor.exe version 10.0.7
/*=====*/
Packet_Loss Extraction started for the Log :C:\Logs\TICKET\CYW-1502\20201002T181716_20201002T181726_000000_LJ09090_SRR4.
0_SRR_DEBUG.MF4!!

Packet_Loss information extraction completed for the Log :C:\Logs\TICKET\CYW-1502\20201002T181716_20201002T181726_000000
_LJ09090_SRR4.0_SRR_DEBUG.MF4!!

/*=====*/

Reading next log file from the input list...

Press any key to continue . . .
  
```

Report will be generated with name- “Data_Logging_Quality.xml”.

This report would contain following information all sensor data in the log-

- Log name
- Report Generation time
- Packet Loss Summary

5 Glossary

Binary

A file which is in machine executable, compiled form: hex data.

DLL

A DLL (Dynamic Link Library) is a file that can be loaded and executed by programs dynamically.

Terminal

A terminal window is usually a command line window that one uses to execute a command.